


# OPERATION AND MAINTENANCE MANUAL


## LOW HUMIDITY GENERATOR SERIES 3900



**THUNDER SCIENTIFIC<sup>®</sup>**  
**CORPORATION**

# **SERIES 3900 LOW HUMIDITY GENERATOR**

## **OPERATION AND MAINTENANCE MANUAL**



Copyright © 1993-2018  
THUNDER SCIENTIFIC CORPORATION  
623 WYOMING BLVD. SE  
ALBUQUERQUE, NEW MEXICO 87123-3198  
**[www.thunderscientific.com](http://www.thunderscientific.com)**

Printed 2018

Tel: 505.265.8701 ✈ FAX: 505.266.6203

E-mail: [support@thunderscientific.com](mailto:support@thunderscientific.com)

Document Edition 16 ♦ June 2018  
Firmware Version 2.12

**THUNDER SCIENTIFIC®** is the registered trademark of Thunder Scientific Corporation.  
All the information provided in this document is correct and true at the time of publication.  
Thunder Scientific Corporation reserves the right to change any technical data without notice.

MADE IN USA





**Model 3900 Low Humidity Generator**

# TABLE OF CONTENTS

## Section 1 - GENERAL INFORMATION

	List of Reference Drawings - iv	
	Warranty	
1.1	INTRODUCTION -----	1-1
1.2	PRINCIPLE OF OPERATION -----	1-1
1.2.1	General Description-----	1-1
1.2.2	Humidity Formulas -----	1-1
1.2.2.1	Saturation Vapor Pressure, $e$ -----	1-2
1.2.2.2	Enhancement Factor, $f$ -----	1-3
1.2.2.3	Frost Point -----	1-4
1.2.2.4	Dew Point -----	1-5
1.2.2.5	Parts Per Million by Volume, PPMv -----	1-5
1.2.2.6	Parts Per Million by Weight, PPMw -----	1-6
1.2.2.7	Relative Humidity, %RH-----	1-6
1.3	SPECIFICATIONS -----	1-7
1.3.1	Facility Requirements -----	1-7
1.3.2	Environmental -----	1-7
1.4	COMPUTER/CONTROL SYSTEM -----	1-8
1.4.1	General Description-----	1-8
1.4.2	Computer/Control System Configuration -----	1-8
1.4.2.1	Central Processing Unit (CPU)-----	1-8
1.4.2.2	Liquid Crystal Display (LCD) -----	1-9
1.4.2.3	Liquid Crystal Display Driver -----	1-9
1.4.2.4	Keypad -----	1-9
1.4.2.5	Memory Card -----	1-9
1.4.2.6	Analog to Digital Converter (A/D) -----	1-9
1.5	ELECTRICAL SYSTEM-----	1-10
1.5.1	AC Power Distribution -----	1-10
1.5.2	Power Supply $\pm 15$ , +5 VDC -----	1-10
1.5.3	Power Supply +24 VDC -----	1-10
1.5.4	Analog Inputs -----	1-11
1.5.4.1	Temperature Measurement-----	1-11
1.5.4.2	Test Pressure Transducer-----	1-11
1.5.4.3	Low Range Saturation Pressure Transducer -----	1-12
1.5.4.4	High Range Saturation Pressure Transducer -----	1-12
1.5.4.5	Gas Supply Pressure Transducer -----	1-12
1.5.4.6	Mass Flow Meter -----	1-12
1.5.5	Control Logic -----	1-13
1.5.5.1	Gas Supply Solenoid Valve-----	1-13
1.5.5.2	Fluid Pump Purge Solenoid Valve-----	1-13

1.5.5.3	Saturator Vent/Purge Solenoid Valve-----	1-13
1.5.5.4	Pressure Select Solenoid Valve-----	1-13
1.5.5.5	Saturator Refrigerant Solenoid Valve-----	1-14
1.5.5.6	Saturator Inlet/Outlet Heater -----	1-14
1.5.5.7	Saturator Fluid Heater-----	1-14
1.5.5.8	Saturator Fluid Circulation Pump -----	1-14
1.5.5.9	Saturator Refrigeration Compressors -----	1-14
1.5.5.10	Flow Control Valve -----	1-15
1.5.5.11	Expansion Valve-----	1-15
1.5.5.12	Expansion Valve Heater -----	1-15
1.6	PNEUMATIC SYSTEM-----	1-16
1.7	FLUID SYSTEMS -----	1-16
1.7.1	Saturator Fluid Systems-----	1-16
1.8	REFRIGERATION -----	1-17
1.8.1	Saturator Refrigeration-----	1-17

## Section 2 - INSTALLATION

2.1	GENERAL -----	2-1
2.2	FACILITIES REQUIRED -----	2-1
2.2.1	Floor Space -----	2-1
2.2.2	Power-----	2-1
2.2.3	Gas Supply-----	2-1
2.3	PREPARATION -----	2-1
2.3.1	Methanol Filling Procedure -----	2-2
2.3.2	Vent Muffler-----	2-3
2.4	POSITIONING AND LEVELING -----	2-3
2.5	FACILITY CONNECTIONS-----	2-3
2.5.1	Gas Supply-----	2-3
2.5.2	Pressure Vent-----	2-3
2.5.3	AC Power-----	2-3

## Section 3 - OPERATION

3.1	GENERAL -----	3-1
3.2	STANDARD OPERATING PROCEDURES -----	3-1
3.2.1	Power-Up -----	3-1
3.2.2	Control/Display Screen -----	3-1
3.2.2.1	Changing the Display Contrast -----	3-3
3.2.3	Changing Setpoints-----	3-4
3.2.3.1	Example Setpoint Change -----	3-5
3.2.4	Control Modes -----	3-7
3.2.4.1	Changing Control Mode -----	3-8
3.2.5	Purging -----	3-10

3.2.5.1	Purging Procedure-----	3-11
3.2.6	Saturator Clear-----	3-12
3.2.6.1	Saturator Clear Procedure-----	3-12
3.2.7	Generating-----	3-13
3.2.7.1	Generating Procedure-----	3-14
3.2.7.2	Example Instrument Set-up-----	3-15
3.2.8	Saturator Fill-----	3-16
3.2.8.1	Saturator Fill Procedure-----	3-16
3.2.9	Stopping-----	3-18
3.2.10	Shutdown-----	3-19
3.2.11	Changing Gas Supply-----	3-19
3.2.12	Printer (optional)-----	3-19
3.3	EDITING SYSTEM COEFFICIENTS AND PARAMETERS-----	3-20
3.3.1	Edit Mode-----	3-20
3.3.2	Coefficients and Parameters-----	3-22
3.3.2.1	Temperature Coefficients-----	3-22
3.3.2.2	Reference Resistor Coefficients-----	3-23
3.3.2.3	Pressure Coefficients-----	3-23
3.3.2.4	Flow Coefficients-----	3-24
3.3.2.5	Console Port Parameters-----	3-25
3.3.2.6	Printer Port Parameters-----	3-26
3.3.2.7	Time and Date-----	3-26
3.3.2.8	Miscellaneous User Parameters-----	3-27

#### **Section 4 - CALIBRATION AND MAINTENANCE**

4.1	GENERAL-----	4-1
4.2	CALIBRATION-----	4-1
4.2.1	A/D Card-----	4-2
4.2.2	Temperature Calibration-----	4-2
4.2.2.1	Test Temperature Calibration Procedure-----	4-3
4.2.2.2	Saturation Temperature Calibration-----	4-7
4.2.3	Pressure Transducer Calibration-----	4-11
4.2.3.1	Saturator and Test Pressure Calibration Procedure-----	4-12
4.2.3.2	Supply Pressure Transducer Calibration-----	4-16
4.2.4	Flow Meter Calibration-----	4-18
4.2.4.1	Flow Calibration Procedure-----	4-18
4.2.5	Printing Condensed Coefficient Report-----	4-22
4.3	ROUTINE MAINTENANCE-----	4-23
4.3.1	Console Intake: Monthly-----	4-23
4.3.2	7 Micron Gas Input Filter: Yearly-----	4-23
4.4	SERVICING REFRIGERATION AND FLUID SYSTEMS-----	4-24
4.4.1	Fault Isolation and Diagnosis-----	4-24
4.4.1.1	Moisture In Low Stage-----	4-24
4.4.1.2	Oil In Low Stage Evaporator-----	4-25

4.4.2	Refrigerant Charge -----	4-25
4.4.3	Saturator Fluid System-----	4-25
4.4.4	Methanol System Drain/Fill Procedure-----	4-25
4.5	ERROR CODES AND TROUBLESHOOTING -----	4-27

**Section 5 - PARTS LIST**

5.1	3900 PARTS LIST -----	5-1
-----	-----------------------	-----

LIST OF REFERENCE DRAWINGS

DRAWING #	DRAWING TITLE
94D39901 -----	Mechanical/ Utility
95D39902 -----	Component Locations
95D39903 -----	Card Cage and Card Locations
95D39904 -----	3900 Bus Diagram
95D39905 -----	Electrical Sub-Panel Layout
95S39906 -----	Terminal Layout
95S39907 -----	AC/DC Power Schematic
95S39908 -----	Solid State Relay Module Board
95S39909 -----	Compressor / Heater / Alarm Schematic
95S39910 -----	Flow Valve Drive Schematic
95S39911 -----	Expansion Valve Drive Schematic
95S39912 -----	Temperature Probe / Transducer Schematic
95S39913 -----	Display Block Diagram
95D39914 -----	RS-232C Console / Printer
95S39915 -----	Pneumatic System (Generate Mode)
95S39916 -----	Pneumatic System (Purge Mode)
95S39917 -----	Refrig And Fluid Flow - Saturator
95S39918 -----	Test Temp/Test Press Xducer Schematic
08S39921 -----	3900 Card Cage Schematic
08D39922 -----	Methanol Fill Level Drawing
15A39504 -----	4-Port Sample Cell Manifold

## WARRANTY

Thunder Scientific Corporation (TSC) warrants, to the Buyer, the Product manufactured by TSC to be free of defects in material and workmanship under normal use and service and to be free from inadequate mechanical design when operated within the specified design limitations for a period of one year from date of acceptance. TSC's obligation under this warranty shall be limited to the following: the Product is returned to TSC with transportation charges prepaid and that TSC's examination reveals the Product to be defective. TSC, at its option, shall either refund to the Buyer the purchase price of the product or repair or replace at TSC's plant, any part or parts of the Product which is or are defective. This warranty shall not apply to any Product which has been maintained, handled, stored, repaired or altered in any manner, or by anyone other than an authorized TSC representative, so as to affect adversely such Product or which has been subject to improper installation, misuse, negligence, accident or corrosion. THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY, WHETHER EXPRESS OR IMPLIED, AND ALL OTHER LIABILITIES AND OBLIGATIONS ON THE PART OF TSC; TSC SHALL NOT BE LIABLE FOR ANY OTHER CLAIMS OR DAMAGES, EITHER DIRECT OR CONSEQUENTIAL, ARISING DIRECTLY OR INDIRECTLY OUT OF SUPPLYING THE PRODUCT. All warranties, express or implied, with respect to any device or component not manufactured by TSC but incorporated into its Product are the responsibility of the original manufacturer and shall not affect or apply to TSC.

**3900 Item Check List**

1. Certificate of Calibration (In Manual)

2. Operation and Maintenance Manual

3. HumiCalc<sup>®</sup> with Uncertainty Software Download

4. 3900 ControLog<sup>®</sup> Software Download

5. 5/32" Ball Driver Tool

6. Power Cable

7. Transducer Test Pressure Cable

8. Test Temp Cable

9. Printer Cable



10. Computer IO Control Cable

11. Pure Water Fill Funnel

12. 1/4" 30 Micron Muffler

13. Pressure Transducer 0 – 50 Psi

14. 1/4" Swage x 9/16" – 18 STD



## Suomi

Tämä tuote noudattaa WEEE-direktiivin (2002/96/EY) merkintävaatimuksia. Kiinnitetty etiketti osoittaa, että tätä sähkö-/elektroniikkalaitetta ei saa hävittää kotitalousjätteissä.

**Tuoteluokka:** Viitaten WEEE-direktiivin liitteessä I mainittuihin laitteisiin, tämä tuote on luokiteltu luokan 9 "Tarkkailu- ja ohjauslaitteet" -tuotteeksi.



**Ei saa heittää kotitalousjätteiden mukana!**

Palauta tarpeettomat tuotteet ottamalla yhteyttä valmistajan websivustoon, joka mainitaan tuotteessa tai paikalliseen myyntitoimistoon tai jakelijaan.

## Dansk

Dette produkt er i overensstemmelse med kravene om afmærkning i WEEE-direktivet (2002/96/EC). Det påhæftede mærkat angiver, at du ikke må bortskaffe dette elektriske/elektroniske produkt via husholdningsaffald.

**Produktkategori:** Med reference til kravene i WEEE-direktivets bilag I klassificeres dette produkt som et produkt til "overvågning og kontrolinstrumentering" i kategori 9.



**MÅ ikke bortskaffes via husholdningsaffald!**

Hvis du vil returnere uønskede produkter, skal du besøge producentens websted, som vises på produktet, eller den lokale forhandler eller distributør.

## English

This product complies with the WEEE Directive (2002/96/EC) marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste.

**Product Category:** With reference to the equipment types in the WEEE Directive Annex I, this product is classed as category 9 "Monitoring and Control Instrumentation" product.



**Do not dispose in domestic household waste!**

To return unwanted products, contact the manufacturer's web site shown on the product or your local sales office or distributor.

## Français

Ce produit est conforme aux normes de marquage de la directive DEEE (2002/96/CE). La présence de cette étiquette indique que cet appareil électrique/électronique ne doit pas être mis au rebut avec les déchets ménagers.

**Catégorie de DEEE :** Cet appareil est classé comme catégorie 9 parmi les « instruments de surveillance et de contrôle » en référence aux types d'équipements mentionnés dans l'Annexe I de la directive DEEE.



**Ne pas éliminer avec les autres déchets ménagers !**

Pour renvoyer les produits indésirables, contacter le site Web du fabricant mentionné sur le produit, ou son distributeur ou bureau de ventes local.

## Español

Este producto cumple la Directiva WEEE (2002/96/EC) sobre requisitos de las marcas. La etiqueta que lleva pegada indica que no debe desechar este producto eléctrico o electrónico con los residuos domésticos.

**Categoría del producto:** con referencia a los tipos de equipo del anexo I de la Directiva WEEE, este producto está clasificado como categoría 9 de "Instrumentación de supervisión y control".



**¡No lo deseche con los residuos domésticos!**

Para devolver productos que no desee, póngase en contacto con el sitio Web del fabricante mostrado en el producto, o con la oficina de ventas o distribuidor local.

## Deutsch

Dieses Produkt stimmt mit den Kennzeichnungsanforderungen der WEEE-Richtlinie (2002/96/EC) überein. Das angebrachte Etikett weist darauf hin, dass dieses elektrische/elektronische Produkt nicht in Hausmüll entsorgt werden darf.

**Produktkategorie:** In Bezug auf die Gerätetypen in Anhang I der WEEE-Richtlinie ist dieses Produkt als Kategorie 9 "Überwachungs- und Kontrollinstrument" klassifiziert.



### **Nicht in Hausmüll entsorgen!**

Zur Rückgabe von unerwünschten Produkten die auf dem Produkt angegebene Website des Herstellers oder die zuständige Verkaufsstelle bzw. den zuständigen Fachhändler konsultieren.

## Italiano

Questo prodotto risponde ai requisiti sull'etichettatura stabiliti nella Direttiva RAEE (2002/96/CE). Il simbolo apposto indica che non si deve gettare questo prodotto elettrico o elettronico in un contenitore per rifiuti domestici.

**Categoria del prodotto:** con riferimento ai tipi di apparecchiature elencate nell'Allegato 1 della Direttiva RAEE, questo prodotto rientra nella categoria 9 "Strumenti di monitoraggio e di controllo".



### **Non gettare in un contenitore per rifiuti domestici.**

Per restituire prodotti non desiderati, visitare il sito Web del produttore riportato sul prodotto o rivolgersi al distributore o all'ufficio vendite locale.

## Português

Este produto está em conformidade com as exigências de rotulagem da Directiva WEEE (2002/96/EC). O rótulo afixado indica que o utilizador não deve deitar este produto eléctrico/electrónico fora juntamente com o lixo doméstico.

**Categoria do produto:** No que se refere aos tipos de equipamento listados no Anexo I da Directiva WEEE, este produto está classificado como produto da categoria 9, "Instrumentação de monitorização e controlo".



### **Não deite fora juntamente com o lixo doméstico!**

Para devolver produtos indesejados, contacte o fabricante através do Website constante do produto ou contacte o seu representante de vendas ou distribuidor local.

## Nederlands

Dit product voldoet aan de merktekenvereisten van de AEEA-richtlijn (2002/96/EG). Het aangebrachte merkteken duidt erop dat dit elektrische/elektronische product niet met het huishoudelijk afval mag worden afgevoerd.

**Productcategorie:** Met betrekking tot de apparatuurcategorieën van bijlage I van de AEEA-richtlijn, valt dit product onder categorie 9 'meet- en controle-instrumenten'.



### **Niet afvoeren met huishoudelijk afval!**

Om ongewenste producten te retourneren, neemt u contact op met de website van de fabrikant die op het product staat vermeld, of met uw plaatselijke verkoopkantoor of distributeur.

## Svenska

Denna produkt uppfyller märkningskraven enligt WEEE Directive (2002/96/EC). Märkningsetiketten anger att du inte får kassera denna elektriska/elektroniska produkt tillsammans med vanliga hushållssopor.

**Produktkategori:** Med hänvisning till utrustningstyperna i WEEE Directive Annex I, är denna produkt klassad som kategori 9 "Monitoring and Control Instrumentation" (Instrument för övervakning och styrning).



### **Får ej kasseras tillsammans med vanliga hushållssopor!**

Returnera ej önskvärda produkter genom att gå till tillverkarens webbplats, vilken anges på produkten, eller till det lokala försäljningskontoret eller distributören.

## Norsk

Dette produktet oppfyller bestemmelsene ifølge WEEE-direktiv (2002/96/EC) med krav til merking. Påsatt merke viser at det ikke er tillatt å kassere dette elektriske/elektroniske produktet sammen med husholdningsavfall.

**Produktkategori:** På grunnlag av utstyrstypene i WEEE-direktivet, vedlegg I, er dette produktet klassifisert i kategori 9, "Instrumentering for overvåking og kontroll".



### **Må ikke kastes sammen med husholdningsavfall!**

Ved behov for returforsendelse av uønskede produkter må du gå til produsentens nettside som er angitt på produktet, eller du må kontakte det lokale salgskontoret eller den lokale forhandleren.

## **GENERAL INFORMATION**

### **1.1 INTRODUCTION**

The Model 3900 low humidity generating system is a facility capable of producing known humidity values using the combined fundamental principles of the "two temperature" and "two pressure" generators developed by NIST. This system is capable of continuously supplying accurately known humidity values for instrument calibration and evaluation. When used within the specified frost point range of -95.00 °C to 10.00 °C, the system will generate manually entered setpoints for days or even weeks unattended.

The 3900 operates using an embedded computer and control system to perform calculation and control functions. The Computer Control System utilizes a multifunction CPU in conjunction with other peripheral cards for control and is incorporated into the 3900 low humidity generator. Peripheral equipment, such as a printer or computer, may be connected using the bi-directional RS-232C interfaces.

Humidity and temperature setpoint values are input by the operator from the front panel keypad. The system is then automatically controlled at a setpoint, with visual indications of system status displayed in real time on the Liquid Crystal Display. The automatic features of this system allow the 3900 to generate humidity and temperature setpoints completely unattended, freeing the operating technician from the task of system monitoring and adjustment.

### **1.2 PRINCIPLE OF OPERATION**

#### **1.2.1 General Description**

The Model 3900 humidity generation system is based on the "two temperature - two pressure" principle. This process involves saturating air or some other gas, such as nitrogen, with water vapor at a given temperature and pressure. The saturated high pressure gas is then reduced to test pressure and warmed to test temperature. The indication of saturation temperature, saturation pressure, test temperature, and test pressure may be used in the determination of all hygrometric parameters. Humidity generation by this system does not depend upon measuring the amount of water vapor, but rather is dependent on the measurements of temperature and pressure alone. The precision of the system is determined by the accuracy of the temperature and pressure measurements, and on the constancy of them throughout.

#### **1.2.2 Humidity Formulas**

The humidity (or water vapor content) of a gas may be expressed in a variety of ways. The humidity parameters available with the 3900, and the formulas used to derive them, will be expressed in terms of the two-temperature two-pressure generator. While some basic understanding of humidity is helpful, thorough knowledge of the following formulas and their relationships to the 3900 is not a requirement for successful operation of the generator.

### 1.2.2.1 Saturation Vapor Pressure, e

Saturation Vapor Pressure (SVP) is the pressure exerted by water vapor alone when in equilibrium with pure ice or water, and is expressed as a function of temperature only. Since SVP can be established with respect to either ice or water, two separate formulas are used. Wexler's<sup>1</sup> formula for SVP over water is expressed as

$$e_w(T) = \exp \left\{ \left[ \sum_{i=0}^6 C_i (T + 273.15)^{i-2} \right] + D \ln(T + 273.15) \right\} \quad (1)$$

where  $C_0 = -2.9912729 \times 10^3$   
 $C_1 = -6.0170128 \times 10^3$   
 $C_2 = 1.887643854 \times 10^1$   
 $C_3 = -2.8354721 \times 10^{-2}$   
 $C_4 = 1.7838301 \times 10^{-5}$   
 $C_5 = -8.4150417 \times 10^{-10}$   
 $C_6 = 4.4412543 \times 10^{-13}$   
 $D = 2.858487$   
 $T =$  temperature of the gas in °C.

For SVP over ice, the equation of Hyland & Wexler<sup>2</sup> is expressed as

$$e_i(T) = \exp \left\{ \left[ \sum_{i=0}^5 C_i (T + 273.15)^{i-1} \right] + D \ln(T + 273.15) \right\} \quad (2)$$

where  $C_0 = -5.6745359 \times 10^3$   
 $C_1 = 6.3925247$   
 $C_2 = -9.6778430 \times 10^{-3}$   
 $C_3 = 6.2215701 \times 10^{-7}$   
 $C_4 = 2.0747825 \times 10^{-9}$   
 $C_5 = -9.4840240 \times 10^{-13}$   
 $D = 4.1635019$   
 $T =$  temperature of the gas in °C.

---

<sup>1</sup> Wexler, Arnold, Vapor Pressure Formulation for Water in Range 0 to 100 °C. A Revision., Journal of Research of the National Bureau of Standards - A. Physics and Chemistry, Vol. 80A, Nos. 5 and 6, September-December 1976, pp. 775-785, Equation 15.

<sup>2</sup> Hyland, Richard, and Wexler, Arnold, Formulations of the Thermodynamic Properties of the Saturated Phases of H<sub>2</sub>O from 173.15 K to 473.15 K, ASHRAE Transactions 1983, Part 2A, pp. 500-513, Equation 18

### 1.2.2.2 Enhancement Factor, $f$

The enhancement factor,  $f$ , corrects for the non-ideal behavior of air when it is used as the carrier gas. The enhancement factor is a function of two independent variables; pressure,  $P$ , and temperature,  $T$ . A formula for calculation of the enhancement factor at any given pressure and temperature above freezing is given by Greenspan<sup>1</sup> as

$$f_w(T,P) = \exp \left[ \alpha \left( 1 - \frac{e_w(T)}{P} \right) + \beta \left( \frac{P}{e_w(T)} - 1 \right) \right] \quad (3)$$

where  $P$  = the absolute pressure in Pascals, and  
 $e_w(T)$  = the saturation vapor pressure (in Pascals) at temperature,  $T$ .

The two remaining variables,  $\alpha$  and  $\beta$ , are given as

$$\alpha = \sum_{i=0}^3 A_i T^i$$

$$\beta = \exp \sum_{i=0}^3 B_i T^i$$

where  $A_0 = 3.53624 \times 10^{-4}$   
 $A_1 = 2.93228 \times 10^{-5}$   
 $A_2 = 2.61474 \times 10^{-7}$   
 $A_3 = 8.57538 \times 10^{-9}$   
 $B_0 = -1.07588 \times 10^1$   
 $B_1 = 6.32529 \times 10^{-2}$   
 $B_2 = -2.53591 \times 10^{-4}$   
 $B_3 = 6.33784 \times 10^{-7}$ , and  
 $T$  = temperature of the gas in °C.

This formula for the enhancement factor is valid over the pressure range of the 3900 and over the temperature range of 0 to 100 °C.

When calculating enhancement factors with respect to ice for temperatures from -100 to 0 °C, the formula becomes

$$f_i(T,P) = \exp \left[ \alpha \left( 1 - \frac{e_i(T)}{P} \right) + \beta \left( \frac{P}{e_i(T)} - 1 \right) \right] \quad (4)$$

where  $P$  = the absolute pressure in Pascals, and  
 $e_i(T)$  = the saturation vapor pressure (in Pascals) at temperature,  $T$ .

---

<sup>1</sup> Greenspan, Lewis, Functional Equations for the Enhancement Factors of CO<sub>2</sub>-Free Moist Air, Journal of Research of the National Bureau of Standards - A. Physics and Chemistry, Vol. 80A, No.1, January-February 1976, pp. 41-44

Again the variables,  $\alpha$  and  $\beta$ , are given as

$$\alpha = \sum_{i=0}^3 A_i T^i$$

$$\text{and } \beta = \exp \sum_{i=0}^3 B_i T^i$$

where

$$A_0 = 3.6449 \times 10^{-4}$$

$$A_1 = 2.93631 \times 10^{-5}$$

$$A_2 = 4.88635 \times 10^{-7}$$

$$A_3 = 4.36543 \times 10^{-9}$$

$$B_0 = -1.07271 \times 10^1$$

$$B_1 = 7.61989 \times 10^{-2}$$

$$B_2 = -1.74771 \times 10^{-4}$$

$$B_3 = 2.46721 \times 10^{-6}, \text{ and}$$

$$T = \text{temperature of the gas in } ^\circ\text{C}.$$

### 1.2.2.3 Frost Point

Frost point temperature,  $T_f$ , is the temperature to which a gas must be cooled in order to just begin condensing water vapor in the form of ice or frost. For this reason, frost point is not applicable above freezing. In relation to the two-temperature two-pressure generator, frost point vapor pressure is derived from the formula

$$e_i(T_f) = \frac{f(T_s, P_s) * e(T_s) * P_c}{f(T_f, P_t) * P_s} \quad (5)$$

where

$$f(T_s, P_s) = \text{the enhancement factor at saturation temperature, } T_s, \text{ and saturation pressure, } P_s$$

$$f(T_f, P_t) = \text{the enhancement factor at the frost point temperature, } T_f, \text{ and test pressure, } P_t. \text{ (Since frost point is not known, this equation is solved by iteration.)}$$

$$e(T_s) = \text{the SVP (} e_i \text{ or } e_w \text{) at saturation temperature, } T_s$$

$$P_t = \text{the absolute test pressure, } P_t$$

$$P_s = \text{the absolute saturation pressure, } P_s.$$

Then frost point temperature relative to that vapor pressure is solved for as the inverse of the SVP formula (see equation 2 section 1.2.2.1)

$$T_f = \text{In} e_i(T_f) \quad (6)$$

where  $e_i(T_f) =$  SVP over ice at the frost point temperature,  $T_f$ , obtained from equation 5.

The 3900 generates a particular frost point by first selecting a suitable saturation temperature,  $T_s$ , then determining the saturation pressure,  $P_s$ , required to establish the correct frost point vapor pressure (and ultimately the correct frost point temperature) at any given test pressure,  $P_t$ . Frost point is independent of test temperature.

### 1.2.2.4 Dew Point

Dew point temperature,  $T_d$ , is the temperature to which a gas must be cooled in order to just begin condensing water vapor in the form of dew. Unlike frost point, dew point can exist both above and below freezing. In relation to the two-temperature two-pressure generator, dew point vapor pressure is derived from the formula

$$e_w(T_d) = \frac{f(T_s, P_s) * e(T_s) * P_t}{f(T_d, P_t) * P_s} \quad (7)$$

where  $f(T_s, P_s)$  = the enhancement factor at saturation temperature,  $T_s$ , and saturation pressure,  $P_s$

$f(T_d, P_t)$  = the enhancement factor at the dew point temperature,  $T_d$ , and test pressure,  $P_t$ . (Since dew point is not known, this equation is solved by iteration.)

$e(T_s)$  = the SVP ( $e_i$  or  $e_w$ ) at saturation temperature,  $T_s$

$P_t$  = the absolute test pressure,  $P_t$

$P_s$  = the absolute saturation pressure,  $P_s$ .

Then dew point temperature relative to that vapor pressure is solved for as the inverse of the SVP formula (see equation 1 section 1.2.2.1)

$$T_d = t_{e_w}(T_d) \quad (8)$$

where  $e_w(T_d)$  = SVP over water at the dew point temperature,  $T_d$ , obtained from equation 7.

The 3900 generates a particular dew point by first selecting a suitable saturation temperature,  $T_s$ , then determining the saturation pressure,  $P_s$ , required to establish the correct dew point vapor pressure (and ultimately the correct dew point temperature) at any given test pressure,  $P_t$ . Dew point is independent of test temperature.

### 1.2.2.5 Parts Per Million by Volume, $PPM_V$

$PPM_V$  is a relationship between the number of molecules of water vapor to the number of molecules of the dry carrier gas. In the two-temperature two-pressure generator, it is expressed by the relationship

$$PPM_V = \frac{f(T_s, P_s) * e(T_s)}{P_s - f(T_s, P_s) * e(T_s)} * 10^6 \quad (9)$$

where  $f(T_s, P_s)$  = the enhancement factor at saturation temperature,  $T_s$ , and saturation pressure,  $P_s$

$e(T_s)$  = the SVP ( $e_i$  or  $e_w$ ) at saturation temperature,  $T_s$

$P_s$  = the absolute saturation pressure,  $P_s$ .

The 3900 generates a particular  $PPM_V$  by first selecting an appropriate saturation temperature,  $T_s$ , then determining the required saturation pressure,  $P_s$ .  $PPM_V$  is independent of test pressure and test temperature.

### 1.2.2.6 Parts Per Million by Weight, PPM<sub>w</sub>

$PPM_w$  is a relationship between the weight of the molecules of water vapor to those of the dry gas carrier.  $PPM_w$  is related to  $PPM_v$  by the relationship

$$PPM_w = \frac{MW_w}{MW_a} * PPM_v \quad (10)$$

where  $MW_w$  = molecular weight of water ( $\approx 18.02$  g/mol)  
 $MW_a$  = molecular weight of air ( $\approx 28.97$  g/mol)  
 $PPM_v$  = Parts Per Million by Volume from equation 9.

Therefore  $PPM_w \approx 0.622 PPM_v$ . With the exception of the 0.622 scaling factor,  $PPM_w$  is generated in a manner identical to that of  $PPM_v$ .  $PPM_w$  is also independent of test temperature and test pressure. As shipped from the factory the default molecular weight of the carrier gas is set at 28.9645 g/mol, appropriate for a carrier gas of air. To change the molecular weight, consult the factory.

### 1.2.2.7 Relative Humidity, %RH

Relative Humidity, %RH, is a percentage ratio of the amount of water vapor in a given gas mixture to the maximum amount physically allowable in the gas at the same temperature and same pressure. As it relates to the two-temperature two-pressure generator, %RH is expressed as

$$\%RH = \frac{f(T_s, P_s) * e(T_s) P_t}{f(T_t, P_t) * e(T_t) P_s} * 100 \quad (11)$$

where  $f(T_s, P_s)$  = the enhancement factor at saturation temperature,  $T_s$ , and saturation pressure,  $P_s$   
 $f(T_t, P_t)$  = the enhancement factor at test temperature,  $T_t$ , and test pressure,  $P_t$   
 $e(T_s)$  = the SVP ( $e_i$  or  $e_w$ ) at saturation temperature,  $T_s$   
 $e(T_t)$  = the SVP ( $e_i$  or  $e_w$ ) at test temperature,  $T_t$   
 $P_t$  = the absolute test pressure,  $P_t$   
 $P_s$  = the absolute saturation pressure,  $P_s$

The 3900 generates a particular Relative Humidity by first selecting a suitable saturation temperature,  $T_s$ , then determining the saturation pressure,  $P_s$ , required to establish the correct %RH at test temperature,  $T_t$ , and test pressure,  $P_t$ . Relative Humidity is dependent on both test temperature and test pressure.

The 3900 can display and generate %RH in either of two different methods. In the *Normal* mode of RH calculation, saturation vapor pressure at the test temperature,  $e(T_t)$ , is computed with respect to water (equation 1) for test temperatures above 0 °C, and with respect to ice (equation 2) for test temperatures below 0 °C. However, when configured for the *WMO* mode of RH calculation (in accordance with the guidelines of the World Meteorological Organization), the saturation vapor pressure at the test temperature,  $e(T_t)$ , is always computed with respect to water (equation 1) for all test temperatures, even those below 0 °C. Note that the two methods are identical when the test temperature is above 0 °C, and only differ from each other when the test temperature is below 0 °C. The method of RH calculation used by the 3900 is user selectable. See section 3.3.

### 13 SPECIFICATIONS

Frost / Dew Point Range:	-----	-95 to +10 °C
Frost / Dew Point Uncertainty: *	-----	(-95 to -90 °C) 0.9 °C
	-----	(-90 to -80 °C) 0.5 °C
	-----	(-80 to -70 °C) 0.2 °C
	-----	(-70 to 10 °C) 0.1 °C
Parts Per Million Range:	-----	0.05 to 12000 PPMv
Relative Humidity Range:	-----	0.0002 to ~50%
Saturation Pressure Range:	-----	Ambient to 300 psiA
Saturation Pressure Uncertainty (10 - 50 psiA): *	-----	0.05 psiA
Saturation Pressure Uncertainty (50 - 300 psiA): *	-----	0.30 psiA
Saturation Temp Range:	-----	-80 to +12 °C
Saturation Temp Uncertainty: *	-----	0.08 °C
Saturation Heating Rate:	-----	2 minutes per °C Avg
Saturation Cooling Rate:	-----	2 minutes per °C Avg
Test Pressure Range:	-----	Ambient to 50 psiA
Test Pressure Uncertainty (10 - 50 psiA): *	-----	0.05 psiA
Test Pressure Range (Option):	-----	Ambient to 150 psiA
Test Pressure Uncertainty (10 - 150 psiA) (Option):	-----	0.05 psiA
Test Temp Range:	-----	0 to 50 °C
Test Temp Uncertainty: *	-----	0.08 °C
Display Resolution:	-----	0.01
Gas Flow Rate Range:	-----	0.1 to 5 L/min
Gas Flow Rate Range (Option): **	-----	0.5 to 10 L/min
Gas Flow Rate Resolution:	-----	0.02 L/min
Gas Flow Rate Uncertainty: *	-----	0.2 L/min
Gas Type:	-----	Air or Nitrogen
Gas Pressure Rating (MAWP):	-----	350 psiG
Refrigeration:	-----	1/3 HP R-134A & 1/3 HP R-23 in cascade
Heating:	-----	Stainless Steel Immersion Heaters
Test Port:	-----	1/4 Inch Swagelok® Tube Fitting (6.35mm)
Physical Dimensions:	-----	37.5" H x 23" W x 30" D (953mm x 584mm x 762mm)

\* Represents an expanded uncertainty using a coverage factor, k=2, at an approximate level of confidence of 95%.

#### 13.1 Facility Requirements

Electrical Power:	-----	200/240VAC @ 50/60 Hz, 10A
Gas Supply (External):	--	350 psiG @ 0.17 cfm (5 L/min) w/ambient pressure FP <-80 °C
Floor Space:	-----	9 Ft <sup>2</sup> (0.84 m <sup>2</sup> )

\*\* Gas Supply (Option): 350 psiG @ 0.35 cfm (10 L/min) w/ambient pressure FP <-80 °C

#### 13.2 Environmental

Operating Temperature:	-----	15 °C to 30 °C
Storage Temperature:	-----	0 °C to 50 °C
Humidity:	-----	5 to 95% Non-condensing

## **1.4 COMPUTER / CONTROL SYSTEM**

### **1.4.1 General Description**

The Computer Control System is embedded in the humidity generator. The computer controls all aspects of the humidity generation process (i.e. controlling temperatures, pressures, etc.) as well as performing all human interface functions of keypad input and information display. The computer also controls printer operation and interfaces with an external computer (optional) for bi-directional RS-232C communications.

The Computer Control System is considered a "single-point automation" unit, controlling the functions of the humidity generator to bring it to any operator input setpoint. The computer will always control the system at the most current setpoint that has been input, whether from keypad input, or from external computer input through the RS-232C port. The Computer Control System knows nothing of past or future setpoints, requiring the use of an external computer if automated humidity profiling or sequencing is desired.

### **1.4.2 Computer / Control System Configuration**

Reference Drawings 95D39903, 95D39904 & 905

The Computer Control System consists of the following key components:

- 1) Embedded Computer system, consisting of:
  - a) CPU card
  - b) 8 channel, 16 bit A/D converter card with signal conditioning
  - c) Memory Card
  - d) Liquid Crystal Display driver card
  - e) Solid State Relay Board
- 2) 256 x 128, backlit, dot matrix Liquid Crystal Display (LCD) module
- 3) 16 key front panel keypad

#### **1.4.2.1 Central Processing Unit (CPU)**

Reference Drawing 95D39903

The Central Processing Unit (CPU) consists of a microprocessor, along with all supporting hardware required to interface with the other devices. During the humidity generation process, the CPU executes programming designed to control the parameters needed to generate humidity, such as pulsing heaters and operating valves. Virtually all functions of the system are controlled by this CPU which is responsible for system timing, user interfacing, information display, and parameter control.

The CPU also retrieves measured temperature and pressure data from the A/D, which it uses to calculate frost point, dew point, parts per million by volume, parts per million by weight and relative humidity. Once calculated, this and all other pertinent information is sent to the Liquid Crystal Display for real time numeric display. At given (user definable) intervals, the CPU also sends this data to the printer, if enabled, for hard copy output.

## **1.4.2.2 Liquid Crystal Display (LCD)**

Reference Drawing 95S39913

The display incorporated into the 3900 low humidity generator is a backlit, 256 x 128, dot matrix Liquid Crystal Display (LCD). It is used for the purpose of displaying system information such as setpoints, measurements and any other information pertinent to the operation of the 3900 humidity generator.

## **1.4.2.3 Liquid Crystal Display Driver**

Reference Drawings 95D39904, 95S39913

The Liquid Crystal Display Driver card receives display commands and data from the Central Processing Unit then converts these into the signals required to drive the Liquid Crystal Display module. It also incorporates a voltage inversion circuit, which converts +5 VDC input to a -21 VDC output required by the LCD module.

## **1.4.2.4 Keypad**

Reference Drawings 95D39903, 95D39904

The 4 x 4 keypad is the human interface to the 3900 generator. From this keypad, the operator will select modes of operation from the menus, enter humidity and temperature setpoints for humidity generation, and perform any other interface functions where user input is required. During operation, most of the screens will show four rectangular shaped blocks at the right side of the display. These blocks correspond with the four blank keys on the left side of the keypad, which will be used to perform certain functions within the program.

## **1.4.2.5 Memory Card**

Reference Drawings 95D39903, 95D39904

The Memory Card contains EPROM and battery backed RAM. This memory contains all program code and data required for operation of the generator. All programs are stored in EPROM, while all factory and user editable parameters (such as Calibration Coefficients) are stored in battery backed RAM.

## **1.4.2.6 Analog to Digital Converter (A/D)**

Reference Drawings 95D39903, 95D39904

The Analog to Digital Converter card is a 16 bit analog to digital converter, with integral signal conditioning. It is used to continuously measure thermistor resistances and pressure transducer / flow meter voltages. Data obtained from the A/D board is sent to the CPU where it is used in the control process. The A/D converter has a usable voltage range of 0 to +5 VDC.

## **15 ELECTRICAL SYSTEM**

### **15.1 AC Power Distribution**

Reference Drawings 95D39904, 95S39906 through 95S39909

The 3900 requires a single phase AC power source. From the primary power switch CBS1, primary power is distributed to the refrigeration compressors, C1 and C2, through SSR8 and SSR9, the saturator fluid heater H1 through SSR10; the fluid pump FP1 through SSR6; the console fan CF1 through SSR7; and the DC power supplies PS1 and PS2.

### **15.2 Power Supply $\pm 15$ , +5 VDC**

Reference Drawings 95D39904, 95S39907 through 95S39913

The  $\pm 15$  VDC portion of power supply PS1 provides power to the flow meter, the pressure transducers, the A/D card, and the LCD backlight inverter board. The mass flow transducer and the A/D card use  $\pm 15$  VDC for their particular voltage requirements, while the pressure transducers require +15 VDC and the LCD backlight inverter board requires -15 VDC.

The +5 VDC portion of power supply PS1 provides power to the computer system, the solid state relay board and the terminal interface board.

### **15.3 Power Supply +24 VDC**

Reference Drawings 95D39904, 95S39907 & 908, 95S39910 & 911

The +24 VDC power supply PS2 provides power for all solenoid valves as well as the stepper motor drives SMD-1 and SMD-2.

## **1.54 Analog Inputs**

The temperature, flow and pressure transducers are measured by the Analog to Digital Converter. Each of these is discussed further in the following sections.

### **1.5.4.1 Temperature Measurement**

Reference Drawing 95S39912, 95S39915 & 916

Two thermistors are used by the system for continuous real time temperature monitoring.

A 1K $\Omega$  thermistor probe, RTD1, is connected to channel 1 of the Analog Terminal Board, ATB. It is used to measure and control the actual saturation temperature.

A 10K $\Omega$  thermistor probe, RTD2, is connected to channel 2 of the ATB. It is used to measure the test temperature, which is utilized for calculation and control of various humidity parameters, such as %RH. The computer senses that the probe is connected by monitoring terminal A2 of TIB.

When the Test Temperature probe is connected, a logic low is transferred from pin 1 to pin 2 of the probe connector, CN2, then to terminal A2 of TIB. When disconnected, terminal A2 is internally pulled high.

The thermistor temperatures are measured by the Analog to Digital Converter card (A/D) with a resolution of approximately 0.01  $^{\circ}$ C/bit. Since the temperatures measured by the A/D card are based on ideal R-T curves, further calibration to actual temperature values is performed by the CPU prior to use or display (refer to 4.2.2 for calibration).

A reference resistor of approximately 10K $\Omega$  is connected to channel 3 of the ATB, and is used to compensate for short and long term drift of the temperature measurement electronics in the A/D circuitry. Deviations from the reference resistor's nominal value are used to mathematically offset the measured values of the two thermistor probes.

### **1.5.4.2 Test Pressure Transducer**

Reference Drawings 95S39912, 95S39915 & 916

The Test Pressure Transducer TR5 is powered by +15 VDC from the  $\pm$ 15 VDC power supply PS1. The output, 0-5 VDC for 0 to full scale (typically 50 psiA), is connected to channel 7 of the ATB for measurement by the A/D card. When connected this transducer continually monitors the test or barometric pressure. The computer senses that the probe is connected by monitoring terminal A3 of TIB. When the probe is connected, a logic low is transferred from pin 1 to pin 2 of the probe connector, CN3, then to terminal A3 of TIB. When disconnected, terminal A3 is internally pulled high.

### **1.5.4.3 Low Range Saturation Pressure Transducer**

Reference Drawings 95S39912, 95S39915 & 916

The Low Range Saturation Pressure Transducer TR3 is powered by the  $\pm 15$  VDC power supply PS1, and has a measurement range of 0 to 50 psiA. This pressure transducer is pneumatically connected to the saturator via a computer controlled solenoid valve SOL4 that is only activated below 50 psiA to monitor saturation pressure. The output voltage, 0-5 VDC for 0 to 50 psiA, is connected to channel 5 of the ATB for measurement by the A/D card.

### **1.5.4.4 High Range Saturation Pressure Transducer**

Reference Drawings 95S39912, 95S39915 & 916

The High Range Saturation Pressure Transducer TR4 is powered by the  $\pm 15$  VDC power supply PS1, and has a measurement range of 0 to 300 psiA. This transducer is generally used to measure saturation pressures above 50 psiA. Operation is identical to that of the test pressure transducer described in section 1.5.4.3. The output voltage, 0-5 VDC for 0 to full scale, is connected to channel 6 of the ATB for measurement by the A/D card.

### **1.5.4.5 Gas Supply Pressure Transducer**

Reference Drawings 95S39912, 95S39915 & 916

The Gas Supply Transducer TR1 is powered by +15 VDC from the  $\pm 15$  VDC power supply PS1. The output is connected to channel 4 of the ATB for measurement by the A/D card. This transducer monitors the regulated gas supply pressure.

### **1.5.4.6 Mass Flow Meter**

Reference Drawings 95S39912, 95S39915 & 916

The mass flow meter TR2 is a thermal type transducer and is powered by the  $\pm 15$  VDC power supply PS1. The output of the transducer is 0-1 VDC for a mass flow rate of 0-2 L/min. The output voltage is connected to channel 0 of the ATB for measurement by the A/D card.

## **1.5.5 Control Logic**

All control is performed digitally at a logic level of 5 VDC. Activation of most devices is accomplished by applying a logic low to the control input of the associated solid state relay or other coupling device.

### **1.5.5.1 Gas Supply Solenoid Valve**

Reference Drawings 95S39908, 95S39915 & 916

The Gas Supply Solenoid Valve SOL1 is activated (gas on) by applying a low from the CPU (monitored at TIB terminal C5) to the optical input (-) side of SSR5 on the Solid State Relay Board. Valve actuation voltage is 24 VDC.

### **1.5.5.2 Fluid Pump Purge Solenoid Valve**

Reference Drawings 95S39908, 95S39915 & 916

The Fluid Pump Purge Solenoid Valve SOL2, when activated, allows a dry gas supply to be vented into the pump motor housing area in an effort to keep this area free of ice build up when operating at very cold temperatures. The valve is activated by applying a low from the CPU (monitored at TIB terminal C4) to the optical input (-) side of SSR4 on the Solid State Relay Board. Valve actuation voltage is 24 VDC. Adjust needle valve V5 to 1.0 liter per minute if regulated pressure is changed.

### **1.5.5.3 Saturator Vent / Purge Solenoid Valve**

Reference Drawings 95S39908, 95S39915 & 916

The Saturator Vent / Purge Solenoid Valve SOL3, when activated, allows the saturator pressure to vent to ambient. This valve is activated when performing shutdown, clear and purge procedures. The valve is activated by applying a low from the CPU (monitored at TIB terminal C3) to the optical input (-) side of SSR3 on the Solid State Relay Board. Valve actuation voltage is 24 VDC.

### **1.5.5.4 Pressure Select Solenoid Valve**

Reference Drawings 95S39908, 95S39915 & 916

The Pressure Select Solenoid Valve SOL4, when activated, allows the generator to monitor the saturator using the 50 psiA pressure transducer when the saturator is operating in the ambient to 50 psiA range. The valve is activated by applying a low from the CPU (monitored at TIB terminal C2) to the optical input (-) side of SSR2 on the Solid State Relay Board. Valve actuation voltage is 24 VDC.

### **1.5.5.5 Saturator Refrigerant Solenoid Valve**

Reference Drawings 95S39908, 95S39917

The Saturator Refrigerant Solenoid Valve SOL5, when activated, allows refrigerant to be injected into the refrigeration evaporator EX1 to cool and control the temperature of the saturator. Activation of this solenoid valve is accomplished by applying a low from the CPU (monitored at TIB terminal C0) to the optical input (-) side of SSR0 on the Solid State Relay Board. Saturation temperature is controlled through fixed frequency pulse width modulation of SOL5. Valve actuation voltage is 24 VDC.

### **1.5.5.6 Saturator Inlet/Outlet Heater**

Reference Drawing 95S39908

The Saturator Inlet/Outlet Heater H2 is a resistive heating element which keeps the inlet and outlet tubing of the saturator slightly warmer than the saturator itself in order to limit condensation in this area. Activation of this heater is accomplished by applying a low from the CPU (monitored at TIB terminal C5) to the optical input (-) side of SSR5 on the Solid State Relay Board. Heater drive voltage is 24 VDC.

### **1.5.5.7 Saturator Fluid Heater**

Reference Drawings 95S39909, 95S39917

The Saturator Fluid Heater H1 is a resistive heating element, activated by a two-stage control process. Heat limit switch HLS1 must be in the normally closed position, indicating that saturator fluid temperature is within allowable limits (i.e. below 30 °C). Activation is then accomplished by applying a low from TIB channel B5 to the optical input (-) side of SSR10. Saturator heater temperature is controlled through fixed frequency pulse width modulation of the heater power at the AC line voltage.

### **1.5.5.8 Saturator Fluid Circulation Pump**

Reference Drawings 95S39908, 95S39917

The Saturator Fluid Circulation Pump FP1 is a centrifugal pump energized by applying a low from the CPU (monitored at TIB terminal C6) to the optical input (-) side of SSR6 on the Solid State Relay Board. The pump is powered at AC line voltage.

### **1.5.5.9 Saturator Refrigeration Compressors**

Reference Drawings 95S39909, 95S39917

The R-134A Compressor, C1, is energized by applying a low from the CPU (monitored at TIB terminal C6) to the optical input (-) side of SSR8. The R-23 Compressor, C2, is energized by applying a low from the CPU (monitored at TIB terminal B6) to the optical input (-) side of SSR9. Compressor C2 is not activated by the computer until compressor C1 has been on for several minutes. Both compressors are powered at AC line voltage.

### **1.5.5.10 Flow Control Valve**

Reference Drawing 95S39910, 95S39915 & 916

The Flow Control Valve V1 is a bi-directional ball valve actuated by a gear reduced stepper motor. The valve is driven indirectly via pulses from the CPU to TIB terminals B0 & B2, which triggers stepper motor driver SMD-1. Pulses on channel B0 turn the valve clockwise, while pulses on channel B2 turn the valve counter clockwise. The stepper motor driver is powered from the 24 VDC power supply. Controlled by the CPU using feedback from the mass flow sensor, the computer operated flow control valve allows the mass flow rate to be controlled by varying the orifice of the flow control valve from nearly closed to fully open depending upon the required mass flow rate. This valve also determines the direction of flow for purge and generate modes. When in generate mode, flow control is accomplished in the proper direction using one of the orifices. When in purge mode the other orifice is used causing the gas to flow in a different direction. The central point between the two orifices is the HOME or CENTER CLOSED position of the valve. The HOME position is sensed by a low at TIB channel A0 resulting from the contact closure of limit switch SL1.

### **1.5.5.11 Expansion Valve**

Reference Drawings 95S39911, 95S39915 & 916

The Expansion Valve V2, or saturation pressure control valve, is a bi-directional ball valve actuated by a gear reduced stepper motor. The valve is driven indirectly via pulses from the CPU to TIB terminals B1 & B3, which triggers stepper motor driver SMD-2. Pulses on channel B1 turn the valve clockwise, while pulses on channel B3 turn the valve counter clockwise. The stepper motor driver is powered from the 24 VDC power supply. Controlled by the CPU using feedback from the saturator pressure transducers, the computer controlled expansion valve allows the saturated high pressure air stream to be reduced to test pressure by varying the orifice of the expansion valve from nearly closed to fully open depending upon the required saturation pressure. This valve also determines the direction of flow for purge and generate modes. When in generate mode, flow control is accomplished in the proper direction using one of the orifices. When in purge mode the other orifice is used causing the gas to flow in a different direction. The central point between the two orifices is the HOME or CENTER CLOSED position of the valve. The HOME position is sensed by a low at TIB channel A1 resulting from the contact closure of limit switch SL2.

### **1.5.5.12 Expansion Valve Heater**

Reference Drawing 95S39908

The Expansion Valve Heater H3 is a series of heating elements which keep the outlet tubing of the saturator warm in order to limit condensation at the expansion valve. Activation of these heaters is accomplished by applying a low signal from the CPU (monitored at TIB terminal C1) to the optical input (-) side of SSR1 on the Solid State Relay Board. Heater drive voltage is 24 VDC.

## 1.6 PNEUMATIC SYSTEM

The pneumatic system of the Model 3900 is an open loop "two pressure" system. Dry, high pressure, high purity gas is saturated with water vapor as it passes through the saturator assembly, then reduced to test pressure. Once reduced to the test pressure the gas is sent to the device under test and ultimately vented to the atmosphere.

Dry high purity gas, regulated at up to 350 psiG, is connected to the gas supply inlet. The gas is filtered by a 7 micron filter LF1, then admitted through the supply pressure regulator REG to the ON/OFF solenoid valve SOL1. This regulator is factory preset to 300 psiG. Regulated pressure is measured by the supply pressure transducer TR1.

After pressure regulation, the gas flows from the mass flow transducer TR2 to the flow control valve V1. The gas is admitted through valve V1 in one of two modes:

A) Generate Mode: (reference drawing 95S39915)

The gas flows from flow control valve V1 through the saturator and is saturated with water vapor as the gas establishes thermal equilibrium with the saturator fluid. The saturation pressure,  $P_s$  (TR3 or TR4), and saturation temperature,  $T_s$  (RTD1), of the gas are then measured. Upon exiting the saturator, the saturated gas encounters the expansion valve V2 and the saturation pressure is reduced to test pressure. The gas stream enters the device under test from the fitting located on counter top, at the desired humidity, given test pressure,  $P_t$ , and test temperature,  $T_t$ , conditions. The gas exits the device under test and is then vented to the atmosphere.

B) Purge Mode: (reference drawing 95S39916)

By reversing the normal path the gas follows in the generate mode, it is possible to purge the system of any unwanted moisture. The gas flows from flow control valve V1 through valve V2 to the saturator. The gas passes from the saturator to the vent / purge solenoid valve SOL3 and out the saturator vent outlet.

## 1.7 FLUID SYSTEMS

### 1.7.1 Saturator Fluid System

Reference Drawing 95S39917

Temperature conditioning of the saturator employs a methanol fluid circulation system in conjunction with a cascade refrigeration system. Methanol is circulated by a magnetically coupled centrifugal pump FP1 at approximately two gallons per minute. The methanol is piped from the circulation pump to the immersion heater H1, through the R-23 refrigerant evaporator EX1 to the saturator fluid jacket. From the saturator fluid jacket the methanol is piped back to the circulation pump completing the saturator fluid circuit. RT1 is a methanol expansion tank.

## **1.8 REFRIGERATION**

The Model 3900 utilizes a cascade refrigeration system to cool the fluid circulating in the saturator assembly.

### **1.8.1 Saturator Refrigeration**

Reference Drawing 95S39917

The saturator fluid system is cooled by two hermetic refrigeration systems in cascade. The high stage refrigeration utilizes Refrigerant 134A. This refrigerant is compressed from a low-pressure vapor into a high-pressure vapor by compressor C1. The high-pressure vapor flows to the air-cooled condenser CON1 where it is cooled to a high-pressure liquid as heat is removed. The condensed refrigerant passes through the filter-drier FD1 to the thermostatic expansion valve V3. Refrigerant is metered into the interstage cooler CON2, heat is removed, and the heat laden vapor is piped back to the compressor and the cycle is repeated.

The low stage refrigeration system utilizes Refrigerant 23, which has a boiling point of -81.4 °C. The refrigerant is compressed from a low-pressure vapor to a high-pressure vapor by compressor C2. The high-pressure vapor flows through the oil separator OS1 to the interstage cooler CON2 where heat is removed as it is cooled to a high-pressure liquid. Upon demand, refrigerant is admitted through solenoid valve SOL5 to the capillary tube where it is metered into the saturator fluid heat exchanger/R-23 evaporator EX1. The refrigerant expands and changes to a low-pressure vapor as it absorbs heat from the saturator fluid circuit. The vapor is then piped back to the suction side of the compressor and the cycle is repeated.

## Section 2

# INSTALLATION

### 2.1 GENERAL

Preparations should be made to have adequate floor space, proper power source, and a dry gas supply available at the location of installation.

### 2.2 FACILITIES REQUIRED

Reference Drawing 94D39901

#### 2.2.1 Floor Space

A minimum 9 ft<sup>2</sup> (0.84 m<sup>2</sup>) of floor space is recommended for the 3900. This allows 6 inches (0.15 m) of access to side and rear console panels.

#### 2.2.2 Power

The 3900 humidity generator requires a single phase AC power source as indicated on the identification label on the rear of the unit.

#### 2.2.3 Gas Supply

The 3900 requires a gas supply that is clean, dry and oil free. Zero nitrogen or air regulated to a pressure between 325 and 350 psiG ( $\approx$  22 to 24 bar gauge), with a flow rate capability of 5 standard liters/minute, and an ambient pressure frost point of -80 °C or lower is recommended.

### 2.3 PREPARATION

Reference Drawing 95D39902

Temperature conditioning of the 3900's saturator employs a fluid circulation system in conjunction with a cascade refrigeration system. Methyl alcohol (methanol) is used as the heat transfer medium in this fluid circulation system because of its low freezing point (-93 °C). The methanol has been drained prior to shipment and must be replaced prior to power-up and operation. Extreme caution is required in the filling due to the flammability of methanol.

## 23.1 Methanol Filling Procedure

Reference Drawing 08D39922

Equipment Required:

1. 1.5 gallons (5.675 Liters) of anhydrous methanol
2. 7/8" (23 mm) socket with 6" (0.15 m) extension
3. 3/16" (4.5 mm) ball/hex driver (to remove counter top bolts)
4. 3/8" (9.5 mm) ball/hex driver (to remove Methanol Expansion Tank Fill Port Plug)
5. Funnel
6. Gloves and goggles

**CAUTION!**  
**METHANOL IS FLAMMABLE AND POISONOUS**

*Keep away from sparks, flames, or other ignition sources. Avoid prolonged or repeated breathing of vapors or contact with skin. Do not allow material to contaminate water sources.*

To fill saturator fluid system, proceed as follows:

- 1) Ensure power source is **not** connected.
- 2) Remove left and right side console panels.
- 3) Using 3/16" ball/hex driver, remove 4 securing bolts near corners, and remove counter top.
- 4) Locate and remove RTD access insulation. Using the 7/8" socket with 6" extension, remove the Saturator Methanol Fill Port Cap from the top of the saturator.
- 5) Remove circular insulation and the Methanol Expansion Tank Fill Port Plug.
- 6) Insert the funnel into the Methanol Expansion Tank Fill Port. **Slowly and carefully** fill the saturator assembly until methanol is observed just below the Saturator Methanol Port Fitting located on top of the saturator (in the square insulation area).

***Note** - The methanol must be added slowly as it is being gravity fed through 3/8" tubing between the methanol expansion tank and the saturator. Do not allow funnel to fill.*

*Methanol degrades the urethane foam insulation; sponge dry any methanol spilled during the filling operation!*

- 7) Replace the saturator methanol port cap (tighten 1/4 turn past finger tight).
- 8) Replace methanol expansion tank fill port plug.
- 9) Replace all insulation.
- 10) Replace counter top and console panels.

### **2.3.2 Vent Muffler**

Install vent muffler into gas vent port at rear of system.

## **2.4 POSITIONING & LEVELING**

- 1) Position the system so as to have access to all sides of the console.
- 2) Lower leveling legs and raise the wheels off the floor to hold system stationary. Level the console using counter top as a reference. Tighten leveling leg locking nuts against frame.

## **2.5 FACILITY CONNECTIONS**

Reference Drawing 94D39901

### **2.5.1 Gas Supply**

- 1) Connect a source of clean, oil free, gas to "GAS INLET" with a line size equal to or larger than the 1/4" OD tubing on console. The gas supply should be regulated to a pressure between 325 and 350 psiG (Maximum Allowable Working Pressure is 350 psiG).

### **2.5.2 Pressure Vent**

No connection is required. Normally a sintered filter is installed. A small tray should be placed under the vent to catch drips of water.

#### ***CAUTION!***

*Do not restrict or back-pressure the gas vent in any way.*

### **2.5.3 AC Power**

- 1) Connect to a source of single phase AC power per specifications on the identification label on the rear of the unit.

## Section 3

# OPERATION

### 3.1 GENERAL

At this point, all preparation and positioning of the Model 3900 humidity generator should have been performed. Refer to section 2.


### 3.2 STANDARD OPERATING PROCEDURES

#### 3.2.1 Power-Up

- 1) Verify that the gas supply connection has been made and the gas supply is pressurized. Open any On/Off valve in the supply line if applicable.
- 2) Verify that primary AC power is connected to the console and is switched ON.
- 3) Toggle the Power switch located at rear console panel to ON. Within a few seconds, the liquid crystal display will light, a banner will appear, and the generator will perform a very short diagnostics test.

#### 3.2.2 Control/Display Screen

At the end of the power-up sequence, the following Control/Display Screen appears.



All control and measurement parameters critical to the operation of the humidity generator are displayed on this screen. Notice that in the leftmost column, each parameter is identified with a brief title and corresponding units. The asterisk in the leftmost column indicates the active humidity control parameter (section 3.2.4).

The Date and Time are displayed at the bottom of the screen, updating continuously every few seconds. To the right of the Date and Time is a number enclosed in square brackets [ ]. This is a measurement of the regulated input supply pressure.

The SetPnt column lists the user entered (and system calculated) control setpoints. The 3900 uses the setpoints as target values when controlling these parameters. The setpoints may be changed by the user at will (section 3.2.3).

The Actual column lists all of the measured data and calculated parameters of the generator.

A description of each of the Control/Display parameters follows:

<u>Parameter</u>	<u>Description</u>
------------------	--------------------

FRST PT °C -	The Frost Point temperature calculated at test pressure, $P_t$ , from saturation temperature, $T_s$ , and saturation pressure, $P_s$ . This calculation is independent of test temperature, and is only valid when below 0.01 °C Frost Point. Although inter-related, Frost Point is not the same as Dew Point.
--------------	---

DEW PT °C -	The Dew Point temperature calculated at test pressure, $P_t$ , from saturation temperature, $T_s$ , and saturation pressure, $P_s$ . This calculation is valid both above and below 0 °C, and is independent of test temperature. While inter-related, Dew Point is not the same as Frost Point.
-------------	--

PPMv -	Parts Per Million by Volume, PPMv, calculated from saturation temperature, $T_s$ , and saturation pressure, $P_s$ . This calculation is independent of test temperature and test pressure.
--------	--

PPMw -	Parts per Million by Weight, PPMw, calculated from saturation temperature, $T_s$ , saturation pressure, $P_s$ , and the molecular weight of the carrier gas. To change the molecular weight of the carrier gas, refer to section 3.3. This calculation is independent of test temperature and test pressure.
--------	--

%RH -	The %RH calculated from saturation pressure, $P_s$ , saturation temperature, $T_s$ , at test pressure, $P_t$ , and test temperature, $T_t$ . This calculation is only accurate if the device under test is at the conditions indicated by the test temperature and test pressure probes. Placing these external probes at the humidity sensing point of devices under test gives the actual value of the relative humidity being imposed on the devices, as %RH is dependent on both test pressure and test temperature.
-------	--

SATUR psi -	The saturation pressure measurement, $P_s$ , in pounds per square inch absolute, as measured by the low or high range saturation pressure transducer. (Pressure units may be set to psi, bar, or hPa. See section 3.3) Various humidity values are generated by controlling the saturation pressure, relative to a constant saturation temperature, $T_s$ . Saturation pressure is used in the calculation of all humidity parameters.
-------------	--

SATUR °C -	The temperature of saturation, $T_s$ , as measured by the saturation fluid temperature probe. This is used to control the temperature of the fluid surrounding the saturator, thereby ultimately controlling the saturation temperature. Saturation temperature is used in the calculation of all humidity parameters.
------------	--


- TEST  $\psi$ si - The test pressure,  $P_t$ , in pounds per square inch absolute, measured whenever the test pressure transducer is plugged in. (Pressure units may be set to psi, bar, or hPa. See section 3.3) Since test pressure is used in the determination of Frost Point, Dew Point, and %RH, the test pressure transducer should be placed as close as possible to, but downstream of, the device under test in order to measure device pressure. When the test pressure transducer is not plugged in, calculations of Frost Point, Dew Point, and %RH are referenced to the user entered test pressure setpoint rather than any measured value. For accurate humidity generation under these conditions, the absolute pressure at the device under test should be entered as the test pressure setpoint.
- TEST  $^{\circ}$ C - The test temperature,  $T_t$ , as measured by the test temperature probe whenever the test temperature probe is plugged in. Since test temperature is used in the calculation of %RH, the test temperature probe should be placed as close as possible to either the temperature sensing element (for chilled mirror hygrometers, etc.) or the humidity sensing element (for solid state humidity sensors) of any device under test. When the test temperature probe is not plugged in, calculations of %RH are referenced to the user entered test temperature setpoint rather than any measured value. For accurate humidity generation under these conditions, the temperature at the device under test should be entered as the test temperature setpoint.
- FLOW l/m - The mass flow rate, in standard liters per minute. Flow rate is not used in the calculation of humidity and is only an indication of the amount of gas flowing into the system. Since all gas flowing into the system also flows through and out of the system, it is useful for setting the desired flow rate through a device under test.

### 3.2.2.1 Changing the Display Contrast


To increase the display contrast press the <1> key on the numeric keypad. To decrease the contrast, press the <0>. The new contrast setting is automatically remembered by the system.

### 3.2.3 Changing Setpoints

After the initial power-up sequence of section 3.2.1, the Control/Display screen appears. On the display are four rectangular function key labels. These labels correspond to the four blank keys on their right.



To change any of the Frost Point, Dew Point, PPMv, PPMw, %RH, pressure, temperature, or flow setpoints, press the [CHNG SETP] key. The menu labels then change to arrows.



A cursor block will begin flashing in the SetPnt column on the first digit of the **current humidity control parameter** (the one with the asterisk to the left). Move the cursor up, down, left, or right using the appropriate arrow key.

To change any (or all) of the setpoints, position the cursor over the desired setpoint, then edit the value using the numeric keypad. Continue using the arrow keys and the numeric keypad until all desired values have been changed.

To enter a negative setpoint value for Frost Point, Dew Point, or Saturation Temperature, place the cursor on the leftmost digit of the desired setpoint and press the left arrow key to toggle the minus sign on and off.

End the setpoint editing session by pressing the <ENTER> key on the numeric keypad. The arrow keys revert back to their previously displayed functions, and the setpoints are validated and updated.

### 3.2.3.1 Example Setpoint Change

Change the setpoints to -20 °C Frost Point at a flow rate of 0.50 L/min.

- 1) Press [CHNG SETP]. The key labels change to arrows, and the cursor begins flashing.

	SetPnt	Actual	
*FRST PT °C	-10.00		▲
DEW PT °C	-11.23		
PPMv	2581.		▼
PPMw	1605.		
%RH	10.37		
SATUR psi	70.92		◀
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		▶
03/25/11	15:23:03	[294.6]	

- 2) Using the arrow keys and numeric keys as necessary, make the FRST PT °C setpoint value on the screen appear as -20.00.

	SetPnt	Actual	
*FRST PT °C	-20.00		▲
DEW PT °C	-11.23		
PPMv	2581.		▼
PPMw	1605.		
%RH	10.37		
SATUR psi	70.92		◀
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		▶
03/25/11	15:23:03	[294.6]	

- 3) If the negative sign is not present, use the arrow keys to place the cursor on the leftmost digit of the FRST PT °C setpoint and press the left arrow key once. The negative sign will appear.
- 4) Move the cursor down to the FLOW l/m setpoint value.

	SetPnt	Actual	
*FRST PT °C	-20.00		▲
DEW PT °C	-11.23		
PPMv	2581.		▼
PPMw	1605.		
%RH	10.37		
SATUR psi	70.92		◀
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		▶
03/25/11	15:23:03	[294.6]	

- 5) Using the arrows and numeric keys as necessary, make the FLOW 1/m setpoint value appear as 0.500.

	SetPnt	Actual	
*FRST PT °C	-20.00		▲
DEW PT °C	-11.23		▼
PPMv	2581.		◀
PPMw	1605.		▶
%RH	10.37		
SATUR psi	70.92		
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW 1/m	0.500		
03/25/11	15:23:03	[294.6]	

- 6) Find the asterisk in the left most column of the display. If it is not next to the FRST PT °C label, use the arrow keys and position the cursor back at the FRST PT °C setpoint value. This tells the system to switch to Frost Point Control mode (see section 3.2.4).
- 7) Press the <ENTER> key. The cursor disappears, and the displayed function key labels revert back to their previous descriptions. There should also be an asterisk left of FRST PT °C to indicate that it is the humidity controlling parameter.

Setpoints within legal limits are accepted. Those setpoints that are slightly above or below these limits are simply replaced by the appropriate limit value. Those setpoints that are far beyond the limits revert back to the previous setpoint value and are accompanied by a short audible warning beep. This most often occurs when the user inadvertently enters a wrong value or fails to include a decimal point.

The system automatically chooses a suitable saturation temperature setpoint if the one displayed would require a saturation pressure outside the range of the systems capability. In other words, if the value of the current control parameter requires a saturation pressure that is either too high or too low to achieve, the saturation temperature is automatically adjusted to a new value that allows saturation pressure to work within normal limits. The resulting humidity output will be valid regardless of the saturation temperature and saturation pressure combination that the system chooses.

### 3.2.4 Control Modes

The generator has the ability to control the humidity in one of six possible modes.

Mode 0  
*Power-up*  
*Default* \*FRST PT °C is controlled at a constant value by varying the saturation pressure,  $P_s$ , to compensate for changes in either saturation temperature,  $T_s$ , or test pressure,  $P_t$ . While Frost Point is held constant, PPMv, PPMw, and %RH may vary. When in Frost Point control mode, the saturation temperature setpoint is automatically determined.

Frost Point control mode is the one most often used, and is the power-up default mode of the generator. Frost Point control mode will automatically change to Dew Point control mode for setpoints above 0.01 °C.

Frost Point is independent of test temperature.

Mode 1 \*DEW PT °C is controlled at a constant value by varying saturation pressure,  $P_s$ , to compensate for any changes in either saturation temperature,  $T_s$ , or test pressure,  $P_t$ . While Dew Point is held constant, PPMv, PPMw, and %RH may vary. While in Dew Point control mode, the saturation temperature setpoint is automatically determined.

Dew Point control mode is valid both above and below 0 °C.

Dew Point is independent of test temperature.

Mode 2 \*PPMv is controlled at a constant value by varying saturation pressure,  $P_s$ , to compensate for any changes in saturation temperature,  $T_s$ . While PPMv is held constant, Frost Point, Dew Point, and %RH may vary. While in PPMv control mode, the saturation temperature setpoint is automatically determined.

PPMv is independent of test pressure and test temperature.

Mode 3 \*PPMw is controlled at a constant value by varying saturation pressure,  $P_s$ , to compensate for any changes in saturation temperature,  $T_s$ . While PPMw is held constant, Frost Point, Dew Point, and %RH may vary. While in PPMw control mode, the saturation temperature setpoint is automatically determined.

PPMw is independent of test pressure and test temperature.

Mode 4 \*%RH is controlled at a constant value by varying saturation pressure,  $P_s$ , to compensate for any changes in saturation temperature,  $T_s$ , test temperature,  $T_t$ , or test pressure,  $P_t$ . While %RH is held constant, all other humidity parameters may vary. While in %RH control mode, the saturation temperature setpoint is automatically determined.

Mode 5 \*SATUR psi,  $P_s$ , is controlled at a constant value independent of any other pressure, temperature, or humidity value. While saturator pressure is held constant, all humidity parameters may vary. While in saturation pressure control mode, the saturation temperature remains fixed at the user entered setpoint.

### 3.2.4.1 Changing Control Mode

- 1) Get into the setpoint editing mode by pressing [CHNG SETP]. The key labels change to arrows.

	SetPnt	Actual	
*FRST PT °C	-10.00		▲
DEW PT °C	-11.23		▼
PPMv	2581.		◀
PPMw	1605.		▶
%RH	10.37		
SATUR psi	70.92		
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		
03/25/11	15:23:03	[294.6]	

- 2) Position the cursor on the desired control parameter.

	SetPnt	Actual	
*FRST PT °C	-10.00		▲
DEW PT °C	-11.23		▼
PPMv	2581.		◀
PPMw	1605.		▶
%RH	10.37		
SATUR psi	70.92		
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		
03/25/11	15:23:03	[294.6]	

- 3) Change its value if needed.

	SetPnt	Actual	
*FRST PT °C	-10.00		▲
DEW PT °C	-11.23		▼
PPMv	2000.		◀
PPMw	1605.		▶
%RH	10.37		
SATUR psi	70.92		
SATUR °C	10.00		
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		
03/25/11	15:23:03	[294.6]	

- 4) With the cursor *still on that parameter*, press <ENTER>. The asterisk will then appear next to this selected control mode parameter.

	SetPnt	Actual	
FRST PT °C	-10.00		▲
DEW PT °C	-11.23		
*PPMv	2000.		▼
PPMw	1244.		
%RH	8.051		◀
SATUR psi	91.00		
SATUR °C	10.00		▶
TEST psi	14.70		
TEST °C	21.11		
FLOW l/m	1.000		▶
03/25/11	15:23:33	[294.6]	

When <ENTER> is pressed, the system first determines if there is a requested control mode change based on the position of the cursor. If the cursor is on one of the first six parameters, the control mode is changed to that parameter; otherwise the previous control mode remains in effect.

Next the setpoint of the active control mode is read and validated. Finally, the remaining parameters (Test Temperature, Test Pressure, and Flow) are read and validated. The current control mode parameter is indicated with an asterisk to its left.

### 3.2.5 Purging

The Purge mode is generally used to prevent icing within the saturator and dry the saturator outlet after movement (transportation), storage (power off, no gas flow, etc.), after performing the saturator fill procedure (section 3.2.8), or while transitioning the saturator from higher to lower temperatures.

When the system is not being used (power off, no gas flow, etc.), the saturator is closed off and the gas within is static. As thermal equilibrium is reached, water vapor will condense on all inner surfaces between the saturator outlet and the expansion valve inlet. The Purge mode counteracts this condition by allowing the carrier gas to flow in the opposite direction (expansion valve to saturator), drying the affected sections of tubing. This is a necessary preparatory step in any low humidity system.

As a general rule, when starting from an ambient condition the system should be purged for 24 hours or more before attempting to operate in the Generate mode. If sufficient purge time is not allowed, condensed or trapped water will remain and system accuracy will suffer. Insufficient purge time is usually indicated by higher than normal (wetter than normal) indications of the device under test. These indications can be as little as a few tenths of a degree to as much as several degrees frost point.

Purging should also be performed while transitioning from warmer to colder saturation temperatures, and for approximately 5 hours after each 500 hours of continuous Generate mode operation.

During Purge mode, both flow control and saturation temperature control are active, but saturation pressure control is disabled. The generator will attempt to achieve the indicated flow and saturation temperature setpoint values.

*Notes -1) When the saturation temperature is lowered, the fluid jacket surrounding the saturator cools in order to reduce the saturation temperature to its new setpoint value. As the saturator cools during this transition period, temperature gradients will exist between the inside of the saturator and the fluid jacket that surrounds it. The saturator outlet passes through this fluid jacket and will also exhibit temperature gradients along its length. If gas is allowed to flow normally through the saturator during this cooling period, the 100% humidified gas of the saturator may condense at the colder saturator outlet. Therefore, Purge mode should be used while cooling the saturator to lower temperatures. For this reason, the lowest humidity of a generation sequence or profile should be performed first. This low to high order requires that a Purge be performed only once prior to the generation sequence when cooling to the lowest saturation temperature. Then as humidity values are increased, warming the saturator to higher values, further purging is not required.*

*2) During Purge, no gas flows to the 3900 Conditioned Gas Outlet, and consequently no gas flows through the device under test if connected.*

### 3.2.5.1 Purge Procedure

- 1) From the idle Control/Display screen press [PRG]. The pump and compressors start and purge gas begins flowing within several seconds. Or, if the system is currently running in the Generate mode, press [PRG GEN\*] to switch to Purge mode. Within a few seconds, the following screen appears.

	SetPnt	Actual	
*FRST PT °C	-10.00		CHNG SETP
DEW PT °C	-11.23		
PPMv	2581.		CLR
PPMw	1605.		
%RH	10.39		
SATUR psi	70.29	14.48	PRG* GEN
SATUR °C	10.00	10.00	
TEST psi		14.70	
TEST °C		21.10	
FLOW l/m	1.000	1.001	STOP
03/25/11	15:23:37	[294.6]	

- 2) Using the [CHNG SETP] key, adjust setpoints to desired settings.
    - A) Typical purge flow rate is 1 liter/minute. Lower flows (minimum 0.1 L/min) will conserve gas while higher flow rates (maximum 5 L/min) will decrease purge time.
    - B) Saturation temperature should be set to the lowest temperature desired in the humidity generation sequence. However, when starting from a power-on condition, allow the generator to purge at the default setpoint (10 °C) for several hours before adjusting the setpoint to a lower value. The higher the saturation temperature during purge, the quicker the system will dry down. This makes it easier to evaporate any condensate that may exist in the saturator outlet tubing.
- To change the saturation temperature setpoint, edit one of the humidity control setpoints to a desired minimum target value. The saturation temperature setpoint will automatically adjust. (See note 1.)
- 3) Remain in the Purge mode for 24 to 48 hours if possible, depending on (1) flow rate, (2) how low the saturation temperature setpoint is, and (3) the length of time that the system purged while at a higher saturation temperature (discussed in step 2B above). Lower flow rates and lower saturation temperatures require longest purge times.

**Notes** -1. Entering a humidity control setpoint value causes the generator to automatically determine a suitable saturation temperature for that humidity. Saturation temperature setpoint must always be at least 2 °C above the frost point setpoint, and in general will not be more than 20 to 30 °C above frost point setpoint. If an attempt is made to directly adjust the saturation temperature setpoint outside these bounds, it will automatically readjust to a suitable value for the setpoint of the current humidity control parameter.

2. When in the Purge mode, if the flow rate will not achieve setpoint or drops to zero, icing may have occurred within the saturator passages, the saturator vent, or at the saturator inlet causing the generator to shutdown due to Error 4 - Low Supply Pressure. If this condition occurs, restart the generator, adjust the mass flow setpoint to zero, adjust the saturation temperature setpoint to 5 °C or warmer and allow to stabilize. Perform the Saturator Clear procedure (Section 3.2.6), then readjust setpoints and continue in the Purge mode.

### 3.2.6 Saturator Clear

This procedure is used to clear the saturator of any excess water that may have occurred as a result of filling (see section 3.2.8), as a result of movement (such as transportation), or as a result of freezing and thawing a full saturator. Any time that water is observed at the gas vent whether after filling, movement, or thawing, the saturator should be cleared several times until no further indication of excess water exists.

If the saturator has not been recently filled, and the generator not moved, saturator clearing is normally not needed (although it can never hurt).

#### 3.2.6.1 Saturator Clear Procedure

- 1) From the Control / Display screen press [PRG] to enable the purge mode. The pump and compressors start and purge gas begins flowing within several seconds.

Or, if the system is currently running in the Generate mode, press [PRG GEN\*] to switch to Purge mode.

- 2) View the saturator temperature. If the generator is or has been operating below 0 °C, adjust the Dew Point setpoint to 2 °C or warmer. Then adjust the saturation temperature setpoint to 5 °C or warmer and allow the system to stabilize.

*Note - The saturation temperature must be above 0 °C for a minimum of four hours before proceeding with the saturator clear procedure. This allows any ice in the saturator to completely melt.*

- 3) Press [CLR] key **3 times**. The key will increment to [CLR 15]. This clears the saturator of excess water for 15 cycles by pressurizing the system at 1 liter/minute and then quickly depressurizing the system through the gas vent at the rear of the generator. This will occur 15 times, decrementing the number on the [CLR] key after each cycle.

	SetPnt	Actual	
*FRST PT °C	-10.00		CHNG SETP
DEW PT °C	-11.23		
PPMv	2581.		CLR [15]
PPMw	1605.		
%RH	10.39		PRG* GEN
SATUR psi	70.29	24.35	
SATUR °C	10.00	10.00	
TEST psi		14.70	
TEST °C		21.10	
FLOW l/m	1.000	1.001	STOP
03/25/11	15:23:39	[294.6]	

- 4) If water is still observed at the pressure vent port by the fifteenth cycle, press the [CLR] key again for more cycles. Each time the [CLR] key is pressed, 5 cycles are added. Repeat this step until all excess water has been cleared. (Pressing the <0> key on the numeric keypad aborts the clearing process, removing the number from the [CLR] key label.)

Upon completion of the Saturator Clear process, the system remains in the Purge mode at the flow rate indicated in the SetPnt column.

### 3.2.7 Generating

The Generate mode is used to generate a gas stream of desired humidity. In the Generate mode, the gas flows through the saturator where it is saturated with water vapor at the indicated saturation temperature and saturation pressure conditions, then flows to the device under test at test pressure and test temperature conditions. Before attempting to Generate, the Purge procedure (Section 3.2.5) should have been performed.

- Notes -**
1. Upon initial receipt of the generator prior to use for the very first time, a Saturator Fill procedure (section 3.2.8 should be performed.)
  2. Before attempting to Generate after periods of inactivity, the Purge procedure (section 3.2.5) must be performed and allowed to purge for 24 to 48 hours.
  3. When in the Generate mode, if the flow rate indicates zero or remains well below setpoint, icing has occurred at the saturator outlet. This condition can occur after a saturator fill if an insufficient saturator clear and/or purge was performed. If this condition occurs, the saturator must be warmed above freezing (in the Purge mode) until the problem corrects itself. The Purge procedure (section 3.2.5) and the Saturator Clear procedure (section 3.2.6) must be performed.

When the [GEN] key is pressed (or the [PRG\* GEN] key from within the Purge mode), the temperature, pressure, and flow control processes begin. The fluid circulation pump will start and the refrigeration system will begin its start up sequence. If switching to Generate from the Purge mode, all control processes were already active with the exception of pressure control.

When in Generate mode, the 3900 will control at the values of humidity, temperature, and flow indicated in the SetPnt column. Setpoints may be freely changed regardless of whether the system is Generating, Purging, or Stopped. The values in the Actual column are the actual measured values, and when Generating will update approximately every 2 seconds.

	SetPnt	Actual	
*FRST PT °C	-10.00	-10.02	CHNG SETP
DEW PT °C	-11.23	-11.25	
PPMv	2581.	2576.	PRNT
PPMw	1605.	1603.	
%RH	10.39	10.36	PRG GEN*
SATUR psi	70.29	70.42	
SATUR °C	10.00	10.00	STOP
TEST psi		14.70	
TEST °C		21.10	
FLOW l/m	0.200	0.205	
03/25/11	15:23:40	[294.6]	

The [PRNT] key is used to activate/deactivate the printer (see section 3.2.12).

The [PRG GEN] key is used to switch back and forth between Generate and Purge modes.

Pressing [STOP] causes the computer to perform a system shutdown (see section 3.2.9).

### 3.2.7.1 Generating Procedure

**Note** - Before attempting to Generate after periods of inactivity, the Purge procedure (section 3.2.5) must be performed and allowed to purge for 24 to 48 hours.

To operate the system in the Generate mode:

- 1) Enter the desired setpoints (section 3.2.3) and set the control mode (section 3.2.4).
- 2) From an idle mode press [GEN]. Or, from the Purge mode, press [PRG\* GEN]. Within a few seconds, the following screen appears.

	SetPnt	Actual	
*FRST PT °C	-10.00	-10.02	CHNG SETP
DEW PT °C	-11.23	-11.25	
PPMv	2581.	2576.	PRNT
PPMw	1605.	1603.	
%RH	10.39	10.36	
SATUR psi	70.29	70.42	PRG GEN*
SATUR °C	10.00	10.00	
TEST psi		14.70	
TEST °C		21.10	
FLOW l/m	0.500	0.505	STOP
03/25/11	15:23:41	[294.6]	

- 3) Allow the system to run overnight if possible.

**Note** - Even though the greatest portion of excess moisture is removed with the purge procedures, an accurate humidity point may still take several hours to achieve, especially when attempting to generate very low humidities. For instance, a -80 °C frost point temperature can typically take 24 hours or more to completely dry down the outlet tubing and the device under test.

- 4) After operating in the Generate mode for several hours, the system should be at the desired humidity point. Check all instrumentation for stability and record a data point.
- 5) Adjust humidity to the next desired setpoint. Several hours should be allowed for the system and instrumentation being calibrated to stabilize and equilibrate to the new humidity value.
- 6) After the required amount of time, check all instrumentation for stability and record the data point.
- 7) Repeat steps 5 and 6 as required.

### 3.2.7.2 Example Instrument Set-Up

A chilled mirror hygrometer is to receive dew/frost point calibration at ambient temperature and pressure conditions.

- 1) Connect the gas inlet side of the chilled mirror to the generator outlet fitting with polished ID stainless steel tubing. The generator outlet is the Swagelok<sup>®</sup> fitting located on the counter top farthest from the front of the generator. For best chilled mirror stability, insulate this tube.
- 2) Allow the chilled mirror outlet to exhaust to atmosphere through a short section of tubing. This helps to prevent upstream humidity permeation.
- 3) Connect the pressure transducer to mirror exhaust if other than atmospheric pressure. Ensure that the transducer is plugged into the 3900. Otherwise, enter the mirror pressure as the Test Pressure Setpoint.
- 4) If making relative humidity measurements, plug the Test Temperature probe into the 3900 and attach the probe to the mirror thermometer.

### 3.2.8 Saturator Fill

The saturator filling procedure should be performed upon initial use after installation, and approximately every 500 hours or more of operation thereafter, depending upon the humidities and flow rates generated. Generating high flow rates and high humidity values requires more frequent filling.

The generator may require up to ten ounces (300 cc) of pure water (triple distilled or better) per fill. The amount of run time available from each fill is dependent upon the Frost/Dew Point being generated (during a Purge, it is based upon the saturation temperature). Colder temperatures (lower humidities) require less water than do higher temperatures (higher humidities).

The following table illustrates the approximate run time available at various generated humidity values. The amount of water used is also dependent upon flow rate. For instance, using only 0.5 liters/min gives twice as much run time as listed below, while using 2.0 liters/min gives only one half as much run time as listed.

<u>Dew/Frost Point Generated</u>	<u>Approximate Continuous Run Time @ 1 liter/min flow</u>
+15 °C	400 hours (2 weeks)
+10 °C	500 hours (3 weeks)
0 °C	1000 hours (1.5 months)
-10 °C	2500 hours (3.5 months)
-30 °C	17,000 hours (2 years)
-50 °C	150,000 hours (17 years)
-70 °C	2,500,000 hours (285 years)

Even though the lower temperatures make it appear that the system would never require filling; remember that a Purge always starts first at the higher temperatures to remove excess condensed water within the saturator passages and outlet tubing. Under these circumstances, the saturator water will eventually be depleted even if the lower temperatures are all that is ever generated.

#### 3.2.8.1 Saturator Fill Procedure

- 1) Put the system in a Purge mode, using the [PRG] key if the system is idle, or the [PRG\* GEN] if currently in the Generate mode. Within a few seconds, the Purge screen appears.

	SetPnt	Actual	
*FRST PT °C	-10.00		CHNG SETP
DEW PT °C	-11.23		
PPMv	2581.		CLR
PPMw	1605.		
%RH	10.39		
SATUR psi	70.29	14.60	PRG* GEN
SATUR °C	10.00	10.00	
TEST psi		14.70	
TEST °C		21.10	
FLOW l/m	1.000	1.001	STOP
03/25/11	15:23:42	[294.6]	

- 2) View the Saturation Temperature (SATUR °C). If the Saturation Temperature Setpoint is below 0 °C, then (1) adjust the dew point to 2 °C or warmer, and (2) adjust the saturation temperature to 5 °C or warmer. Allow the Saturation Temperature to warm above 0 °C and stabilize before proceeding to allow all ice in the saturator to completely melt.

*Note - Due to the large thermal mass of the saturator, the saturation temperature must be above 0 °C for a minimum of four hours before proceeding with the saturator fill procedure. This allows for sufficient thermal lag time when undergoing an ice/water phase change within the saturator.*

- 3) Press the [CLR] key. The key will increment to [CLR 10]. This step will perform 10 cycles of a pressurization/depressurization process which clears excess water from the pressure vent tubing and lower portions of the saturator prior to performing a saturator fill. Excess water is cleared by pressurizing the saturator at 1 liter/minute and then quickly depressurizing the saturator through the gas vent at the lower rear of the generator.

	SetPnt	Actual	
*FRST PT °C	-10.00		CHNG SETP
DEW PT °C	-11.23		
PPMv	2581.		CLR [10]
PPMw	1605.		
%RH	10.39		
SATUR psi	70.29	24.35	PRG* GEN
SATUR °C	10.00	10.00	
TEST psi		14.70	
TEST °C		21.10	
FLOW l/m	1.000	1.001	STOP
03/25/11	15:23:43	[294.6]	

- 4) After the completion of the Clear cycles, adjust flow setpoint to 0.5 liters/minute or less.
- 5) Locate the saturator fill port at front right of counter top and remove the port cap.
- 6) Slowly add two ounces of pure water (triple distilled or reagent grade) into the fill port using the supplied funnel.
- 7) Replace the port cap and tighten port cap 1/4 turn past finger tight.
- 8) Press saturator [CLR] key **2 times** to increment the saturator clear counter to [CLR 20]. This clears the saturator of excess water for 20 cycles.
- 9) If water is not observed in the gas vent during the 20 cycles repeat steps 4-8. Continue repeating steps 4-8 until water is observed in the gas vent. Saturator capacity is approximately 10 ounces (300 cc).
- 10) If water is observed in the gas vent after the twentieth cycle, press the [CLR] key for more cycles. Each time the [CLR] key is pressed, 10 cycles are added. Repeat this step until all excess water has been cleared.
- 11) Adjust flow setpoint to 1.0 liter/min or more, and allow the generator to continue purging for 24 to 48 hours before proceeding.
- 12) While remaining in the Purge mode, adjust setpoints to desired settings and allow the saturation temperature to achieve its setpoint.


### 3.2.9 Stopping

The system may be stopped while either Generating or Purging. When stopped, all system functions shutdown, pressure is vented, the printer is disabled (if attached), and the idle Control/Display screen is shown. The system must be stopped in order to access the Edit and Cal modes.

During this idle time when the system is either Stopped, in the Edit mode, or in the Cal mode, no gas is flowing in the saturator. After extended periods of this idle time, the system must be Purged again prior to further use.

To Stop the system and enter and idle mode:

- 1) From either the Generate or Purge modes, press [STOP]. Within a few seconds, all system functions will shut down and the idle Control/Display screen will appear.



	SetPnt	Actual	
*FRST PT °C	-10.00		CHNG SETP
DEW PT °C	-11.23		
PPMv	2581.		EDIT /CAL
PPMw	1605.		
%RH	10.37		
SATUR psi	70.29		PRG
SATUR °C	10.00		
TEST psi			
TEST °C			
FLOW l/m	1.000		GEN
03/25/11	15:23:44	[294.6]	

The Stopped mode is easily distinguished from all others since all data in the Actual column is blank on this idle Control/Display screen.

### 3.2.10 Shutdown

A shutdown should be performed when servicing the 3900, or when use is not frequent enough (such as day to day) to justify leaving the instrument in the Generate or Purge mode. When these conditions apply, follow the complete shutdown procedure:

- 1) Press the [STOP] key. This disables the temperature control circuits, vents the system of excess pressure, and closes all valves.
- 2) Allow all pressure to vent, then toggle main power switch to OFF.
- 3) Cap conditioned gas outlet.
- 4) Turn gas source OFF.
- 5) If maintenance is to be performed, disconnect power source from the system.

### 3.2.11 Changing Gas Supply

It is quite common to operate the system from a non-permanent gas source such as compressed bottled gas or a LN<sub>2</sub> Dewar. These gas sources eventually become depleted and require changing. To change the gas supply without completely stopping or shutting down the system:

- 1) Set the Flow setpoint to 0 liters/minute. Allow a few seconds for the flow and saturation pressure indications to drop off. Temperature control will remain active.
- 2) Disconnect and remove the depleted gas source.
- 3) Connect to the new gas source.
- 4) Set the Flow setpoint back to the original setting. Within a few minutes, the system will return to its previous state.

### 3.2.12 Printer (optional)

Reference Drawings 94M39901, 95M39914

An optional printer is used for hard copy output of system data and other parameters. While the 3900 humidity generator is operating in a Generate mode, data is output on a timed interval basis when activated by the user. User alterable printer parameters are explained in section 3.3.2.6. The printer is connected to the printer port using either a factory supplied or user made cable. The required cable is simply a 9 to 25 pin AT Port Adapter (see drawings).

The [PRNT] key, when pressed, toggles to [PRNT ON] and causes measured system data to be sent to the printer at regular time intervals (see section 3.3 to change default time and other print parameters).

The [PRNT ON] key, when pressed, toggles to [PRNT], disables printer output, and sends a form feed to the printer. This also occurs when switching to Purge mode or Stopping.

The <ENTER> or <•> key, when pressed, immediately sends one line of system data to the printer regardless of the PRNT ON/OFF status, and independent of print time interval. Notice that this *print now* feature is not active while in the Change Setpoint mode.

### 3.3 EDITING SYSTEM COEFFICIENTS AND PARAMETERS

All of the calibration coefficients and system parameters may be viewed and/or edited by the operator. The following is a summary of these items.

<u>Category</u>	<u>Editable Parameters</u>
Temperature Coefficients	Coefficients and Averaging
Pressure Coefficients	Coefficients and Averaging
Flow Coefficients	Coefficients and Averaging
Console Port Parameters	Baud Rate, Parity, etc.
Printer Port Parameters	Baud Rate, Parity, Print Interval, Lines per Page, etc.
Time & Date	Time and Date of Real Time Clock
Misc User Parameters	RH Calculation Method (WMO), Pressure Units, Date Format, Molecular Weight of Carrier Gas


#### 3.3.1 Edit Mode

The EDIT mode is used for the viewing and editing process.


- 1) From the idle Control/Display screen, press [EDIT/CAL]. Note, for this menu option to appear the generator must not be in Generate or Purge mode. In a few seconds, the following menu appears.




- 2) From this menu, press [EDIT].
- 3) At the prompt, enter in your authorization code (found at the back of the manual).




An incorrect code prevents access and returns to step 3. A correct code results in the display of calibration coefficients.



- 4) Using the [NEXT] and [PREV] keys, view any or all of the remaining coefficient and parameter screens.



- 5) To edit a particular displayed value, press [EDIT]. The cursor begins flashing at the left of the first parameter displayed.




Using [-/+], [E], arrow keys, and the numeric keys as necessary, change any or all displayed values as desired. Then press <ENTER>.

- 6) After Editing or Viewing, press [DONE]. Then from the next menu, press [DONE] again. The system reinitializes back to the Control/Display screen.

### 3.3.2 Coefficients and Parameters

Each of the values on the various coefficient and parameter screens will be discussed in detail in the following sections.

#### 3.3.2.1 Temperature Coefficients



The ZERO, SPAN, and LIN values are coefficients to the formula

$$\text{Temp} = A + Bx + Cx^2$$

- where A = zero coefficient
- B = span coefficient
- C = linearity coefficient
- x = output of the A/D converter card.

These coefficients are automatically computed during temperature calibration (section 4.2.2).

AVG is the amount of averaging applied to the displayed value. Averaging is applied with the formula

$$\text{New Value} = \{(\text{Previous Value} * \text{AVG}) + \text{New Reading}\} / (\text{AVG} + 1)$$

An AVG of zero (0) effectively eliminates averaging. An AVG that is very large has a correspondingly large averaging affect. Non-integer averaging amounts are allowable; however, negative amounts should never be used. An AVG of approximately 10 is typical, while an AVG of 1000 would be excessively high.


The date indicated at the bottom of the screen is the last date of calibration or the date of the most recent editing of any of the listed values. The date shown may not be edited and is updated automatically during calibration or when changing coefficients on this screen.

### 3.3.2.2 Reference Resistor Coefficients

These coefficients are factory set and similar to the temperature coefficients of section 3.3.2.1. The reference resistor is approximately 10KΩ with coefficients chosen to provide a reference value of approximately 0 °C. An AVG amount of approximately 50 is typical.

Any change made to either the reference resistor or the coefficients (with the exception of AVG) requires that the temperature calibration of section 4.2.2 be performed on both temperature probes.

### 3.3.2.3 Pressure Coefficients



The ZERO, SPAN, and LIN values are coefficients to the formula

$$\text{Pressure} = A + Bx + Cx^2$$

- where A = zero coefficient
- B = span coefficient
- C = linearity coefficient
- x = output of the A/D converter card.

These coefficients are automatically computed during pressure calibration (section 4.2.3)

AVG is the amount of averaging applied to the displayed value. Averaging is applied with the formula

$$\text{New Value} = \{(\text{Previous Value} * \text{AVG}) + \text{New Reading}\} / (\text{AVG} + 1)$$

An AVG of zero (0) effectively eliminates averaging. An AVG that is very large has a correspondingly large averaging affect. Non-integer averaging amounts are allowable; however, negative amounts should never be used. An AVG of approximately 10 is typical, while an AVG of 1000 would be excessively high.

The date indicated at the bottom of the screen is the last date of calibration or the date of the most recent editing of any of the listed values. The date shown may not be edited and is updated automatically during calibration or when changing coefficients on this screen.

### 3.3.2.4 Flow Coefficients

MASS FLOW RATE			EDIT
Zero	[ 0	]	NEXT
Span	[ 4E-04	]	PREV
Lin	[ 0	]	DONE
Avg	[ 10	]	
Last Cal Date 03/14/10			

The ZERO, SPAN, and LIN values are coefficients to the formula

$$\text{Flow} = A + Bx + Cx^2$$

where A = zero coefficient  
B = span coefficient  
C = linearity coefficient  
x = output of the A/D converter card.

These coefficients are automatically computed during flow calibration (section 4.2.4)

AVG is the amount of averaging applied to the displayed value. Averaging is applied with the formula

$$\text{New Value} = \{(\text{Previous Value} * \text{AVG}) + \text{New Reading}\} / (\text{AVG} + 1)$$

An AVG of zero (0) effectively eliminates averaging. An AVG that is very large has a correspondingly large averaging affect. Non-integer averaging amounts are allowable; however, negative amounts should never be used. An AVG of approximately 10 is typical, while an AVG of 1000 would be excessively high.

The date indicated at the bottom of the screen is the last date of calibration or the date of the most recent editing of any of the listed values. The date shown may not be edited and is updated automatically during calibration or when changing coefficients on this screen.



### 3.3.2.6 Printer Port Parameters

These parameters affect the manner in which the unidirectional RS-232 Printer Port behaves. It not only affects communication parameters, but time interval between printouts of system data, and the number of lines to print per page.

```
PRINTER PORT PARAMETERS
Baud  [ 9600 ]
Data  [ 8     ]
Stop  [ 1     ]
Parity [ 0     ]
Intrvl [ 60   ]
Lns/Pg [ 50   ]
```

Baud: 300, 600, 1200, 2400, 4800, 9600, 19200 or 38400 bits per second

Data: 7 or 8 bit word size.

Stop: 1 or 2 stop bits

Parity: 0 for NO parity, 1 for ODD parity, or 2 for EVEN parity

Intrvl: The print interval, or number of seconds between printouts of system data.

Lns/Pg: Lines per Page of printed data.

### 3.3.2.7 Time and Date

This screen is used to change the Time and/or Date of the Real Time Clock. Note that time is input and displayed in 24-hour format. Also notice that the date is displayed in the date format selected in Miscellaneous User Parameters (section 3.2.2.8).

```
DATE 10/11/12
TIME 15:29:39
Month [10 ]
Day   [11 ]
Year  [12 ]
Hour  [15 ]
Min   [29 ]
Sec   [39 ]
```

### 3.3.2.8 Miscellaneous User Parameters

This screen is used to change the Miscellaneous User Parameters.

MISC USER PARAMETERS		EDIT
WMO	[ 1 ]	
P Units	[ 0 ]	NEXT
T Units	[ 0 ]	
F Units	[ 0 ]	PREV
DateFmt	[ 0 ]	
MW	[ 28.9645 ]	DONE
Tt Type	[ 0 ]	
Pt Type	[ 50 ]	
Pg Warn	[ 50 ]	
Pg Stop	[ 35 ]	
Pg Ctrl	[ 1 ]	

**WMO:** When the Test Temperature is below 0 °C, %RH may be computed with respect to either water in accordance with the World Meteorological Organization (WMO=1) or with respect to ice (WMO=0).

**P Units:** 0 = psi  
1 = bar  
2 = hPa  
*Note that all pressure measurements are absolute with the exception of the input supply transducer which is gauge.*

**T Units:** 0 = °C (currently the only option)

**F Units:** 0 = liters/min (currently the only option)

**Date Fmt:** 0 = mm/dd/yy (U.S. format)  
1 = dd/mm/yy (European format)

**MW Gas:** Molecular Weight of the carrier gas. Setting this value to zero (0) forces the system to revert back to the factory setting of 28.9645 (Molecular Weight of Air). When using N<sub>2</sub> as the carrier gas, set the value to 28.0134. PPMw is the only parameter directly affected by the value entered.

***Note -** The Molecular Weight does not alter the Enhancement Factors in any way nor compensate for variations in solubility or compressibility of various gasses. Therefore, when using a carrier gas other than air or nitrogen, the validity of the Enhancement Factors used in the calculation of humidity parameters cannot be assured.*

**Tt Type:** Set this to zero (0) when using the standard 10K thermistor for Test Temperature measurement. A setting of one (1) indicates that the optional low temperature 1K thermistor is to be used. Any time that the test temperature probe is changed, it must either be recalibrated, or its previously computed calibration coefficients must be re-entered.

**Pt Type:** This must be set to the full scale range (in psiA) of the Test Pressure transducer.

**Pg Warn:** If the supply pressure drops below this pressure, the system emits a warning signal to indicate that the supply pressure is low.

Pg Stop: If the supply pressure drops below this pressure while generating or purging, the system will shutdown.

*Note - If the Flow Rate setpoint is set to zero (0), the system does not shutdown on low supply pressure. This allows gas supply bottles to be changed while generating and purging without requiring that the system be shutdown.*

Ps Ctrl: The system has the capability of operating simply as a two-temperature generator (Ps Ctrl = 0), or in a combined two-temperature two-pressure mode (Ps Ctrl = 1). When operating as a two-temperature generator only, the expansion valve remains fully open in order to minimize any pressure drop between the saturator and devices under test. In this mode, all humidity changes require changes in the saturator temperature. The lowest frost point obtainable in the two-temperature mode is governed by the saturation temperature range as defined in section *1.3 Specifications*.

## CALIBRATION AND MAINTENANCE

### 4.1 GENERAL

The Model 3900 low humidity generation system requires little periodic maintenance. Following the proper operating procedures as given in this manual will help assure trouble-free operation of this system.

### 4.2 CALIBRATION

Proper calibration of the temperature and pressure transducers is critical to the accuracy of the generated humidity. Each time a transducer is calibrated its current calibration coefficients and calibration date are stored to non-volatile memory.

Calibration of the system requires the following support equipment:

- 1) Temperature:
  - A. Temperature bath with a liquid medium (recommend Fluorinert FC-77, a 3M product), a range of 0-50 °C, and stability of  $\pm 0.01$  °C or better. Less stable baths may require the use of a thermal block.
  - B. Standard or reference thermometer (PRT or Thermistor) for the range of -80 to 10 °C for the saturator temperature, and 0 to 50 °C for the test temperature both having a resolution of 0.01 °C or better. Thermometer accuracy should be  $\pm 0.03$  °C or better.
- 2) Low Pressure Range:
  - A. Static gas pressure source for the pressure range of ambient to 50 psi, 3.5 bar, or 3500 hPa absolute with a stability of  $\pm 0.0025$  psi, 0.00017 bar, 0.17 hPa or better.
  - B. Standard or reference pressure gauge for the range of ambient to 50 psi, 3.5 bar, or 3500 hPa absolute with a resolution of  $\pm 0.0025$  psi, 0.00017 bar, 0.17 hPa or better. Reference pressure accuracy should be  $\pm 0.025$  psi, 0.0017 bar, 1.7 hPa or better.
- 3) High Pressure Range:
  - A. Static gas pressure source for the pressure range of ambient to 300 psi, 21 bar, or 21000 hPa absolute with a stability of  $\pm 0.01$  psi, 0.00069 bar, 0.69 hPa or better.
  - B. Standard or reference pressure gauge for the range of ambient to 300 psi, 21 bar, or 21000 hPa absolute with a resolution of  $\pm 0.01$  psi, 0.00069 bar, 0.69 hPa or better. Reference pressure accuracy should be  $\pm 0.10$  psi, 0.0069 bar, 6.9 hPa or better.
- 4) Flow:
  - A. Standard or reference flow meter for the range of 0 to 5 standard liters per minute with a resolution of 0.01 L/min or better. Flow meter accuracy should be  $\pm 0.05$  L/min or better.

Calibration of all transducers is to be performed "in the system, as a system". There are no provisions for, nor is it recommended that calibration of any of the transducers (temperature, pressure, or flow) be performed while electrically disconnected from the generator. Since all calibration is performed mathematically by the computer, there are no manual adjustments to make.

Calibration is performed on all of the transducers by solving for the coefficients A, B, and C of the quadratic formula:

$$Y=A+Bx+Cx^2$$

where x is the raw count (or uncalibrated output of the A/D converter) while measuring a transducer, and

Y is the desired value (the standard or reference transducer's reading) for the transducer being calibrated.

The three coefficients A, B, and C are found by applying three separate, distinct, and stable references to each transducer, measuring the resulting raw count, then solving the mathematical system of three equations with three unknowns. Since all of these calculations are performed automatically by the 3900's embedded computer, the operator need only be concerned with providing three known stable references required for the calibration of each transducer.

#### **4.2.1 A/D Card**

Equipment Required: (None)

All calibration errors appearing in the A/D card will be accounted for automatically during calibration of the temperature, pressure, and flow transducers. The card is also equipped with built in auto-zero and auto-span circuitry which automatically and continually accounts for short and long term drift in measurement accuracy. No user calibration is required. A card suspected of extreme inaccuracies or malfunctions should be sent to the factory for repair.

#### **4.2.2 Temperature Calibration**

The systems EDIT/CAL mode may be used in conjunction with a precision temperature bath for temperature probe calibrations. Only one temperature probe may be calibrated at a time.

By using the temperature bath to generate three known temperatures, all coefficients (ZERO, SPAN, LINEARITY) can be calculated automatically by the embedded computer and used to update the system calibration. A new expanded calibration report may also be printed at the conclusion of the calibration sequence.

### 4.2.2.1 Test Temperature Calibration Procedure


Reference Drawing 95D39902

Equipment Required:

1. Temperature Bath (per section 4.2).
2. Standard or Reference thermometer (per section 4.2)

Calibration Procedure:


- 1) Bring a precision temperature bath with reference thermometer to the system, and install the Test Temperature thermistor into temperature bath. If using water as the fluid medium, do not submerge the probe completely or water may get into the probe and damage the thermistor element.
- 2) From the main Control/Display screen, press the [EDIT/CAL] key. The Edit/Cal menu appears.



- 3) Press the [CAL] key. The calibration menu appears.




4) Press the [TEMP CAL] key. The probe selection screen appears.




5) Using [MARK/CLR] and the down arrow key as necessary, mark the Test Tmp probe. A marked probe is indicated with an asterisk on the left. Since the two temperature probes require different calibration ranges, the computer will only allow you to mark one probe at a time.

6) After marking the Test Tmp probe, press [OK] or <ENTER>. The LOW, MID, and HIGH temperature reference values appear at the bottom of the screen, and within a few seconds, actual data begins updating in the Count and °C columns.



7) Adjust the temperature bath to a LOW temperature point at or near 0 °C and allow sufficient time for stability.

8) Once stable, press [LOW TEMP], and input the value of the Standard Thermometer as the LOW temperature. Use [-/+ ] and arrow keys as necessary.



Then press <ENTER>. The LOW temperature value just entered, and the values of the marked probe are automatically saved to memory for later computation of calibration coefficients.

*Note - If a mistake was made during the temperature entry mode, use [OOPS] rather than <ENTER>. This will cancel the temperature entry mode and restore the previous "standard" and "marked" probe values to memory. For instance, [OOPS] could be used if the operator wanted to take the LOW temperature point, but had mistakenly pressed the [MID TEMP] key.*

- 9) Repeat step 8 for both a MID temperature (near 25 °C) and HIGH temperature (near 50 °C). Be sure to use the appropriate [MID TEMP] and [HIGH TEMP] keys.

*Note - Using the [LOW TEMP], [MID TEMP], or [HIGH TEMP] key more than once allows the previous point of the thermistor to be over-written with the most current measured value. The reference thermometer value will also be over-written with the new value entered. The data stored is that which exists on the screen in the "Count" column when the [LOW TEMP], [MID TEMP], or [HIGH TEMP] key is pressed.*

- 10) After all three temperature points have been taken, press [CALC COEF] to calculate the new temperature coefficients for the probe which is marked. Unmarked probes retain their previous coefficients. The current coefficients for the marked probe will appear on the screen.

TEST TEMPERATURE, Tt		PRNT COEF
Zero	[ .0197137 ]	
Span	[ 9.98941E-03 ]	EXIT QUIT
Lin	[ 1.56924E-09 ]	SAVE QUIT

- 11) If a printer is attached, a calibration record of the temperature points and calculated coefficients is printed. Press the [PRNT COEF] key if additional printouts are desired. This is the only opportunity to print this report. Upon leaving this screen, the data used for report generation is lost (with the exception of the calculated coefficients being displayed.)
- 12) To update the calibration with new coefficients, press the [SAVE QUIT] key. To abort without storing these new coefficients, press the [EXIT QUIT] key.

*Note - If the new coefficients were printed but not SAVED, the new coefficient values may be entered later using the EDIT mode described in section 3.3.*

- 13) Check the accuracy of the calibration if desired, by repeating steps 4 through 6, however, don't "mark" any of the probes for calibration. Adjust the temperature bath to any values between 0 and 50 °C and visually compare readings. When done, press [EXIT QUIT].
- 14) At the calibration menu, press [DONE]. Then press [DONE] at the next menu. The system reinitializes and the Control/Display screen appears.
- 15) To print a condensed coefficient report, listing temperature, pressure, and flow coefficients together on one page, refer to section 4.2.5.

#### 4.2.2.2 Saturation Temperature Calibration

Reference Drawings 95D39902

Equipment Required:

1. Standard or Reference Thermometer (per section 4.2)
2. 3/16" (4.5 mm) ball/hex driver
3. 9/16" (15 mm) wrench
4. 9/16" (15 mm) socket with 6" (15 cm) extension

Calibration Procedure:

The saturation temperature probe may be calibrated using the 3900's temperature controlled saturator as the fluid bath.

- 1) For safety purposes, switch console power OFF and remove line cord.
- 2) Remove both side panels, and then remove the four socket head screws that secure the counter top. Lift off the counter top and remove the 4" square foam insert that insulates the saturator.
- 3) Using a 9/16" socket with 6" extension, loosen and remove the 1/4" Swagelok cap on the Auxiliary Temperature Port.
- 4) Slide a 1/4" Swagelok nut and nylon ferrule set onto the shaft of the Standard Thermometer and then insert it into the saturator's Auxiliary Temperature Port approximately 3 to 4 inches. Seal the saturator by tightening the nut.
- 5) Install foam insulation around the saturator and the Standard Thermometer.
- 6) Replace side panels.

*Note - The system must not be operated unless all panels are in place or the refrigeration system will overheat.*


- 7) Reinsert the line cord and switch console power ON.
- 8) From the main Control/Display screen, press the [EDIT/CAL] key. The Edit/Cal menu appears.



9) Press the [CAL] key. The calibration menu appears.




10) Press the [TEMP CAL] key. The probe selection screen appears.




11) Using [MARK/CLR] and the down arrow key as necessary, mark the Satur Tmp probe. A marked probe is indicated with an asterisk on the left. To complete selection, press [OK] or <ENTER>.

12) The saturation temperature calibration screen consists of two sections, the saturator temperature control and the calibration data.




To obtain access to the setpoint control, press the <ENTER> key on the numeric keypad.



At this time, the cursor will begin flashing on the control setpoint in the saturator temperature control section. The temperature setpoint may be changed to any value within the operational limits of the saturator by using the numeric keypad, the arrow keys and the [-/+ ] key as necessary. To enable the saturator temperature control at the setpoint entered, press the [ON/OFF] toggle key. To return to the calibration section, press <ENTER> on the numeric keypad.

Using the method described above, enter the high temperature setpoint and enable the control. Allow sufficient time for movement to and stability at the setpoint.

- 13) Once stable, press [HIGH TEMP], and input the value of the Standard Thermometer as the HIGH temperature. Use [-/+ ] and arrow keys as necessary.




Then press <ENTER>. The HIGH temperature value just entered, and the values of the marked probe are automatically saved to memory for later computation of calibration coefficients.

**Note -** *If a mistake was made during the temperature entry mode, use [OOPS] rather than <ENTER>. This will cancel the temperature entry mode and restore the previous "standard" and "marked" probe values to memory. For instance, [OOPS] could be used if the operator wanted to take the HIGH temperature point, but had mistakenly pressed the [MID TEMP] key.*

- 14) Repeat steps 12 and 13 for both a MID temperature and LOW temperature. Be sure to use the appropriate [MID TEMP] and [LOW TEMP] keys.

*Note - Using the [LOW TEMP], [MID TEMP], or [HIGH TEMP] key more than once allows the previous point of the thermistor to be over-written with the most current measured value. The reference thermometer value will also be over-written with the new value entered. The data stored is that which exists on the screen in the Count column when the [LOW TEMP], [MID TEMP], or [HIGH TEMP] key is pressed.*

- 15) After all three temperature points have been taken, press [CALC COEF] to calculate the new coefficients for the probe which is marked. Unmarked probes retain their previous coefficients. The current coefficients for the probe will appear on the screen.



- 16) If a printer is attached, a calibration record of the temperature points and calculated coefficients is printed. Press the [PRNT COEF] key if additional printouts are desired. This is the only opportunity to print this report. Upon leaving this screen, the data used for report generation is lost (with the exception of the calculated coefficients being displayed.)
- 17) To update the calibration with the new coefficients, press the [SAVE QUIT] key. To abort without storing these new coefficients, press the [EXIT QUIT] key.

*Note - If the new coefficients were printed but not SAVED, the new coefficient values may be entered later using the EDIT mode described in section 3.3.*

- 18) Check the accuracy of the calibration if desired, by repeating steps 10 through 12, however, don't "mark" any of the probes for calibration. Adjust the Saturator control setpoint to any values between -80 and +12 °C and visually compare readings. When done, press [EXIT QUIT]
- 19) At the calibration menu, press [DONE], then press [DONE] at the next menu. The system reinitializes and the Control/Display screen appears.
- 20) To print a condensed coefficient report, listing temperature, pressure, and flow coefficients together on one page, refer to section 4.2.5.
- 21) For safety purposes, switch the console power off and remove line cord.
- 22) Remove Standard Temperature probe and reinstall Swagelok cap. Reinstall the foam insulation, counter top and replace side panels. *The system must not be operated unless all panels are in place.*

### 4.2.3 Pressure Transducer Calibration

Pressure Transducer Calibration is typically performed in a calibration laboratory and requires that the transducers be removed from the pneumatic system of the 3900, but must remain electrically connected. The pressure readings must be precise in order to retain accurate relative humidity calculations. Since the 3900 may be operated and calibrated in various pressure units (psi, bar, hPa), ensure that the system is set to the desired units (section 3.3) prior to performing the pressure calibration.

Reference Drawing 95D39902

Equipment Required:

1. Static pressure source, and standard or reference measurement, with absolute pressure range of ambient to 50 psi, 3.5 bar, or 3500 hPa (per section 4.2).
2. Static pressure source, and standard or reference measurement, with absolute pressure range of ambient to 300 psi, 21 bar, or 21000 hPa (per section 4.2).
3. 9/16" (15 mm) and 11/16" (18 mm) open end wrenches.
4. Flat blade screwdriver.

Pressure Conversion Factors:

$$\text{psi} = \text{bar} * 14.503774$$
$$\text{psi} = \text{hPa} * 0.014503774$$

$$\text{bar} = \text{psi} * 0.068947573$$
$$\text{bar} = \text{hPa} * .001$$

$$\text{hPa} = \text{psi} * 68.947573$$
$$\text{hPa} = \text{bar} * 1000$$

#### 4.2.3.1 Saturator and Test Pressure Calibration Procedure

Reference Drawing 95D39902

- 1) For safety purposes, switch console power OFF and remove the line cord.
- 2) For safety purposes, turn OFF or disconnect air supply.

**CAUTION!**  
ALL SYSTEM PRESSURE MUST BE  
VENTED BEFORE PROCEEDING.

- 3) Bring the pressure source to the generator or take the generator to the pressure calibration lab.
- 4) To access the saturator pressure transducers, remove left console panel.
- 5) Slowly disconnect pressure transducers (11/16" & 9/16" wrench required). Some static pressure may still exist in the saturator and pressure transducers. This pressure should be allowed to vent slowly through the fitting during removal. Using a screwdriver, pry open the round snap-lock transducer mounts, and remove the transducers. Ensure the electrical connectors are in place.
- 6) Reinsert line cord and switch console power ON. Wait a few moments for the softkey menu to appear. Allow approximately 30 minutes or more for warm-up of the pressure transducer electronics.
- 7) Connect the pressure source to the transducer to be calibrated (only one transducer at a time may be calibrated).

*Note - Each transducer is operated over a limited range and requires calibration within this range only.*


- A) Low Range Saturation Pressure Transducer - Calibrate from ambient to approximately 50 psi, 3.5 bar, or 3500 hPa absolute.
- B) High Range Saturation Pressure Transducer - Calibrate from ambient to approximately 300 psi, 21 bar, or 21000 hPa absolute.
- C) External Test Pressure Transducer - Calibrate from its lowest to highest range of actual use (typically ambient to full scale).

8) Press the [EDIT/CAL] key, then the [CAL] key. The calibration menu appears.




9) Press the [PRES CAL] key.

10) Using [MARK /CLR] and the down arrow key as necessary, mark the transducer to be calibrated. A marked transducer is indicated with an asterisk in the left most display column. Since each of the transducers require a different calibration range, the computer will only allow you to mark one transducer at a time.



11) Confirm selection by pressing [OK] or <ENTER>.

12) Apply the lower recommended calibration pressure and watch the displayed value of the marked transducer. Once stable, press the [LOW PRES] key and enter the reference pressure.



*Note - For all transducers, ambient pressure may be used for the low pressure calibration point.*

*Note - If a mistake is made during reference pressure entry, pressing the [OOPS] key cancels the data entry mode, leaving all values for that point unchanged.*

- 13) Apply the mid range pressure and watch the displayed value. Once stable, press the [MID PRES] key and enter the reference pressure.

	Count	psi A	
*Low Range	15538	30.11	- / +
Hi Range	1513	12.19	OOPS
Ext Test	7385	12.19	◀
Supply	29806	250.9	▶
<u>Low</u>	<u>Mid</u>	<u>High</u>	
12.212	29.989	50	

- 14) Apply the upper recommended pressure and watch the displayed value. Once stable, press the [HIGH PRES] key and enter the reference pressure.

	Count	psi A	
*Low Range	15538	30.11	- / +
Hi Range	1513	12.19	OOPS
Ext Test	7385	12.19	◀
Supply	29806	250.9	▶
<u>Low</u>	<u>Mid</u>	<u>High</u>	
12.212	29.989	50	

- 15) Press the [CALC COEF] key. All coefficients for the marked transducer will be calculated, and appear on the LCD display.

		PRNT COEF
LOW RANGE PRESSURE, Ps		
Zero	[ -.609974 ]	
Span	[ 1.96204E-03 ]	EXIT QUIT
Lin	[ 5.12663E-09 ]	SAVE QUIT

- 16) If a printer is attached, a calibration record of the pressure points and calculated coefficients is printed. Press the [PRNT COEF] key if additional printouts are desired. This is the only opportunity to print this report. Upon leaving this screen, the data used for report generation is lost (with the exception of the calculated coefficients being displayed.)
- 17) To save the coefficients, press [SAVE QUIT]. The coefficients will be stored to non-volatile memory. To abort the calibration without saving the coefficients just calculated, press [EXIT QUIT]. The previous coefficients will be reinstated.
- 18) Check the accuracy of the calibration if desired by repeating steps 9 through 11 however don't "mark" any of the probes. Apply various pressures within the range of the transducer and visually compare the readings.
- 19) Repeat steps 7 through 18 for the high-pressure saturator and the external test pressure transducers, using the suggested LOW, MID, and HIGH pressures indicated on the screen.
- 20) For safety purposes, switch main console power to OFF and disconnect line cord.
- 21) Re-install the pressure transducers (0-50 psiA Saturator transducer, TR3, goes on the right next to the solenoid valve.) Tighten all connections 1/4 turn past finger tight.
- 22) Replace left console panel. *The system must not be operated unless all panels are in place.*
- 23) To print a condensed coefficient report, listing temperature, pressure, and flow coefficients together on one page, refer to section 4.2.5.

### 4.2.3.2 Supply Pressure Transducer Calibration

The supply pressure measurement, while indicated on the screen, is not critical to the accuracy of the 3900 and is not used in the humidity calculations.

Reference Drawing 95D39902

Equipment Required:


1. Gas Supply of at least 300 psi, 21 bar, or 21000 hPa gauge.

Calibration Procedure:

- 1) For safety purposes, switch the console power OFF and then remove front console panel.
- 2) Switch console power ON. Wait a few minutes for the softkey menu to appear. Allow approximately 30 minutes or more for warm-up of the pressure transducer electronics.
- 3) Press the [EDIT/CAL] key, then the [CAL] key. The calibration menu appears.



- 4) Press the [PRES CAL] key.
- 5) Using [MARK /CLR] and the down arrow key as necessary, mark the Supply pressure transducer.



- 6) Confirm the selection by pressing [OK] or <ENTER>.



#### 4.2.4 Flow Meter Calibration

The flow measurement, while indicated on the screen, is not critical to the accuracy of the generated humidity and is not used in the humidity calculations. Flow calibration accuracy depends upon the requirements of the user.

Equipment Required:

1. Standard or Reference flow meter (per section 4.2).

##### 4.2.4.1 Flow Calibration Procedure

Reference Drawing 95D39902

The calibration for the flow meter is slightly different than for the temperatures and pressures, and does not require the removal of the flow meter from the system.

- 1) Using appropriate fittings, connect a flow meter reference instrument to the gas outlet port of the system.
- 2) Generate a flow rate of approximately 1.0 L/min. Once stable, note the readings of the reference flow meter and of the indicated flow of the 3900.
- 3) Change the flow to 2.0 L/min. Once stable note both readings again.
- 4) Press [STOP]. Once the shutdown is complete, press [EDIT/CAL]. The following menu appears.




5) Press [CAL]. The calibration menu appears.




6) Press [FLOW CAL].

7) Press [MARK/CLR] to mark the flow meter (indicated by an asterisk to its left).



8) Press [OK]. Within a few seconds, the measured flow readings begin updating.



- 9) Allow a few moments for stability of the flow indication. This "no flow" condition will be used for a LOW flow reference. Press [LOW FLOW] to store this point. Then press <ENTER>.

	Count	l/min	
*Mass Flow	4	.0144	↕ /+
			OOPS
			◀
Low	Mid	High	▶
0	1.0	2.0	

- 10) Using the 1.0 liter data obtained in step 2, calculate the following:

$$1.0 + (\text{Reference Indication}) - (3900 \text{ Indication})$$

Press [MID FLOW] and enter this calculated value.

	Count	l/min	
*Mass Flow	2500	1.000	↕ /+
			OOPS
			◀
Low	Mid	High	▶
0	0.98	2.0	


- 11) Using the 2.0 liter data obtained in step 3, calculate the following:

$$2.0 + (\text{Reference Indication}) - (3900 \text{ Indication})$$

Press [HIGH FLOW] and enter this calculated value.

	Count	l/min	
*Mass Flow	5000	2.000	↕ /+
			OOPS
			◀
Low	Mid	High	▶
0	0.98	1.97	

- 12) Press [CALC COEF] to calculate the new flow meter coefficients. These new coefficients appear on the display.



- 13) If a printer is attached, a calibration record of the flow points and calculated coefficients is printed. Press the [PRNT COEF] key if additional printouts are desired. This is the only opportunity to print this report. Upon leaving this screen, the data used for report generation is lost (with the exception of the calculated coefficients being displayed.)
- 14) To save the coefficients to non-volatile memory, press [SAVE QUIT]. To discard these new coefficients and revert to the previous ones, press [EXIT QUIT].
- 15) At the calibration menu, press [DONE]. At the next menu, press [DONE] again. The system reinitializes to the Control / Display screen.
- 16) To print a calibration report, refer to section 4.2.5.

## 4.2.5 Printing Condensed Coefficient Report

If a printer is connected to the Printer Port, a Coefficient Report for the temperature, pressure and flow transducers may be printed. This condensed report lists the current system calibration coefficients and calibration date for all of the system transducers. This report is printed from the Edit/Cal menu.

To print the report:

- 1) From the idle Control/Display screen press [EDIT/CAL], or from the Cal menu press [DONE]. Both actions should bring up the Edit/Cal menu.
- 2) Ensure the printer is on, then press [PRNT REPT]. The Coefficient Report will be sent to the printer. See sample below.
- 3) Press [DONE] to return to the Control/Display screen.

Coefficient Report				
for				
TSC Model 3900 Low Humidity Generator				
S/N: XXXXXXX				
Date: MM/DD/YY				
Temperature	Zero	Span	Linearity	Cal Date
Saturation Temperature	0.00000E+00	1.00000E-02	0.00000E+00	MM/DD/YY
Test Temperature	0.00000E+00	1.00000E-02	0.00000E+00	MM/DD/YY
Temp Reference Resistor	-2.50000E+01	1.00000E-02	0.00000E+00	MM/DD/YY
-----				
Pressure	Zero	Span	Linearity	Cal Date
Low Range Sat	0.00000E+00	2.00000E-03	0.00000E+00	MM/DD/YY
Hi Range Sat	0.00000E+00	1.20000E-02	0.00000E+00	MM/DD/YY
External Test	0.00000E+00	2.00000E-03	0.00000E+00	MM/DD/YY
Supply	0.00000E+00	2.00000E-02	0.00000E+00	MM/DD/YY
-----				
Flow	Zero	Span	Linearity	Cal Date
Mass Flow Rate	0.00000E+00	4.00000E-04	0.00000E+00	MM/DD/YY
-----				
Certified by _____				
Date _____				

## **4.3 ROUTINE MAINTENANCE**

### **4.3.1 Console Intake: Monthly**

Reference Drawing 94D39901

Equipment Required: (None)

Cleaning Procedure:

- 1) Locate console intake on left side of console.
- 2) Remove any obstruction and dust from console panel.
- 3) Remove left console panel and dust finned aluminum condenser.
- 4) Replace left console panel

### **4.3.2 7 Micron Gas Input Filter: Yearly**

Reference Drawing (pneumatic)

Equipment Required:

1. 9/16" open end wrench
2. Two 3/4" open-end wrenches.

Filter Change Out Procedure:

- 1) For safety purposes, switch console power OFF and remove line cord.
- 2) Disconnect facility gas supply.
- 3) Remove right side console panel.
- 4) Using both a 9/16" and a 3/4" wrench, remove inline filter from gas supply line tubing.
- 5) Using both 3/4" wrenches, disassemble filter body and remove filter from tapered bore.
- 6) Insert new filter element into tapered bore.
- 7) Reassemble filter body and tighten securely.
- 8) Replace inline filter into gas supply line tubing.
- 9) Replace console access panel and reconnect console power.

## **4.4 SERVICING REFRIGERATION AND FLUID SYSTEMS**

Reference Drawing 95S39917

Before starting repairs on either refrigeration system, the serviceman should be familiar with the location of all components of the stages. Especially important is the identification of the high and low stages of the refrigeration system. The high stage compressor always connects directly to the air-cooled condenser. The low stage compressor connects directly to the oil separator. By following the tubing and referring to the flow diagram, most parts can easily be traced. By necessity, some parts are foam insulated and rarely require servicing.

### **4.4.1 Fault Isolation and Diagnosis**

In the event of system failure, before attaching gauges or opening either refrigeration circuit, every effort should be made to ensure that the problem is not electrical in nature. If compressors are suspected, check the compressor relays, overloads, and capacitors. Check the temperature control contacts and associated wiring. Use the above procedure on the high stage first, as it is impossible to run the low stage system unless the high stage is functional and has had time (10 minutes) to cool the interstage heat exchanger.

Although great care is taken in the design and manufacture, these systems can be subject to normal failures. Refrigerant leaks, moisture, and component failure can be diagnosed in much the same way as in other refrigeration equipment. There are some differences, especially with respect to the low stage.

#### **4.4.1.1 Moisture In Low Stage**

This can be diagnosed and repaired as in any medium temperature refrigeration system.

Excess moisture in the low stage results in ice blocking the capillary tube; however, the replacement of the drier is not possible as it is located within the foam insulation. The cabinet must be allowed to warm up to room temperature so that sufficient heat will enter the interstage heat exchanger. Then proceed in this order:

- 1) Bleed off all refrigerant from the low stage.
- 2) Evacuate for 8 to 12 hours.
- 3) Replace vacuum with ultra dry nitrogen to a pressure of 150 psiG.
- 4) Bleed off pressure.
- 5) Repeat steps 2-4 three times.
- 6) Evacuate again as in step 2.
- 7) Replace refrigerant with specified amount (Section 4.4.2).

#### 4.4.1.2 Oil In Low Stage Evaporator

The migration of compressor oil to the low stage capillary tube will create symptoms similar to those of moisture. Solidification does occur as the oil reaches the capillary tube. This can reduce flow resulting in lower suction pressure. If the cabinet is warmed to a temperature of -18 °C or higher and then restarted, the oil will be flushed out of the capillary tube and will not build up again for a week or more. Moisture will show up much sooner, usually in a matter of hours.

#### 4.4.2 Refrigerant Charge

Saturator Refrigeration: High stage requires fourteen (13) ounces of R-134A. Low stage requires six (9.5) ounces of R-23.

#### 4.4.3 Saturator Fluid System

The saturator fluid system uses methyl alcohol (methanol) as a heat transfer medium because of its low freezing point. This fluid is circulated by a magnetically coupled centrifugal pump (FP1) at approximately two gallons per minute. This pump has an approximate life of 10,000 hours and may ultimately need service. Should this system require repair, extreme caution is required in the draining and filling due to the flammability of methanol.

#### **CAUTION!**

*THIS SYSTEM CONTAINS METHYL ALCOHOL (METHANOL)*

*FLAMMABLE AND POISONOUS*

*Keep away from sparks, flames, or other ignition sources. Avoid prolonged or repeated breathing of vapors or contact with skin. Do not allow material to contaminate water sources.*

#### 4.4.4 Methanol System Drain / Fill Procedure

Reference Drawings 95D39902 & 08D39922

Equipment Required:

1. 3/16" & 3/8" ball/hex driver
2. 7/8" socket with 6" extension
3. 4 feet of 1/4" OD tube with 1/4" Swagelok nut and ferrules attached on one end
4. 5.675 liters (1.5 gallons) of anhydrous methanol
5. Marked 7.5 liter (2 gallon) container for used methanol
6. Funnel
7. Gloves and goggles

To drain saturator fluid system, proceed as follows:

- 1) Disconnect power source from console.
- 2) Remove right side console panel.
- 3) Locate saturator drain valve (located below pump on right side of console). Remove insulation on drain valve outlet. Remove Drain Valve Cap and connect 1/4" hose to drain valve. Place other end of drain hose into two gallon container.
- 4) Open drain valve and drain methanol.
- 5) After draining methanol, close drain valve, remove drain hose and replace Drain Valve Cap and insulation.
- 6) Repairs or shipment may be made at this time.

To fill saturator fluid system, proceed as follows:

- 1) Disconnect power source from console.
- 2) Locate and remove the four counter top bolts using 3/16" ball/hex driver, then remove the counter top.
- 3) Remove circular insulation and using the 3/8" ball/hex driver remove the Methanol Expansion Tank Fill Port Plug.
- 4) Locate RTD1 Access Insulation and remove. Using the 7/8" socket with 6" extension, remove the Saturator Methanol Port Cap from the top of the saturator.
- 5) Insert the funnel into the Methanol Expansion Tank Fill Port. **Slowly and carefully** fill the saturator assembly until methanol is observed just below the Saturator Methanol Port Fitting located on top of the saturator (in the square insulation area).

***Note -** The methanol must be added slowly as it is being gravity fed through 3/8" tubing between the methanol expansion tank and the saturator. Do not allow funnel to fill.*

*Methanol degrades the urethane foam insulation; sponge dry any methanol spilled during the filling operation!*

- 6) Replace the Saturator Methanol Fill Port Cap (tighten 1/4 turn past finger tight).
- 7) Replace Methanol Expansion Tank Fill Port Plug.
- 8) Replace all insulation.
- 9) Replace counter top.

## 4.5 ERROR CODES and TROUBLESHOOTING

Prior to system start-up, and during humidity generation, the system monitors itself for errors and sources of possible malfunction. When a catastrophic error occurs, the system automatically shuts down, then alerts the operator with a visual flashing message and an audible tone. The visual message displays the error number and a brief description of the problem.

It is possible (in many cases probable) to have multiple errors occurring at one time. Under these circumstances, the error codes simply add together algebraically, and all of the associated messages are displayed in turn. Any error code greater than 16383 will be displayed as a negative number. In this case, simply add 65536 to the displayed number to calculate the appropriate code. While it is not necessary to understand the error code system, it is important to write down the error code number exactly as it appears on the screen when consulting the factory for technical support. Little can be done to ascertain the nature of the problem without the exact error code.

The following is a list of error codes and a brief description of each.

<u>ERROR CODE</u>	<u>DESCRIPTION</u>
1	Expansion Valve Not Closing
2	Flow Valve Not Closing
4	Low Supply Pressure
8	Cabinet Temperature Overrange
32	Reference Temperature Underrange
48	Reference Temperature Overrange
64	Test Temperature Underrange
80	Test Temperature Overrange
128	Saturator Temperature Underrange
144	Saturator Temperature Overrange
512	Test Pressure Underrange
768	Test Pressure Overrange
1024	Low Range Saturator Pressure Underrange
1280	Low Range Saturator Pressure Overrange
2048	High Range Saturator Pressure Underrange
2304	High Range Saturator Pressure Overrange

### **Error 1 - Expansion Valve Not Closing**

This indicates that while attempting to close the expansion valve, the HOME position limit switch closure was not detected. This could mean that either the valve is not moving properly or the switch is mechanically or electrically malfunctioning.

### **Error 2 - Flow Valve Not Closing**

This indicates that while attempting to close the flow valve, the HOME position limit switch closure was not detected. This could mean that either the valve is not moving properly or the switch is mechanically or electrically malfunctioning.

#### **Error 4 - Low Supply Pressure**

This indicates that there is insufficient gas supply pressure to continue or that icing has occurred (section 3.2.5.1 Note 2). Check the gas supply. A malfunction of solenoid valve SOL1 or solid state relay SSR5 may also cause this problem.

#### **Error 8 - Cabinet Temperature Overrange**

The measured cabinet temperature is too high. Most likely causes include a blocked or clogged intake vent on the left side of the unit, a blocked outlet at the back of the unit, or a faulty fan. Anytime the rear panel is removed and reinstalled, ensure that the fan gets plugged in.

#### **Error 32 - Reference Temperature Underrange**

The temperature reference resistor is well below its nominal value of 0 °C. This typically indicates a faulty reference resistor or a malfunctioning A/D converter card.

#### **Error 48 - Reference Temperature Overrange**

The temperature reference resistor is well above its nominal value of 0 °C. This typically indicates a faulty reference resistor or a malfunctioning A/D converter card.

#### **Error 64 - Test Temperature Underrange**

The indicated test temperature is below -80 °C. One possible cause could be the testing environment temperature is less than -80 °C. The most likely cause is a malfunction of the temperature probe.

#### **Error 80 - Test Temperature Overrange**

The indicated test temperature is above 100 °C. One possible cause could be the testing environment temperature is greater than 100 °C. The most likely cause is a malfunction of the temperature probe.

#### **Error 128 - Saturation Temperature Underrange**

The indicated saturation temperature is below -85 °C. The most likely cause is a malfunction of the temperature probe. This could also be caused by a faulty heat control circuit or a short in SSR0.

#### **Error 144 - Saturation Temperature Overrange**

The indicated saturation temperature is above 30 °C. The most likely cause is a malfunction of the temperature probe.

#### **Error 512 - Test Pressure Underrange**

The test pressure transducer indicates a pressure that is less than 10 psiA. The most likely cause is a pressure transducer malfunction or calibration error.

**Error 768 - Test Pressure Overrange**

The test pressure transducer indicates a pressure more than 10% above its full scale reading. The most likely cause is a pressure transducer malfunction or calibration error.

**Error 1024 - Low Range Saturation Pressure Underrange**

The low range saturation pressure transducer indicates a pressure less than 10 psiA. The most likely cause is a pressure transducer malfunction or calibration error.

**Error 1280 - Low Range Saturation Pressure Overrange**

The low range saturation pressure transducer indicates a pressure more than 10% above its full scale reading. One possible cause would be a malfunction or leak in the pressure select solenoid, SOL4. This error could also be caused by a pressure transducer malfunction or calibration error.

**Error 2048 - High Range Saturation Pressure Underrange**

The high range saturation pressure transducer indicates a pressure less than 10 psiA. The most likely cause is a pressure transducer malfunction or calibration error.

**Error 2304 - High Range Saturation Pressure Overrange**

The high range saturation pressure transducer indicates a pressure more than 10% above its full scale range. The most likely cause is a pressure transducer malfunction or calibration error.

## Section 5

**3900 PARTS LISTS**

Find #	Qty.	Description	Part Number
A/D	1	Analog A/D Card	MCM7418
ATB	1	Analog Terminal Board	ADP7409TB
C1	1	Compressor, R-134A	COMPR-220V/50HZ
C2	1	Compressor, R-23	COMPR-220V/50HZ
CBS1	1	Power Switch	PWRSW-2P
CF1	1	Fan, Console	MR77B3
CF2	1	Fan, Console	FN624N
CON1	1	Condenser, R-134A	BT-COND
CON2	1	Condenser, R-13	D95A00186
CP1,2	2	Capacitor, 10 $\mu$ F 35V Elec	*****
CPU	1	CPU Card	D96A39021
CV1	1	Valve, Check	S4C-1/3
EX1	1	Exchanger, Heat	D95A00185
FB1	1	Core, Ferrite	FERSPLTCORE
FD1,2	2	Filter/Drier	C-032-S
FP1	1	Pump, Centrifugal	D95A00192
G1	1	Gauge, Pressure	J2258
H1	1	Heater, Cartridge	N9N-1560
H2	4	Heater, Foil	HK5161
H3	6	Heater, Foil	** HK5579
HLS1	1	Heat Limit Switch	A19AAF-12
KB	1	Keypad	D94M39205
LCD-CON	1	Display Controller	D96A00228_39
LCD	1	Liquid Crystal Display	DMF6104
LCD-INV	1	Inverter Board (Back-Lite)	CXAM10L
LF1	1	Filter, Inline	S4F-7
MEM	1	Memory Card	D96A39022
MOV1	3	Varistor, Metal Oxide	MOV1
OS1	1	Separator, Oil	D40B0010
PLF1	1	Filter, Power Line	F1700BB03
PS1	1	Supply, $\pm$ 15/5VDC Power	HTAA-16W-A
PS2	1	Supply, +24VDC Power	MAP55-1024
RECR	1	Receiver, Refrigeration	BT-RECR
REG	1	Regulator, Pressure	CONREG
RTD1	1	Sensor, Temperature	THRMPB3
RTD2	1	Sensor, Temperature	BTPROBE3
RV1	1	Valve, Relief	S4C-150
SAT	1	Saturator	D95A00026
SL1,2	2	Switch, Limit	MCRSW2
SM-1,2	2	Motor, Stepper	PX243G
SMD-1,2	2	Driver, Stepper Motor	RD-023MS
SOL1-4	4	Valve, Solenoid	A2012
SOL5	1	Valve, Solenoid	V8264G9-24V
SPKR	1	Minilert Audible Signal	MINLRT


### 3900 PARTS LIST (continued)

Find #	Qty.	Description	Part Number
SSR0-5	6	DC SSR Module	G4DC5
SSR6,7	2	AC SSR Module	G4AC5
SSR8-10	3	10 Amp SSR	R24D10
SSRB	1	SSR Module Board	OP2512
TR1	1	Transducer, Pressure	ST2500G1
TR2	1	Transducer, Flow	BK5860E
TR3	1	Transducer, Pressure	PTE50
TR4	1	Transducer, Pressure	DCT300A
TR5	1	Transducer, Pressure	PTE50
			* DCT150A
TB1	20	Terminal Block	ABWM3
TIB	1	Terminal Interface Board	TBD-100
TM1	1	Tank, Methanol Expansion	D95A00187
V1	1	Valve, Flow	D95A00172
V2	1	Valve, Expansion	D95A00172
V3	1	Valve, Refrigeration Expansion	NIF-1/2-C
V5	1	Valve, Metering	SS-2MA

\* High Pressure (HP) Option Parts


\*\* High Air Flow (39-HAF) Option Parts

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APP. BY
DWF	F	DRAWN TO SW	8/12/2013	MJG
DWF	G	UPDATED SHEET FORMAT	8/13/2018	BB



TOP


CONDITIONED GAS OUTLET  
FILL PORT - PURE WATWE ONLY



LEFT SIDE


COMPUTER & PRINTER  
INTERFACE

AIR INTAKE



FRONT

TEST TEMPERATURE (RTD2)  
TEST PRESSURE (TR5)



REAR

MAIN AC  
POWER &  
SWITCH


GAS VENT  
GAS INLET

DO NOT SCALE FROM DRAWING		THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION			<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
			<b>TOLERANCES</b> .XXX ±.010 .XX ±.015 ∠ ±.50° UNLESS NOTED OTHERWISE			DRAWN FISCHER 7/28/1994 APPROVED BB 7/28/1994 ISSUED GMF 7/28/1994		<b>Mechanical / Utility</b>
NEXT ASSY	USED ON		SIZE <b>A</b>	DWG. NO. <b>94D39901</b>		REV <b>G</b>		
APPLICATION			WT. 404.05		SHEET 1 OF 1			

**NOTES:**



1. INTERPRET DRAWING PER ASME Y14.100-2013
2. INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5-2009
3. ALL UNITS ARE INCHES U.N.O.

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	E	Drawn to SW	8/13/2013	<i>MJE</i>




		PRODUCTION DESIGNATION 39-Z-2	THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123	
		TOLERANCES .X ±.25 ∠ ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER 4/4/1995	Component Locations		
NEXT ASSY	USED ON	3900		CHECKED <i>MB</i> 4/4/1995	SIZE <b>A</b>	DWG. NO. <b>94D39902</b>	REV <b>E</b>
APPLICATION				ISSUED <i>MB</i> 4/4/1995	SCALE: 1 : 16	WT. 293.46	SHEET 1 OF 1

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	E	Drawn to SW	8/14/2013	<i>MJE</i>




		PRODUCTION DESIGNATION 39-Z-3	THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
		TOLERANCES		DRAWN FISCHER 3/31/1995		Cards & Card Cage		
NEXT ASSY USED ON		.X ±.25		CHECKED <i>MJE</i> 4/4/1995		SIZE A	DWG. NO. 95D39903	REV E
APPLICATION		UNLESS NOTED OTHERWISE		ISSUED <i>MJE</i> 4/4/1995		SCALE: 1 : 8	WT.	SHEET 1 OF 1

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	D	Drawn to SW	8/14/2013	<i>MJE</i>



		PRODUCTION DESIGNATION	THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123			
		39-Z-4				<b>3900 Bus Diagram</b>			
		TOLERANCES		DRAWN	FISCHER	3/29/1995	SIZE <b>A</b>	DWG. NO. <b>95D39904</b>	REV <b>D</b>
		.X ±.25		CHECKED	<i>MG</i>	4/4/1995			
NEXT ASSY		USED ON		ISSUED	<i>MG</i>	4/4/1995	SCALE: N/A   WT.		SHEET 1 OF 1
APPLICATION		UNLESS NOTED OTHERWISE							



REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	F	Drawn to SW	8/14/2013	<i>MJE</i>
DWF	G	Added SSR1 for 10 SLPM Option	1/19/2015	<i>MJE</i>



SIDE VIEW


PRODUCTION DESIGNATION 39-Z-5		THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123	
TOLERANCES .X ±.25 ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER 3/29/1995 CHECKED <i>MB</i> 4/13/1995 ISSUED <i>MB</i> 4/13/1995		<b>Electrical Sub Panel Layout</b>		
NEXT ASSY USED ON		SIZE <b>A</b>		DWG. NO. <b>95D39905</b>		
APPLICATION		SCALE: N / A		WT.		
				REV <b>G</b>		
				SHEET 1 OF 1		

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	G	Drawn to SW	8/20/2013	<i>MJE</i>




		PRODUCTION DESIGNATION <b>39-Z-6</b>	THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123			
		<b>TOLERANCES</b> .X ±.25 ∠ ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER	3/29/1995	<b>Terminal Layout</b>			
NEXT ASSY	USED ON			CHECKED	<i>MB</i>	4/4/1995	SIZE <b>A</b>	DWG. NO. <b>95S39906</b>	REV <b>G</b>
APPLICATION				ISSUED	<i>MB</i>	4/4/1995	SCALE: N / A	WT. N / A	SHEET 1 OF 1

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	G	Drawn to SW	8/21/2013	




		THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123	
			<b>TOLERANCES</b> .XXX ±.010 ±.50° UNLESS NOTED OTHERWISE		<b>AC - DC Power Schematic</b>	
NEXT ASSY	USED ON	3900	DRAWN	FISCHER	3/25/1995	SIZE
APPLICATION			CHECKED	<i>MG</i>	4/4/1995	DWG. NO.
			ISSUED	<i>MG</i>	4/4/1995	95S39907
						REV
						G
			SCALE: N/A		WT. N/A	SHEET 1 OF 1

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	J	Drawn to SW	9/19/2013	<i>DF</i>
DWF	K	Revised 10 SLPM Option Heaters	1/20/2015	<i>MJE</i>




		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
			<b>TOLERANCES</b> .XXX ±.010 / ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER 3/31/1995 CHECKED <i>MJE</i> 3/31/1995 ISSUED <i>MJE</i> 3/31/1995	<b>Solid State Relay Module Schematic</b>	
NEXT ASSY	USED ON	3900			SIZE <b>A</b> DWG. NO. <b>95S39908</b> REV <b>K</b>		
APPLICATION				SCALE: N/A WT. N/A		SHEET 1 OF 1	

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	F	Drawn to SW	8/21/2013	




		THIRD ANGLE PROJECTION 	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
					Compressor, Heater, Alarm Schematic		
3900		TOLERANCES		DRAWN	FISCHER	3/30/1995	
NEXT ASSY	USED ON	.XXX ±.010		CHECKED	<i>MG</i>	4/4/1995	SIZE
APPLICATION		UNLESS NOTED OTHERWISE		ISSUED	<i>DWF</i>	4/4/1995	A
							DWG. NO.
							95S39909
							REV
							F
						SCALE: N/A	WT. N/A
						SHEET 1 OF 1	

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	E	Drawn to SW	8/22/2013	<i>[Signature]</i>




		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
					<b>Flow Valve Driver Schematic</b>		
3900		<b>TOLERANCES</b> .XXX ±.010 ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER 3/30/1995 CHECKED <i>MG</i> 4/4/1995 ISSUED <i>DWF</i> 4/4/1995	SIZE <b>A</b> DWG. NO. <b>95S39910</b> SCALE: N / A	REV <b>E</b> WT. N / A	SHEET 1 OF 1
NEXT ASSY	USED ON	APPLICATION					

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	E	Drawn to SW	8/22/2013	




		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
					<b>Expansion Valve Driver Schematic</b>		
3900		<b>TOLERANCES</b> .XXX ±.010 ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER 3/30/1995 CHECKED <i>MF</i> 4/4/1995 ISSUED <i>MF</i> 4/4/1995	SIZE <b>A</b> DWG. NO. 95S39911 SCALE: N / A	REV <b>E</b> WT. N / A	SHEET 1 OF 1
NEXT ASSY	USED ON	APPLICATION					

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	E	Drawn to SW	9/20/2013	




		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
					Temp Probe / Transducer Schematic		
3900		TOLERANCES		DRAWN FISCHER	3/30/1995		
NEXT ASSY	USED ON	.XXX ±.010		CHECKED <i>MB</i>	4/4/1995		
APPLICATION		UNLESS NOTED OTHERWISE		ISSUED <i>MB</i>	4/4/1995		
SIZE <b>A</b>	DWG. NO. <b>95S39912</b>	SCALE N / A		WT. N / A	REV <b>E</b>	SHEET 1 OF 1	

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	D	Drawn to SW	9/20/2013	<i>[Signature]</i>



		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123			
					<b>Display Block Diagram</b>			
			<b>TOLERANCES</b> .XXX ±.010 ±.50° UNLESS NOTED OTHERWISE	DRAWN FISCHER 3/31/1995 CHECKED <i>MF</i> 4/4/1995 ISSUED <i>MF</i> 4/4/1995	SIZE <b>A</b> DWG. NO. <b>95S39913</b>	REV <b>D</b>		
NEXT ASSY	USED ON	3900			SCALE	N / A	WT. N / A	SHEET 1 OF 1
APPLICATION								

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APPROVED
DWF	D	Drawn to SW	07/22/2015	



**CONNECTOR PINOUT**

PIN #	CONSOLE PORT	PRINTER PORT	DATA / LOGIC DIRECTION
1	NC	NC	
2	TxD	TxD	OUT
3	RxD	RxD	IN
4	DSR**	DSR**	
5	SIG GND	SIG GND	
6	DTR**	DTR**	
7	RTS*	RTS	IN
8	CTS*	CTS	OUT
9	NC	NC	

\* = CONSOLE PORT DOES NOT SUPPORT RTS / CTS. PINS 7 & 8 ARE STRAPPED TOGETHER WITHIN THE UNIT.

\*\* = 3900 DOES NOT SUPPORT DSR & DTR SIGNALS. PINS 4 & 6 ARE STRAPPED TOGETHER WITHIN THE UNIT FOR THE USE OF PERIPHERAL EQUIPMENT.

**PRINTER CONNECTION**

TO CONNECT A SERIAL PRINTER TO THE PRINTER PORT, USE PRINTER CABLE (PART #: PCABLE) OR A STANDARD MODEM CABLE

**COMPUTER CONNECTION**


TO CONNECT ANY IBM COMPATABLE COMPUTER TO THE CONSOLE PORT, USE CONSOLE CABLE (PART #: CCABLE) OR 9 PIN EXTENDER CABLE. CONNECTION TO ANY OLDER COMPUTER MAY REQUIRE AN ADAPTER CABLE OR CONNECTOR. (NOT PROVIDED)

THESE CONNECTIONS CAN BE FOUND ON THE UPPER RIGHT HAND CORNER OF THE LEFT SIDE PANEL


		THIRD ANGLE PROJECTION	<p><b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION</p>		<p><b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123</p>			
			<p><b>TOLERANCES</b> .XXX ±.010 ∠ ±.50° UNLESS NOTED OTHERWISE</p>		<p>DRAWN Fischer 03/29/1995</p>		<p>RS-232C / Printer Console</p>	
NEXT ASSY	USED ON	3900	CHECKED <i>MB</i>	04/04/1995	SIZE <b>A</b>	DWG. NO. 95D39914	REV <b>D</b>	
APPLICATION			ISSUED <i>MB</i>	04/04/1995	SCALE: 1 : 1	WT. N/A	SHEET 1 OF 1	

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APP. BY
DWF	E	CHANGED V5 NOTE - DRAWN TO SW	7/24/2015	MG

**GENERATE MODE**



DO NOT SCALE FROM DRAWING	
	3900
NEXT ASSY	USED ON
APPLICATION	



TOLERANCES	
.XXX	±.010
.XX	±.015
∠	±.50°
UNLESS NOTED OTHERWISE	

**PROPRIETARY NOTICE**  
THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION

DRAWN	FISCHER	3/7/1995
APPROVED	MG	4/4/1995
ISSUED	MG	4/4/1995

**Thunder Scientific Corporation**  
623 Wyoming S.E. Albuquerque, NM 87123

**Pneumatic System - Generate Mode**


SIZE	DWG. NO.	REV
<b>A</b>	<b>95S39915</b>	<b>E</b>
WT. N/A		SHEET 1 OF 1

**NOTES:**

1. INTERPRET DRAWING PER ASME Y14.100-2013
2. INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5-2009
3. ALL UNITS ARE INCHES U.N.O.
4. REMOVE ALL BURRS AND SHARP EDGES


REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APP. BY
DWF	E	CHANGED V5 NOTE - DRAWN TO SW	7/24/2015	MG

**PURGE MODE**



DO NOT SCALE FROM DRAWING		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123	
			<b>TOLERANCES</b> .XXX ±.010 .XX ±.015 ∠ ±.50° UNLESS NOTED OTHERWISE		<b>Pneumatic System - Purge Mode</b>	
3900			DRAWN FISCHER	3/7/1995	SIZE	DWG. NO.
NEXT ASSY	USED ON		APPROVED MG	4/4/1995	<b>A</b>	<b>95S39916</b>
APPLICATION			ISSUED MG	4/4/1995	WT. N/A	REV <b>E</b>
					SHEET 1 OF 1	

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APP. BY
DWF	F	DRAWN TO SW	6/11/2018	BB




DO NOT SCALE FROM DRAWING		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123			
					<b>Saturator Refrig. &amp; Fluid Flow</b>			
NEXT ASSY		USED ON	<b>TOLERANCES</b> .XXX ±.010 .XX ±.015 ∠ ±.50° UNLESS NOTED OTHERWISE		DRAWN FISCHER 3/7/1995	SIZE <b>A</b>	DWG. NO. <b>95S39917</b>	REV <b>F</b>
APPLICATION					APPROVED MG 4/4/1995			
					ISSUED GMF 4/4/1995			

NOTES :

1. INTERPRET DRAWING PER ASME Y14.100M-2004
2. INTERPRET ELECTRICAL AND ELECTRONIC DIAGRAMS PER IEEE 315-1975

FOR DETAILED ASSEMBLY INSTRUCTIONS REFER TO: **NONE**

REVISIONS				
DWN	REV	DESCRIPTION	DATE	APPROVED
DWF	D	Redrawn in Solid Edge	'08/06/23	<i>MJE</i>
		Added CN14 & CN25		
		Changed test probe wiring from 4 wires to 2 wires		




<b>PROPRIETARY NOTICE:</b>		This Drawing and Information Contained Within is Proprietary to Thunder Scientific and cannot be Copied or Reproduced without Written Permission		
		<b>TOLERANCES</b> .X ± .015 .XX ± .010 .XXX ± .005 / ± 0.50° UNLESS OTHERWISE SPECIFIED	<b>PRODUCTION DESIGNATION</b> <b>39-Z-18</b>	<b>THIRD ANGLE PROJECTION</b> 
	3900		<b>DRAWN</b> Fischer	<b>DATE</b> '95/09/15
<b>NEXT ASSY</b>	<b>USED ON</b>	<b>TREATMENT NOTE 6</b>	<b>CHECKED</b> <i>zfa</i>	'95/09/19
<b>APPLICATION</b>	<b>FINISH</b>	<b>SEE NOTE 7</b>	<b>ISSUED</b> <i>zfa</i>	'95/09/19
		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123-3198		<b>SCHEMATIC, TEST TEMPERATURE PROBE / TEST PRESSURE TRANSDUCER</b>
		<b>DWG SIZE</b> A	<b>DWG NO.</b> 95S39918	<b>REV</b> D
		<b>SCALE</b> NTS	<b>WEIGHT</b>	<b>SHEET</b> 1 OF 1

NOTES :

1. INTERPRET DRAWING PER ASME Y14.100-2004
2. INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5M-1994
3. INTERPRET WELDS PER AWS A2.4:2007
4. ALL UNITS ARE IN INCHES UNLESS OTHERWISE SPECIFIED
5. REMOVE ALL BURRS AND SHARP EDGES
6. TREATMENT :
7. FINISH :

FOR DETAILED ASSEMBLY INSTRUCTIONS REFER TO:  
**NONE**

REVISIONS				
DWN	REV	DESCRIPTION	DATE	APPROVED




PARTS LIST

<b>PROPRIETARY NOTICE:</b>		This Drawing and Information Contained Within is Proprietary to Thunder Scientific and cannot be Copied or Reproduced without Written Permission		
96A39019	3900	<b>TOLERANCES</b> .X ± .015 .XX ± .010 .XXX ± .005 / ± 0.50° <small>UNLESS OTHERWISE SPECIFIED</small>	PRODUCTION DESIGNATION <b>39-Z-21</b>	THIRD ANGLE PROJECTION 
NEXT ASSY	USED ON		DRAWN Furry CHECKED <i>MJE</i> ISSUED <i>MMF</i>	DATE '08/05/15 '08/09/22 '08/09/22
APPLICATION	FINISH	TREATMENT NOTE 6 SEE NOTE 7	3900 Card Cage Schematic DWG SIZE <b>A</b> DWG NO. 08S39921 REV SCALE NTS WEIGHT SHEET 1 OF 1	

REVISIONS				
DWN	REV.	DESCRIPTION	DATE	APP. BY
DWF	A	DRAWN TO SW	6/14/2018	BB

ALL FITTINGS MUST BE TIGHT. OPEN ONLY WHEN SATURATION TEMPERATURE IS AT OR ABOVE 12 °C




REMOVE EXPANSION TANK ACCESS PLUG AND ADD METHANOL HERE

REMOVE SATURATOR METHANOL ACCESS CAP AND OBSERVE METHANOL LEVEL HERE

RTD1 (SATURATOR TEMP PROBE)

METHANOL EXPANSION TANK

METHANOL FULL LEVEL



SECTION "A" - "A"

SATURATOR

ADD METHANOL ONLY WHEN SYSTEM IS AT 12 °C OR ABOVE


SLOWLY ADD METHANOL TO THE METHANOL EXPANSION TANK UNTIL METHANOL IS OBSERVED IN THE SATURATOR METHANOL ACCESS PORT

REFER TO SECTION 2.3.1 IN THE SERIES 3900 OPERATION AND MAINTENANCE MANUAL

**SERIES 3900  
LOW HUMIDITY  
GENERATOR**

DO NOT SCALE FROM DRAWING		THIRD ANGLE PROJECTION	PROPRIETARY NOTICE THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION			<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123		
NEXT ASSY	USED ON		TOLERANCES .XXX ±.010 .XX ±.015 ∠ ±.50° UNLESS NOTED OTHERWISE			DRAWN FURRY 7/08/2008 APPROVED BB 7/11/2008 ISSUED GMF 7/11/2008		Methanol Fill Level Drawing
APPLICATION		SIZE <b>A</b>	DWG. NO. <b>08D39922</b>		REV <b>A</b>		WT. 326.65	
			SHEET 1 OF 1					

1. Place manifold on counter top.
2. Connect "Conditioned Gas Outlet" to manifold.
3. Connect Outlet tube as shown.
4. Connect "Test Pressure" Transducer as shown.
5. Attach "Test Temperature" sensor to housing.
6. Insert probes to be calibrated into sample cell(s).
7. Operate 3900 per operations manual using a gas flow rate of 4.0 L/min.



NOTE: - Swagelok® fitting  
tightening instructions.

1. Insert tubing with pre-swaged ferrules into fitting body.
2. Tighten nut by hand. Then tighten with a wrench an additional 1/8th turn.

		THIRD ANGLE PROJECTION	<b>PROPRIETARY NOTICE</b> THIS DRAWING AND INFORMATION CONTAINED WITHIN IS PROPRIETARY TO THUNDER SCIENTIFIC AND CANNOT BE COPIED OR REPRODUCED WITHOUT SPECIFIC WRITTEN PERMISSION		<b>Thunder Scientific Corporation</b> 623 Wyoming S.E. Albuquerque, NM 87123			
					<b>4 Port Sample Cell Assembly</b>			
	3900	<b>TOLERANCES</b> .XXX ±.005 .XX ±.010 .X ±.015 ∠ ±.50° UNLESS NOTED OTHERWISE	DRAWN	FURRY	12/15/2015	SIZE	DWG. NO.	REV
NEXT ASSY	USED ON		CHECKED		12/16/2015	<b>A</b>	<b>15A39504</b>	-
APPLICATION			ISSUED		12/16/2015	SCALE: NTS	WT. N/A	SHEET 1 OF 1

# Command Summary

---

The following is a comprehensive list of commands, grouped by type, which are available over the RS-232 interface. Each of the commands is organized in alphabetical order on the following pages. Each command contains examples of its usage and proper syntax.

## Setpoint / Data Retrieval Commands

- ? Returns current system actual/generated values
- ?DP Returns current value of generated Dew Point
- ?FL Returns current value of actual Flow Rate
- ?FP Returns current value of generated Frost Point
- ?PG Returns current value of actual Supply Pressure
- ?PS Returns current value of actual Saturation Pressure
- ?PT Returns current value of actual Test Pressure
- ?PV Returns current value of generated PPMv
- ?PW Returns current value of generated PPMw
- ?RH Returns current value of generated %RH
- ?SP Returns current system setpoint values
- ?TS Returns current value of actual Saturation Temperature
- ?TT Returns current value of actual Test Temperature

## Action Commands

- GEN Changes system to generate mode
- PRI Prints system data
- PUR Changes system to purge mode
- SAV Saves system parameters
- STO Stops system

## Setpoint Commands

- DP= Changes Dew Point setpoint
- FL= Changes Flow Rate setpoint
- FP= Changes Frost Point setpoint
- PS= Changes Saturation Pressure setpoint
- PT= Changes Test Pressure setpoint
- PV= Changes PPMv setpoint
- PW= Changes PPMw setpoint
- RH= Changes %RH setpoint
- TS= Changes Saturation Temperature setpoint
- TT= Changes Test Temperature setpoint

---

---

## Utility/Status Commands

**?CL** Returns number of Saturator Clear cycles remaining  
**CL=** Sets number of Saturator Clear cycles  
**?DA** Returns the system date  
**?DF** Returns Date Format type  
**DF=** Sets Date Format type  
**?ER** Returns Error code  
**?MW** Returns Molecular Weight  
**MW=** Sets Molecular Weight  
**?PI** Returns Print Interval  
**PI=** Sets Print Interval  
**?PR** Returns Print On/Off status  
**PR=** Sets Print On/Off status  
**?PU** Returns Pressure Units type  
**PU=** Sets Pressure Units type  
**?RU** Returns Run status  
**?TF** Returns Cabinet Fan Temperature  
**?TI** Returns the system time  
**?WM** Returns WMO calculation status  
**WM=** Sets WMO calculation status

# Read Actual Values



<b>Description</b>	Returns the current generated system values.
<b>Prerequisites</b>	None
<b>Syntax</b>	?
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>

? returns a list of 11 comma separated values indicating the current data and status of the system. These values are returned in the same order as they appear on the 3900 screen. The values in the sequence shown represent the following:

<u>ITEM</u>	<u>DESCRIPTION</u>
1	Frost Point °C
2	Dew Point °C
3	PPMv
4	PPMw
5	%RH
6	Saturation Pressure, in current system units
7	Saturation Temperature, °C
8	Test Pressure, in current system units
9	Test Temperature, °C
10	Flow Rate, l/m
11	System Status

The System Status parameter (item 11 above) indicates the system's generation status. The three possible returned values are as follows:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	System is idle
1	System is running
-1	System is purging

## Examples

The ? command is used to request the current generated system values and status. This example assumes current system pressure units are set to psi.

computer sends  
3900 responds

```
?<CR>  
-10,-11.23, 2581, 1606, 10.39, 34.73,-.01, 14.7, 21.1, .5, 1<CR><LF>
```

?

---

The data returned indicates that the system is currently running (last item in the list=1), and the generated values are:

Frost Point = -10 °C  
Dew Point = -11.23 °C  
PPM<sub>v</sub> = 2581  
PPM<sub>w</sub> = 1606  
%RH = 10.39  
Sat Pressure = 34.73 psiA  
Sat Temperature = -0.01 °C  
Test Pressure = 14.7 psiA  
Test Temperature = 21.1 °C  
Flow Rate = 0.5 l/m

**See Also**      **GEN, ?PU, PU=, PUR, ?RU, ?SP, STO**

## Read Saturator Clear Cycles

# ?CL

---

<b>Description</b>	Returns an integer value that corresponds to the number of Saturator Clear cycles left to complete.
<b>Prerequisites</b>	Firmware Ver 2.0 or newer
<b>Syntax</b>	?CL ?CLEAR
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>  ?CL returns the number of saturator clear cycles left to complete.
<b>Examples</b>	The ?CL command is used to request the number of saturator clears left to complete:  computer sends      ?CL<CR> 3900 responds      0<CR><LF>  The "0" returned indicates that there are no more clear cycles left to complete.
<b>See Also</b>	CL=, PUR

# CL=

## Set Saturator Clear Cycles

---

### Description

Changes the number of Saturator Clear Cycles to a given value.

### Prerequisites

Firmware Ver 2.0 or newer

### Syntax

**CL=***value*

### Parameters

*value*

The *value* is the number of clear cycles the generator should complete before returning to a purge mode.

### Remarks

#### Data Returned

None. The only response is a carriage return/linefeed terminator. If the generator is not in a purge mode then the carriage return/linefeed terminator will be returned but the command will not be processed.

### Examples

The **CL=***value* command is used to set the number of clear cycles to five, assuming the generator is currently in the purge mode:

computer sends  
3900 responds

**CL= 5**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?CL, PUR

## Read System Date

# ?DA

---

**Description** Returns the current system date.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?DA  
?DATE

**Parameters** None

**Remarks** Data Returned

?DA returns the system date in the current date format.

**Examples** The ?DA command is used to request the current date, assuming the system is using the default US date format:

computer sends  
3900 responds

?DA<CR>  
10/11/95<CR><LF>

The date returned indicates that the system date is 11 October 1995.

**See Also** ?DF, DF=, ?TI

# ?DF

## Read Date Format

---

**Description** Returns an integer value that corresponds to a date format type.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?DF

**Parameters** None

**Remarks** Data Returned

?DF returns one of two values to indicate the current date format. The two possible returned values are as follows:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	US date format, mm/dd/yy
1	European date format, dd/mm/yy

**Examples** The ?DF command is used to request the current date format:

computer sends  
3900 responds

?DF<CR>  
0<CR><LF>

The "0" returned indicates that the system is using the US date format, mm/dd/yy.

**See Also** DF=

# Change Date Format

# DF=

**Description** Changes the system date format to one of two possible date format types.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** **DF=***value*

**Parameters**  
*value* The *value* corresponds to a date format type. The date format types are as follows:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	US date format, mm/dd/yy
1	European date format, dd/mm/yy

A value other than 0 or 1 will cause the system to default to the US date format.

**Remarks** Data Returned

None. The only response is a carriage return/linefeed terminator.

Saving Changes to Non-Volatile Memory

The **DF=***value* command only temporarily changes the date format. Changes will be lost on power down of the system or when switching to the Edit or Cal mode using the front panel keypad. To save the changes permanently, use the **SAV** command.

**Examples** The **DF=***value* command is used to change the current date format to a European style:

computer sends  
3900 responds

**DF=** 1<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also** ?DF, SAV

# ?DP

## Read Generated Dew Point

---

**Description** Returns the current value of the Dew Point being generated.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?DP

**Parameters** None

**Remarks** Data Returned

The value returned is the Dew Point value, in °C, calculated from the current generator values for Ts, Ps, Tt, and Pt.

**Examples** The ?DP command is used to request the current Dew Point value:

computer sends  
3900 responds

```
?DP<CR>  
10.5<CR><LF>
```

The generator is currently generating a Dew Point of 10.5 °C.

**See Also** ?

# Change Dew Point Setpoint

# DP=

**Description** Changes the Dew Point setpoint to a given value.

**Prerequisites** None

**Syntax** **DP=***setpoint*

**Parameters**  
*setpoint* The *setpoint* value is the Dew Point, in °C, that the system should generate.

**Remarks** Control Mode Changed

Sending **DP=***setpoint* also changes the control mode to Dew Point (mode 1). In this mode PPM<sub>v</sub>, PPM<sub>w</sub>, %RH and Saturation Pressure setpoints vary as system temperatures and pressures change.

Data Returned

None. The only response is a carriage return/linefeed terminator.

**Examples** The **DP=***setpoint* command is used to set the Dew Point setpoint to 10 °C.

computer sends **DP=10**<CR>  
3900 responds <CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also** ?SP

# ?ER

## Read Error Number

---

**Description** Returns the current error number relating to system shutdown.

**Prerequisites** None

**Syntax** ?ER

**Parameters** None

**Remarks** Data Returned

?ER returns one of several values indicating the reason(s) that the system shut down. The value returned can be any one, or an algebraic combination, of several, of the following:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	No Error
1	Expansion Valve Not Closing
2	Flow Valve Not Closing
4	Low Supply Pressure
8	Cabinet Temperature Overrange
32	Reference Temperature Underrange
48	Reference Temperature Overrange
64	Test Temperature Underrange
80	Test Temperature Overrange
128	Saturation Temperature Underrange
144	Saturation Temperature Overrange
512	Test Pressure Underrange
768	Test Pressure Overrange
1024	Low Range Saturation Pressure Underrange
1280	Low Range Saturation Pressure Overrange
2048	High Range Saturation Pressure Underrange
2304	High Range Saturation Pressure Overrange

**Examples** After an unexpected system shutdown (indicated by the value returned from the ?RU command or the last parameter in the ? command), the ?ER command is used to determine the nature of the failure:

computer sends      ?ER<CR>  
3900 responds      4<CR><LF>

The "4" returned indicates that the system shutdown due to a low supply pressure.

**See Also** ?, ?RU

## Read Flow Rate

# ?FL

---

**Description** Returns the current value of the Flow Rate.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?FL

**Parameters** None

**Remarks** Data Returned

The value returned is the current value of the Flow Rate in liters/minute.

**Examples** The ?FL command is used to request the current Flow Rate:

computer sends ?FL<CR>  
3900 responds 3.027CR><LF>

The current flow rate is 3.027 l/min.

**See Also** ?

# FL=

## Change Flow Rate Setpoint

---

### Description

Changes the Flow Rate setpoint to a given value.

### Prerequisites

Firmware Ver 2.0 or newer

### Syntax

**FL=***setpoint*

### Parameters

*setpoint*

The *setpoint* value is the Flow rate, in l/m, that the system should control at.

### Remarks

Data Returned

None. The only response is a carriage return/linefeed terminator.

### Examples

The **FL=***setpoint* command is used to set the Flow Rate setpoint to 0.5 l/m.

computer sends  
3900 responds

**FL=.5**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?SP

# Read Generated Frost Point

# ?FP

---

<b>Description</b>	Returns the current value of the Frost Point being generated.
<b>Prerequisites</b>	Firmware Ver 2.0 or newer
<b>Syntax</b>	?FP
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>  The value returned is the Frost Point value, in °C, calculated from the current generator values for Ts, Ps, Tt, and Pt. Frost Point values that are above 0 °C are most likely invalid, use Dew Point.
<b>Examples</b>	The ?FP command is used to request the current Frost Point value:  computer sends           ?FP<CR> 3900 responds           -27.5<CR><LF>  The generator is currently generating a Frost Point of -27.5 °C.
<b>See Also</b>	?

# FP=

## Change Frost Point Setpoint

---

### Description

Changes the Frost Point setpoint to a given value.

### Prerequisites

None

### Syntax

**FP=***setpoint*

### Parameters

*setpoint*

The *setpoint* value is the Frost Point, in °C, that the system should generate.

### Remarks

Control Mode Changed

Sending **FP=***setpoint* also changes the control mode to Frost Point (mode 0). In this mode PPM<sub>v</sub>, PPM<sub>w</sub>, %RH and Saturation Pressure setpoints vary as system temperatures and pressures change.

Data Returned

None. The only response is a carriage return/linefeed terminator.

### Examples

The **FP=***setpoint* command is used to set the Frost Point setpoint to -10 °C.

computer sends  
3900 responds

**FP=-10**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?SP

**Description** Starts the system just as if the front panel "GEN" key had been pressed.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** **GEN**  
**GENERATE**

**Parameters** None

**Remarks** Data Returned

None. The only response is a carriage return/linefeed terminator.

**Examples** The **GEN** command is used to start the system.

computer sends  
*3900 responds*

**GEN**<CR>  
<CR><LF>

The <CR><LF> response will be delayed several seconds until the system start-up is complete.

**See Also** **PUR, STO**

# ?MW

## Read Molecular Weight

---

**Description** Returns the molecular weight of the carrier gas in g/mol.

**Prerequisites** None

**Syntax** ?MW

**Parameters** None

**Remarks** Data Returned

?MW returns the value currently being used as the molecular weight of the carrier gas in g/mol. The molecular weight of the carrier gas is used by the system when calculating PPMw from the fundamental measurements of Ts, Ps, Tt and Pt.

**Examples** The ?MW command is used to request the current Molecular Weight value:

computer sends  
3900 responds

?MW<CR>  
28<CR><LF>

The 28.00 g/mol returned indicates that the system is most likely using Nitrogen (N<sub>2</sub>) as the supply gas type.

**See Also** MW=

# Change Molecular Weight

# MW=

**Description** Changes the value used as the Molecular Weight of the carrier gas to a given value.

**Prerequisites** None

**Syntax** **MW=***value*

**Parameters**  
*value* The *value* is the molecular weight of the carrier/supply gas in grams/mole. If zero is input for the molecular weight the system will revert to a default value of 28.9645, the molecular weight of Air. PPMw is the only parameter directly affected by the value entered.

**Remarks** Data Returned

None. The only response is a carriage return/linefeed terminator.

Saving Changes to Non-Volatile Memory

The **MW=***value* command only temporarily changes the value used as the molecular weight of the carrier/supply gas. Changes will be lost on power down of the system or when switching to the Edit or Cal mode using the front panel keypad. To save the changes permanently, use the **SAV** command.

Validity of Enhancement Factors

The Molecular Weight does not alter the Enhancements Factors in any way or compensate for variations in solubility or compressibility of various gasses. Therefore, when using a carrier gas other than air or nitrogen, the validity of the Enhancement Factors used in the calculation of humidity parameters can not be assured.

**Examples** The **MW=***value* command is used to set the Molecular Weight value to 28.9645 g/mol.

computer sends  
3900 responds

**DP=28.9645**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also** ?MW, SAV

# ?PG

## Read Gas Supply Pressure

---

**Description** Returns the current value of the Gas Supply Pressure.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?PG

**Parameters** None

**Remarks** Data Returned

The value returned is the current value of the Gas Supply Pressure in current system units.

**Examples** The ?PG command is used to request the current Gas Supply Pressure value, assuming the system units are in psi:

computer sends  
3900 responds

?PG<CR>  
259.3<CR><LF>

The current gas supply pressure is 259.3 psiG.

## Read Print Interval

# ?PI

---

<b>Description</b>	Returns the print interval in seconds.
<b>Prerequisites</b>	Firmware Ver 2.0 or newer
<b>Syntax</b>	?PI
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>  ?PI returns the value currently being used as the print interval in seconds.
<b>Examples</b>	The ?PI command is used to request the current print interval:  computer sends       ?PI<CR> 3900 responds     300<CR><LF>  The 300 seconds returned indicates that the system will send a line of data to the printer that is connected to the systems printer port once every five minutes.
<b>See Also</b>	PI=

# PI=

## Change Print Interval

---

### Description

Changes the printer interval to a given value and executes a Print Now command (PRI).

### Prerequisites

Firmware Ver 2.0 or newer

### Syntax

**PI=value**

### Parameters

*value*

The *value* is the time interval (in whole seconds) that the system will use as the lapse time between printed data points.

### Remarks

Data Returned

None. The only response is a carriage return/linefeed terminator.

Saving Changes to Non-Volatile Memory

The **PI=value** command only temporarily changes the value used as the Print interval. Changes will be lost on power down of the system or when switching to the Edit or Cal mode using the front panel keypad. To save the changes permanently, use the **SAV** command.

### Examples

The **PI=value** command is used to set the print interval to 60 seconds.

computer sends  
3900 responds

**PI=60**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?PI, PRI, SAV

## Read Print ON/OFF Status

# ?PR

---

<b>Description</b>	Returns an integer value that is associated with the Print On/Off status.						
<b>Prerequisites</b>	Firmware Ver 2.0 or newer						
<b>Syntax</b>	<b>?PR</b>						
<b>Parameters</b>	None						
<b>Remarks</b>	<p><u>Data Returned</u></p> <p><b>?PU</b> returns an integer value indicating the print function is on or off. The printer status values are as follows:</p> <table><thead><tr><th><u>VALUE</u></th><th><u>DESCRIPTION</u></th></tr></thead><tbody><tr><td>0</td><td>Print is off</td></tr><tr><td>1</td><td>Print is on</td></tr></tbody></table>	<u>VALUE</u>	<u>DESCRIPTION</u>	0	Print is off	1	Print is on
<u>VALUE</u>	<u>DESCRIPTION</u>						
0	Print is off						
1	Print is on						
<b>Examples</b>	<p>The <b>?PR</b> command is used to request the current print function status:</p> <p>computer sends <b>?PU</b>&lt;CR&gt; 3900 responds 1&lt;CR&gt;&lt;LF&gt;</p> <p>The 1 returned indicates that the print function is on.</p>						
<b>See Also</b>	<b>PR=</b>						

# PR=

## Change Print ON/OFF Status

---

**Description** Changes the current print on/off status.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** **PU=***value*

**Parameters**

*value*

The *value* corresponds to the following:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	Print off
1	Print on

**Remarks**

Data Returned

None. The only response is a carriage return/linefeed terminator.

**Examples**

The **PR=***value* command is used to turn on the generators print function.

computer sends  
3900 responds

**PR=1**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also**

?PR

**Description** Sends one line of data to a printer if connected to the 3900's printer port just as if the front panel Enter or Decimal Point key had been pressed in a non-setpoint entering mode.

**Prerequisites** The system must be running, and the serial port parameters must match between the 3900 and the printer used. See section 3.3.2.6 Printer Port Parameters of the 3900 Operations Manual to review and edit parameters.

**Syntax** **PRI**  
**PRINT**

**Parameters** None

**Remarks** Data Returned

None. The only response is a carriage return/linefeed terminator. If the system is not running or no printer is connected, printing will not take place; but the carriage return/linefeed terminator will still be sent back.

**Examples** The **PRINT** command is used to send a line of data to the printer which is connected to the 3900.

computer sends  
3900 responds

**PRI**<CR>  
<CR><LF>

The <CR><LF> response indicates completion of the command even if the system is currently stopped or no printer is connected.

# ?PS

## Read Saturation Pressure

---

**Description** Returns the current value of the Saturation Pressure.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?PS

**Parameters** None

**Remarks** Data Returned

The value returned is the current value of the Saturation Pressure in current system units.

**Examples** The ?PS command is used to request the current Saturation Pressure value, assuming the system units are in psi:

computer sends  
3900 responds

```
?PS<CR>  
150<CR><LF>
```

The saturation pressure is currently 150 psiA.

**See Also** ?

# Change Saturation Pressure Setpoint **PS=**

---

**Description** Changes the Saturation Pressure setpoint to a given value.

**Prerequisites** None

**Syntax** **PS=***setpoint*

**Parameters**  
*setpoint* The *setpoint* value is the Saturation Pressure, in current system units, that the system should control at.

**Remarks** Control Mode Changed  
  
Sending **PS=***setpoint* also changes the control mode to Saturation Pressure (mode 5). In this mode Frost Point, Dew Point, PPMv, PPMw and RH setpoints vary as system temperatures and test pressure change.

Data Returned

None. The only response is a carriage return/linefeed terminator.

**Examples** The **PS=***setpoint* command is used to set the Saturation Pressure setpoint to 121.4 psiA, assuming current system pressure units are set to psi.

computer sends  
3900 responds

**PS=121.4**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also** ?PU, PU=.

# ?PT

## Read Test Pressure

---

**Description** Returns the current Test Pressure value.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?PT

**Parameters** None

**Remarks** Data Returned

The value returned is the current value of the Test Pressure in current system units. If the external pressure transducer is not connected then this value is the test pressure setpoint value.

**Examples** The ?PT command is used to request the current Test Pressure, assuming current system pressure units are set to psi:

computer sends  
3900 responds

```
?PT<CR>  
14.7<CR><LF>
```

The test pressure is currently 14.7 psiA.

**See Also** ?

# Change Test Pressure Setpoint

# PT=

---

<b>Description</b>	Changes the Test Pressure setpoint to a given value.
<b>Prerequisites</b>	None
<b>Syntax</b>	<b>PT=</b> <i>setpoint</i>
<b>Parameters</b> <i>setpoint</i>	The <i>setpoint</i> value is the Test Pressure, in current system units, that the system should use for calculations when the external pressure transducer is not connected.
<b>Remarks</b>	<u>Data Returned</u>  None. The only response is a carriage return/linefeed terminator.
<b>Examples</b>	<b>PT=</b> <i>setpoint</i> command is used to set the Test Pressure default to 14 psiA, assuming current system pressure units are set to psi.  computer sends 3900 responds <b>PT=14</b> <CR> <CR><LF>  The <CR><LF> response signifies completion of the command.
<b>See Also</b>	?PU, PU=.

# ?PU

## Read Pressure Units

---

**Description** Returns an integer value that is associated with the Pressure unit's type.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?PU

**Parameters** None

**Remarks** Data Returned

?PU returns an integer value indicating which of the 3 possible pressure unit types the system is using. The Pressure unit types are as follows:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	psi, pounds per square inch
1	bar
2	hPa, hectoPascals

**Examples** The ?PU command is used to request the current pressure units type:

computer sends  
3900 responds

```
?PU<CR>  
2<CR><LF>
```

The 2 returned indicates that the system is operating in hPa, hectoPascals.

**See Also** PU=

# Change Pressure Units

# PU=

## Description

Changes the current pressure units type.

## Prerequisites

Firmware Ver 2.0 or newer

## Syntax

**PU=***value*

## Parameters

*value*

The *value* corresponds to one of the three following pressure unit types:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	psi, pounds per square inch
1	bar
2	hPa, hectoPascals

## Remarks

### Data Returned

None. The only response is a carriage return/linefeed terminator.

### Saving Changes to Non-Volatile Memory

The **PU=***value* command only temporarily changes the pressure units type. Changes will be lost on power down of the system or when switching to the Edit or Cal mode using the front panel keypad. To save the changes permanently, use the **SAV** command.

## Examples

computer sends  
3900 responds

**PU=1**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

## See Also

?PU, SAV

# PUR

## Purge the System

---

### Description

Starts the system in the purge mode, just as though the Purge mode had been activated from the front panel.

### Prerequisites

Firmware Ver 2.0 or newer

### Syntax

**PUR**  
**PRG**  
**PURGE**

### Parameters

None

### Remarks

Data Returned

None. The only response is a carriage return/linefeed terminator.

### Examples

The **PUR** command is used to start the system in the purge mode.

computer sends  
*3900 responds*

**PUR**<CR>  
<CR><LF>

The <CR><LF> response will be delayed several seconds until system purge mode configuration is complete.

### See Also

**GEN, STO**

**Description** Returns the current value of the PPMv, Parts Per Million by Volume, being generated.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?PV

**Parameters** None

**Remarks** Data Returned

The value returned is the PPMv value calculated from the current generator values for Ts, Ps, Tt, and Pt.

**Examples** The ?PV command is used to request the current PPMv value:

computer sends      ?PV<CR>  
3900 responds      2485.368<CR><LF>

The generator is currently generating 2485.368 parts per million by volume.

**See Also** ?

# PV=

## Change PPMv Setpoint

---

### Description

Changes the PPMv setpoint to a given value.

### Prerequisites

None

### Syntax

**PV=***setpoint*

### Parameters

*setpoint*

The *setpoint* value is the PPMv that the system should generate.

### Remarks

Control Mode Changed

Sending **PV=***setpoint* also changes the control mode to PPMv (mode 2). In this mode Frost Point, Dew Point, %RH and Saturation Pressure setpoints vary as system temperatures and pressures change.

Data Returned

None. The only response is a carriage return/linefeed terminator.

### Examples

The **PV=***setpoint* command is used to set the PPMv setpoint to 2500.

computer sends  
3900 responds

**PV=2500**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?SP

**Description** Returns the current value of the PPMw, Parts Per Million by Weight, being generated.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?PW

**Parameters** None

**Remarks** Data Returned

The value returned is the PPMw value calculated from the current generator values for Ts, Ps, Tt, Pt and the molecular weight of the gas type being used.

**Examples** The ?PW command is used to request the current PPMw value:

computer sends ?PW<CR>  
3900 responds 1546.249<CR><LF>

The generator is currently generating 1546.249 parts per million by weight.

**See Also** ?

# PW=

## Change PPMw Setpoint

---

### Description

Changes the PPMw setpoint to a given value.

### Prerequisites

None

### Syntax

**PW=***setpoint*

### Parameters

*setpoint*

The *setpoint* value is the PPMw that the system should generate.

### Remarks

Control Mode Changed

Sending **PW=***setpoint* also changes the control mode to PPMw (mode 3). In this mode Frost Point, Dew Point, %RH and Saturation Pressure setpoints vary as system temperatures and pressures change.

Data Returned

None. The only response is a carriage return/linefeed terminator.

### Examples

The **PW=***setpoint* command is used to set the PPMw setpoint to 1000.

computer sends  
3900 responds

**PW=1000**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?SP

## Read Generated %RH

# ?RH

---

**Description** Returns the current value of the %RH being generated.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?RH

**Parameters** None

**Remarks** Data Returned

The value returned is the %RH value calculated from the current generator values for Ts, Ps, Tt, and Pt as defined by the RH calculation method.

**Examples** The ?RH command is used to request the current %RH value:

computer sends      ?RH<CR>  
3900 responds      10<CR><LF>

The generator is currently generating 10% RH.

**See Also** ?, ?WM, WM=

# RH=

## Change RH Setpoint

---

**Description** Changes the RH setpoint to a given value.

**Prerequisites** None

**Syntax** **RH=***setpoint*

**Parameters**  
*setpoint* The *setpoint* value is the %RH that the system should generate.

**Remarks** Control Mode Changed  
  
Sending **RH=***setpoint* also changes the control mode to %RH (mode 4). In this mode Frost Point, Dew Point, PPM<sub>v</sub>, PPM<sub>w</sub> and Saturation Pressure setpoints vary as system temperatures and pressures change.

Data Returned

None. The only response is a carriage return/linefeed terminator.

**Examples** The **RH=***setpoint* command is used to set the %RH setpoint to 10.

computer sends  
3900 responds

**RH=10**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also** ?SP

---

<b>Description</b>	Returns the current system operating status.								
<b>Prerequisites</b>	None								
<b>Syntax</b>	?RU ?RUN								
<b>Parameters</b>	None								
<b>Remarks</b>	<p><u>Data Returned</u></p> <p>?RU returns one of three values to indicate whether or not the system is currently generating, purging or idle. The three possible returned values are as follows:</p> <table><thead><tr><th><u>VALUE</u></th><th><u>DESCRIPTION</u></th></tr></thead><tbody><tr><td>0</td><td>System is idle</td></tr><tr><td>1</td><td>System is generating</td></tr><tr><td>-1</td><td>System is purging</td></tr></tbody></table>	<u>VALUE</u>	<u>DESCRIPTION</u>	0	System is idle	1	System is generating	-1	System is purging
<u>VALUE</u>	<u>DESCRIPTION</u>								
0	System is idle								
1	System is generating								
-1	System is purging								
<b>Examples</b>	<p>The ?RU command is used to request the current system status:</p> <p>computer sends      ?RU&lt;CR&gt; 3900 responds      0&lt;CR&gt;&lt;LF&gt;</p> <p>The "0" returned indicates that the system is currently idle.</p>								
<b>See Also</b>	?, GEN, PUR, STO								

# SAV

## Save System Parameters

---

### Description

Saves the current system parameters (i.e. Date Format, Molecular Weight, Pressure Units, Print Interval, and RH calculation method) to non-volatile memory for use as system defaults.

### Prerequisites

None

### Syntax

**SAV**  
**SAVE**

### Parameters

None

### Remarks

Data Returned

None. The only response is a carriage return/linefeed terminator.

### Examples

The **SAVE** command is used to save all changes previously made to the system parameters:

computer sends  
3900 responds

**SAVE**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

### See Also

?DF, DF=, ?MW, MW=, ?PI, PI=, ?PU, PU=, ?WM, WM=

# Read Setpoints

# ?SP

<b>Description</b>	Returns the current system Setpoints and operating mode.
<b>Prerequisites</b>	None
<b>Syntax</b>	?SP
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>

?SP returns a list of 11 comma separated values indicating the current setpoints and control mode of the system. These values are returned in the same order as they appear on the 3900 screen. The values in the sequence shown represent the following:

<u>ITEM</u>	<u>DESCRIPTION</u>
1	Frost Point setpoint, °C
2	Dew Point setpoint, °C
3	PPMv setpoint
4	PPMw setpoint
5	%RH setpoint
6	Saturation Pressure setpoint, in current system units
7	Saturation Temperature setpoint, °C
8	Test Pressure setpoint, in current system units
9	Test Temperature setpoint, °C
10	Flow Rate setpoint, l/m
11	Current Control Mode (0 to 5)

The control mode parameter (item 11 above) indicates which of the six possible parameters the system is set to control on. The control modes are as follows:

<u>MODE</u>	<u>DESCRIPTION</u>
0	System controls on Frost Point
1	System controls on Dew Point
2	System controls on PPMv
3	System controls on PPMw
4	System controls on %RH
5	System controls on Saturation Pressure

## Examples

The ?SP command is used to request the system setpoints and control mode. This example assumes current system pressure units are set to psi.

computer sends  
3900 responds

?SP<CR>  
-8.894, -10, 2846, 1771, 11.44, 131.5, 10, 14.7, 21.1, .2, 1<CR><LF>

# ?SP

---

The data returned indicates that the setpoints are:

Frost Point = 8.894 °C

Dew Point = -10 °C (also the control mode)

PPM<sub>v</sub> = 2846

PPM<sub>w</sub> = 1771

%RH = 11.44

Sat Pressure = 131.5 psiA

Sat Temperature = 10 °C

Test Pressure = 14.7 psiA

Test Temperature = 21.1 °C

Flow Rate = 0.2 l/m

and the Control Mode = 1 (Dew Point)

## See Also

**DP=, FL=, FP=, PS=, PT=, PV=, PW=, RH=, TS=, TT=**

## Stop the System

# STO

---

<b>Description</b>	Stops the system just as if the front panel "STOP" key had been pressed.
<b>Prerequisites</b>	None
<b>Syntax</b>	<b>STO</b> <b>STOP</b>
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>  None. The only response is a carriage return/linefeed terminator.
<b>Examples</b>	The <b>STOP</b> command is used to stop a running or purging system.  computer sends <i>3900 responds</i> <b>STOP</b> <CR> <CR><LF>  The <CR><LF> response will be delayed several seconds until the system is vented of pressure and the shutdown complete.
<b>See Also</b>	<b>GEN, PUR</b>

# ?TF

## Cabinet Fan Temperature

---

**Description** Returns the cabinet fan temperature in °C.

**Prerequisites** None

**Syntax** ?TF

**Parameters** None

**Remarks** Data Returned

?TF returns the value (in whole degrees only) of the cabinet fan temperature.

**Examples** The ?TF command is used to read the current cabinet temperature.

computer sends  
3900 responds

?TF<CR>  
30<CR><LF>

The system indicates that the current measured cabinet temperature is 30°C. At this temperature, the cabinet fan should be running.

## Read System Date

# ?TI

---

<b>Description</b>	Returns the current system time.
<b>Prerequisites</b>	Firmware Ver 2.0 or newer
<b>Syntax</b>	?TI ?TIME
<b>Parameters</b>	None
<b>Remarks</b>	<u>Data Returned</u>  ?TI returns the system time in hh:mm:ss.
<b>Examples</b>	The ?TI command is used to request the current time:  computer sends      ?TI<CR> 3900 responds      13:59:32<CR><LF>  The time returned indicates that the system time is 1:59:32 PM.
<b>See Also</b>	?DA

# ?TS

## Read Saturation Temperature

---

**Description** Returns the current value of the Saturation Temperature.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?TS

**Parameters** None

**Remarks** Data Returned

The value returned is the current value of the Saturation Temperature in degrees Celsius.

**Examples** The ?TS command is used to request the current Saturation Temperature:

computer sends  
3900 responds

?TS<CR>  
-15<CR><LF>

The saturation temperature is currently -15 °C.

**See Also** ?

# Change Saturation Temp Setpoint

# TS=

**Description** Changes the Saturation Temperature setpoint to a given value.

**Prerequisites** None

**Syntax** **TS=***setpoint*

**Parameters**  
*setpoint* The *setpoint* value is the Saturation Temperature, in °C, that the system should control at.

**Remarks** Data Returned

None. The only response is a carriage return/linefeed terminator.

Control Modes and Saturation Temperature

An inherent characteristic of the 3900 is its ability to adjust the Saturation Temperature setpoint to allow the generator to achieve a wider range of humidity values. The only mode that the user has complete control over the Saturation Temperature is the Saturation Pressure Control mode, Mode 5. If the control mode is other than mode 5 (Saturation Pressure) the Saturation Temperature may automatically readjust to a value required for the current humidity setpoint independent of any setpoint sent to the generator via the **TS=***setpoint* command.

**Examples** The **TS=***setpoint* command is used to set the Saturation Temperature setpoint to 10°C.

computer sends  
3900 responds **TS=10**<CR>  
<CR><LF>

The <CR><LF> response signifies completion of the command.

**See Also** ?SP

# ?TT

## Read Test Temperature

---

**Description** Returns the current Test Temperature value.

**Prerequisites** Firmware Ver 2.0 or newer

**Syntax** ?TT

**Parameters** None

**Remarks** Data Returned

The value returned is the current value of the Test Temperature in degrees Celsius. If the external temperature probe is not connected then this value is the test temperature setpoint value.

**Examples** The ?TT command is used to request the current Test Temperature:

computer sends  
3900 responds

?TT<CR>  
21.1<CR><LF>

The test temperature is currently 21.1 °C.

**See Also** ?

# Change Test Temperature Setpoint

# TT=

<b>Description</b>	Changes the Test Temperature setpoint to a given value.
<b>Prerequisites</b>	None
<b>Syntax</b>	<b>TT=</b> <i>setpoint</i>
<b>Parameters</b> <i>setpoint</i>	The <i>setpoint</i> value is the Test Temperature, in °C that the system should use in calculations when the external temperature probe is not connected.
<b>Remarks</b>	<u>Data Returned</u>  None. The only response is a carriage return/linefeed terminator.
<b>Examples</b>	The <b>TT=</b> <i>setpoint</i> command is used to set the Test Temperature default to 25 °C.  computer sends 3900 responds <b>TT=25</b> <CR> <CR><LF>  The <CR><LF> response signifies completion of the command.
<b>See Also</b>	?SP

# ?WM

## Read WMO Status

---

**Description** Returns an integer value that corresponds to the RH calculation method.

**Prerequisites** None

**Syntax** ?WM

**Parameters** None

**Remarks** Data Returned

?WM returns one of two values to indicate the current RH calculation method. The two possible returned values are as follows:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	Normal
1	WMO, World Meteorological Organization

**Examples** The ?WM command is used to request the WMO status:

computer sends ?WM<CR>  
3900 responds 0<CR><LF>

The "0" returned indicates that the system is not using the WMO Relative Humidity calculation method.

**See Also** WM=

# Change WMO Status

# WM=

## Description

Changes the system RH calculation method.

## Prerequisites

None

## Syntax

**WM=*status***

## Parameters

*status*

The *status* corresponds to an RH calculation type. The RH calculation types are as follows:

<u>VALUE</u>	<u>DESCRIPTION</u>
0	Normal
1	WMO, World Meteorological Organization

A value other than 0 or 1 will cause the system to default to the Normal method.

## Remarks

### Data Returned

None. The only response is a carriage return/linefeed terminator.

### Saving Changes to Non-Volatile Memory

The **WM=*status*** command only temporarily changes the RH calculation method. Changes will be lost on power down of the system or when switching to the Edit or Cal mode using the front panel keypad. To save the changes permanently, use the **SAV** command.

## Examples

The **WM=*status*** command is used to change the current RH calculation method to WMO:

computer sends  
3900 responds

```
WM= 1<CR>  
<CR><LF>
```

The **<CR><LF>** response signifies completion of the command.

## See Also

**?WM, SAV**

System Authorization Code:

[3900]

This code was designed to prevent unauthorized personnel access to the calibration coefficients.

**THUNDER SCIENTIFIC® CORPORATION**  
**623 Wyoming Blvd. SE / Albuquerque NM 87123-3198**  
**[www.thunderscientific.com](http://www.thunderscientific.com)**