




REVISIONS			
ZONE	REV.	DESCRIPTION	DATE
886	C	UPDATE FUSE AND CONNECTION	2008/12/02
			XY



	UNLESS OTHERWISE SPECIFIED:		NAME	DATE	QUATROSENSE ENVIRONMENTAL LTD.
	DIMENSIONS ARE IN INCHES		Y. DUBE	03-07-16	
	TOLERANCES:		DRAWN		
	FRACTIONAL: $\pm$		CHECKED		
	ANGULAR: MACH: $\pm$ BEND: $\pm$		ENG APPR.		TITLE: M-CONTROLLER GUIDELINES FOR SYSTEM DESIGN
	HOLE POSITION: $\pm$		MFG APPR.		
	THREE PLACE DECIMAL: $\pm$		Q. A.		
	INTERPRET GEOMETRIC TOLERANCING PER:		COMMENTS:		
	MATERIAL				SIZE DWG. NO. REV B 84350-005-000 C
	FINISH				
NEXT ASSY	USED ON	DO NOT SCALE DRAWING			SCALE: 1:4 WEIGHT: SHEET 1 OF 13

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE PROPERTY OF QUATROSENSE ENVIRONMENTAL LTD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUATROSENSE ENVIRONMENTAL LTD IS PROHIBITED.



NOTE 1 : Power Supply Limitations

- AC Power supplies to the M-Controller must be floating.
- DC Power supplies to the M-Controller may have the negative terminal grounded.
- Power supplies to remote digital (RS-485) sensors may be supplied separately, in which case QEL M-Series sensors can accept AC-Grounded, as per relevant drawings.
- AC Power supplies to the remote M-Relay Modules MUST NOT be AC grounded
- AC Power supplies to the Analog Output card must be floating.
- DC Power supplies to the Analog Output card may be floating or grounded but the connections differ.

NOTE 2 : RS-232 Limitations

- RS-232 ports are ground referenced. Therefore it is best to always use some form of isolated RS-232 connection.
- Laptops running on battery are isolated.
- Do NOT use Laptop power adapters, these will typically have negative (on secondary side) connected to safety ground (on primary side).

NOTE 3 : RS-485 Limitations


- RS-485 connections between devices with separate floating power supplies (and this includes QEL's M-17 which is internally isolated) may have some difficulty due to lack of a positive signal return path.

RS-485 connections operate between devices at different ground potentials. Grounds may differ by up to 5 volts

REVISIONS			
ZONE	REV.	DESCRIPTION	DATE
		SEE SHEET ONE	

				NAME	DATE	QUATROSENSE ENVIRONMENTAL LTD.	
				Y. DUBE	03-07-16		
		UNLESS OTHERWISE SPECIFIED:		DRAWN		TITLE:	
		DIMENSIONS ARE IN INCHES		CHECKED		M-CONTROLLER	
		TOLERANCES:		ENG APPR.		GUIDELINES FOR	
		FRACTIONAL ±		MFG APPR.		SYSTEM DESIGN	
		ANGULAR: MACH ±		Q. A.		SIZE DWG. NO.	
		HOLE PLACES DECIMAL ±		COMMENTS:		B 84350-005-000	
		THREE PLACE DECIMAL ±				REV	
		INTERPRET GEOMETRIC				C	
		TOLERANCING PER:				SCALE: 1:4	
		MATERIAL				SHEET 3 OF 13	
		FINISH					
		USED ON					
		NEXT ASSY					
		APPLICATION					
		DO NOT SCALE DRAWING					

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE PROPERTY OF QUATROSENSE ENVIRONMENTAL LTD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUATROSENSE ENVIRONMENTAL LTD IS PROHIBITED.



NOTE:
BEFORE POWER UP, THE POLARITY OF THE 24VAC POWER SUPPLY SHOULD CHECK CAREFULLY, REVERSING POLARITY ON M-CONTROLLER OR M-5 WILL CAUSE THE RS-485 DRIVER CHIPS BLOW UP.


M-CONTROLLER & M-5
24VAC FLOATING POWER CONNECTIONS

RS-485 CABLE SHOULD WIRE FROM ONE SENSOR TO ANOTHER WITHOUT TEES OR STUB. POWER CABLE DOES NOT MATTER.

REVIEWS		DATE		APPROVED	
ZONE	REV.	DESCRIPTION		DATE	
		SEE SHEET ONE			

NAME	DATE	QUATROSENSE ENVIRONMENTAL LTD
Y. DUBE	03-07-17	
DRAWN		
CHECKED		
ENG APPR.		
MFG APPR.		
Q. A.		
COMMENTS:		
INTERPRET GEOMETRIC TOLERANCING PER:		
MATERIAL		
FINISH		
USED ON		
APPLICATION		
DO NOT SCALE DRAWING		
NEXT ASSY		

SIZE	DWG. NO.	REV
B	84350-005-000	C
SCALE: 1:4		SHEET 5 OF 13



NEGATIVE MAY BE CONNECTED TO GROUND

24VDC SUPPLY

M-CONTROLLER MAIN CCA

POWER SWITCH

END OF LINE RESISTOR SETTING

END OF LINE RESISTOR SETTING

PORT A/B/C/D

PORT A

PORT B

PORT C

PORT D

PORT E

TX- TX+

RX- RX+

RS-422

GND

CH8

CH7

CH6

CH5

CH4

CH3

CH2

CH1

NC

GND

RX

TX


GND

NC

RS-485 CABLE SHOULD WIRE FROM ONE SENSOR TO ANOTHER WITHOUT TEES OR STUB. POWER CABLE DOES NOT MATTER.

M-CONTROLLER & M-5 24VDC POWER CONNECTIONS

UNLESS OTHERWISE SPECIFIED:		NAME	DATE
DIMENSIONS ARE IN INCHES		Y. DUBE	03-07-17
TOLERANCES:			
FRACTIONAL: ±		CHECKED	
ANGULAR: MACH ±		ENG APPR.	
HOLE POSITION: MAX ±		MFG APPR.	
THREE PLACE DECIMAL ±		Q. A.	
INTERPRET GEOMETRIC TOLERANCING PER:		COMMENTS:	
MATERIAL			
FINISH			
USED ON			
APPLICATION			
DO NOT SCALE DRAWING			
NEXT ASSY			
TITLE:		QUATROSENSE ENVIRONMENTAL LTD	
M-CONTROLLER GUIDELINES FOR SYSTEM DESIGN			
SIZE DWG. NO.		REV	
B 84350-005-000		C	
SCALE: 1:4		SHEET 6 OF 13	



RS-485 CABLE SHOULD WIRE FROM ONE SENSOR TO ANOTHER WITHOUT TEES OR STUB. POWER CABLE DOES NOT MATTER.

M-CONTROLLER & M-17 24VAC FLOATING POWER CONNECTIONS

REVISIONS			DATE	APPROVED
ZONE	REV.	DESCRIPTION		
		SEE SHEET ONE		


UNLESS OTHERWISE SPECIFIED:		NAME	DATE	QUATROSENSE ENVIRONMENTAL LTD	
DIMENSIONS ARE IN INCHES		Y. DUBE	03-07-17	TITLE:	
TOLERANCES:		DRAWN		M-CONTROLLER	
FRACTIONAL: 1/16		CHECKED		GUIDELINES FOR	
ANGULAR: MACH 1/2		ENG APPR.		SYSTEM DESIGN	
THREE PLACE DECIMAL: 1/1000		MFG APPR.		SIZE DWG. NO.	
INTERPRET GEOMETRIC TOLERANCING PER:		Q. A.		B 84350-005-000	
MATERIAL		COMMENTS:		REV	
FINISH				C	
NEXT ASSY				SCALE: 1:4	
APPLICATION				SHEET 7 OF 13	

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE PROPERTY OF QUATROSENSE ENVIRONMENTAL LTD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUATROSENSE ENVIRONMENTAL LTD IS PROHIBITED.



PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF QUATROSENSE ENVIRONMENTAL LTD. A REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUATROSENSE ENVIRONMENTAL LTD IS PROHIBITED.


1
2
3
4



8 7 6 5 4 3 2 1

D C B A

REVISIONS			
ZONE	REV.	DESCRIPTION	DATE
		SEE SHEET ONE	



NOTE:
If using grounded DC supply, the supply ground and
the monitor ground must be the same.

Monitor need not be grounded

NON-ISOLATED ANALOG OUTPUT INTERNALLY POWERED ANALOG OUTPUT

UNLESS OTHERWISE SPECIFIED:		NAME	DATE	QUATROSENSE ENVIRONMENTAL LTD	
DIMENSIONS ARE IN INCHES		DRAWN	Y. DUBE	03-07-17	
TOLERANCES:		CHECKED			
FRACTIONAL: $\pm$		ENG APPR.			
ANGULAR: MACH: $\pm$ BEND: $\pm$		MFG APPR.			
HOLE POSITION: $\pm$		Q. A.			
THREE PLACE DECIMAL: $\pm$		COMMENTS:			
INTERPRET GEOMETRIC TOLERANCING PER:					
MATERIAL:					
FINISH:					
USED ON:					
NEXT ASSY:					
APPLICATION:					
DO NOT SCALE DRAWING					

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF QUATROSENSE ENVIRONMENTAL LTD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUATROSENSE ENVIRONMENTAL LTD IS PROHIBITED.

A

TITLE:		M-CONTROLLER GUIDELINES FOR SYSTEM DESIGN	
SIZE	DWG. NO.	REV	
B	84350-005-000	C	

SCALE: 1:4	SHEET 11 OF 13
------------	----------------

1 2 3 4 5 6 7 8

M-CONTROLLER GUIDELINES FOR SYSTEM DESIGN:

A) Power Supply and wiring Considerations

** IMPORTANT **

Mis-wiring the M-System, and/or failing to follow the instructions in the relevant Operation Manuals (supplied with your equipment) can lead to damage to the equipment. It is therefore strongly recommended that you read and understand the relevant product's Operation Manual prior to starting to work with QEL equipment. You must also study the relevant Installation Drawings.

- 24 VAC Power supplies to the M-Controller must be floating.
- **DO NOT USE GROUNDED AC on the M-CONTROLLER or the M-RELAY!**
- If in doubt, measure that there is no continuity between either side of the transformer and ground, or that there is roughly 12 VAC between either side of the transformer and ground.
- If your system design requires a grounded supply, then use an isolating transformer to isolate the M-Controller from ground, or use a DC supply. DC Power supplies to the M-Controller may have the negative terminal grounded.
- The 24 VAC transformer should be dedicated to the M-System, in order to avoid grounding issues. Make sure that a floating transformer is not being grounded out through another device, such as a contactor, damper motor, etc.
- **Use a sufficient wire gauge to supply power to a chain of transmitters.** Consider the length of the wiring runs involved, as well as the maximum current expected on a given line. Insufficient wire gauge on the 24 volt power lines results in inadequate voltage being delivered to the transmitters. The transmitters which are furthest down the line will have the biggest voltage drops. See the table on page 40 of the M-Controller's Operation Manual for details on how to calculate the total current draw down each individual wire run from the M-Controller. Compare this to a wiring table and ensure that the voltage drop is no greater than one or two volts. If in doubt, go with a heavier gauge for power.
- When wiring the system initially, start only by powering-up only the M-controller, then attach the first transmitter: if the M-Controller and the first transmitter appear to be operating properly, communicating and not drawing down the power supply with excessive current, continue wiring to the next transmitter, and so on.
- **Use the recommended wiring for the RS-485 data transmission line, Belden 9841:** It is designed specifically for RS-485 communications, in that it has the proper characteristic impedance of 120 ohms, and is twisted, shielded, and balanced.
- **Use the termination resistor to improve communications quality:** move the appropriate jumper on the last transmitter, as well as on the M-Controller's RS-485 port, on each data line to enable the 120 ohm termination resistor. Consult the relevant manual for jumper location.
- If you connect a laptop to the M-Controller via the RS-232 port, it is best to always use some form of isolated RS-232 connection. Laptops running on battery are isolated. Avoid using the laptop's power adapter when connected to the M-Controller, as these will typically have negative (on secondary side) connected to safety ground (on primary side)!

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF QUATROSENSE ENVIRONMENTAL LTD.
REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUATROSENSE ENVIRONMENTAL LTD. IS PROHIBITED.

- B) Overview: Programming the M-Controller and M-series transmitters
- Follow the instructions in the M-Controller's Operation Manual for specific programming details. Here are some general guidelines on programming an M-Controller.
- **There are two ways to program the controller:** using the keypad and using QEL's M-view software. Both are acceptable.
 - Once the M-Controller and transmitters have been wired together, powered up, the M-Controller will be in it's default condition, reading **'No Sensor', 'No output'**.
 - **'No sensor'** indicates that the controller has not been programmed to with any digital (RS-485) or analog (4-20 mA) inputs.
 - **'No output'** means that no relays, strobe, buzzer, horn or triggers have been programmed, and are therefore not active.
 - When you program the M-Controller, you will be determining:
 - how many and which transmitters (by address) are on the input ports
 - the gas type of each of the transmitters
 - which output devices (i.e. Relays, buzzers, strobes etc.) are active
 - set-points at which the various transmitters will activate specific output devices
 - in the case of an analog input, it is also necessary to program the controller with
 - the appropriate 4-20 mA span
 - You also need to tell the controller what outputs (the three on-board relays are the most commonly used outputs) need to be active.
 - **Make sure that each transmitter has a unique address:** The address will need to be programmed into the transmitter itself iV this is done via the transmitter's menu once the system has power.
 - The default baud rate (communication speed) for the M-System is 4800 bps, which is ideal for most applications.
 - Be sure to note the physical location of each address on the site plan iV this is critical when programming the M-Controller and assigning the outputs.

REVISIONS			
ZONE	REV.	DESCRIPTION	DATE
-	-	See Sheet 1	-

UNLESS OTHERWISE SPECIFIED:		NAME	DATE	QUATROSENSE ENVIRONMENTAL LTD	
DIMENSIONS ARE IN INCHES		XY	2008/12	TITLE:	
TOLERANCES:		DRAWN	ROB	M-CONTROLLER	
FRACTIONAL: 1/16		CHECKED		GUIDELINES FOR	
ANGULAR: MACH: 1/16		ENG APPR.		SYSTEM DESIGN	
THREE PLACE DECIMAL: 1/1000		MFG APPR.		SIZE DWG. NO.	
INTERPRET GEOMETRIC TOLERANCING PER:		Q. A.		B 84350-005-000	
MATERIAL		COMMENTS:		REV	
FINISH				C	
USED ON				SCALE: 1:4	
APPLICATION				SHEET 12 OF 13	

C) Typical Scenario – Programming a digital system in 4 steps:

1. Programming the addresses of the transmitters:

- On all M-series transmitters, there are a series of three push buttons: the top is an 'up' button, the middle is a 'down' button, and the bottom is a 'select' or 'enter' button.
- Push and hold the top push button. release at password prompt.
- Push the top (up) button, and scroll to '0017', if you go past '0017' use the middle (down) button to move down, then press the bottom button (enter).
- Use the 'up' or 'down' button to scroll through the menu, stop at 'ADDRESS'.
- Push the bottom (select) button. An asterisk will appear by the displayed value. The asterisk tells you this is a variable you can change.
- Use the 'up' button to select your desired address. If you go past the number you want use the middle (down) button to move down, then press the bottom button (enter).
- Use the 'up' or 'down' button to scroll through the menu, stop at 'EXIT SAVE', press 'enter' button twice.
- Continue until all the sensors on the network all have a unique digital address.
- Ensure that you record the location of each address.

2. Programming the transmitters into the controller:

At this stage we enter the transmitters, their addresses and their gas type at the controller.

- Press the '7' hotkey for 'sensors'. 'Sensor Database' will be displayed, press 'enter/accept'.
- You are then prompted for an 'address' number - enter your first sensor address number and press 'enter/accept'.
- 'gas type' will be displayed. Use the up 'arrow' or down 'arrow' to select your gas type and press 'enter/accept'.
- 'units' will be displayed. Use the up 'arrow' or down 'arrow' to select your unit of measure and press 'enter/accept'.
- Continue until all your sensor addresses are entered. When prompted for a 'sensor no' and you have no more sensors to enter, press 'exit/clear' once. We have now told the controller you have sensors and what they are.

3. Programming the relays into the controller:

This step determines which on-board or remote relays are active, as well as their mode of operation.

- Press the '8' hotkey for 'relay'. 'Relay Database' will be displayed, press 'enter/accept'.
- Press '8' key for 'r=style'.
- You are prompted for a 'relay' number, enter your first relay number and press 'enter/accept'.

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.

		UNLESS OTHERWISE SPECIFIED:		QUATROSENSE ENVIRONMENTAL LTD	
		DIMENSIONS ARE IN INCHES	DRAWN	XY	DATE
		FRACTIONAL ±	CHECKED	ROB	2008/12
		ANGULAR: MACH ±	ENG APPR.		
		TWO PLACE DECIMAL ±	MFG APPR.		
		THREE PLACE DECIMAL ±			
		INTERPRET GEOMETRIC TOLERANCING PER:	Q.A.		
		MATERIAL	COMMENTS:		
		FINISH			
NEXT ASSY	USED ON				
APPLICATION		SIZE		DWG. NO.	
		B		84350-005-000	
				REV	
				C	
SCALE: 1:4				SHEET 13 OF 13	

88

7

6

5

4

3

2

1

C) Typical Scenario – Programming a digital system in 4 steps:

1. Programming the addresses of the transmitters:

- On all M-series transmitters, there are a series of three push buttons: the top is an 'up' button, the middle is a 'down' button, and the bottom is a 'select' or 'enter' button.
- Push and hold the top push button. release at password prompt.
- Push the top (up) button, and scroll to '0017', if you go past '0017' use the middle (down) button to move down, then press the bottom button (enter).
- Use the 'up' or 'down' button to scroll through the menu, stop at 'ADDRESS'.
- Push the bottom (select) button. An asterisk will appear by the displayed value. The asterisk tells you this is a variable you can change.
- Use the 'up' button to select your desired address. If you go past the number you want use the middle (down) button to move down, then press the bottom button (enter).
- Use the 'up' or 'down' button to scroll through the menu, stop at 'EXIT SAVE', press 'enter' button twice.
- Continue until all the sensors on the network all have a unique digital address.
- Ensure that you record the location of each address.

2. Programming the transmitters into the controller:

At this stage we enter the transmitters, their addresses and their gas type at the controller.

- Press the '7' hotkey for 'sensors'. 'Sensor Database' will be displayed, press 'enter/accept'.
- You are then prompted for an 'address' number - enter your first sensor address number and press 'enter/accept'.
- 'gas type' will be displayed. Use the up 'arrow' or down 'arrow' to select your gas type and press 'enter/accept'.
- 'units' will be displayed. Use the up 'arrow' or down 'arrow' to select your unit of measure and press 'enter/accept'.
- Continue until all your sensor addresses are entered. When prompted for a 'sensor no' and you have no more sensors to enter, press 'exit/clear' once. We have now told the controller you have sensors and what they are.

3. Programming the relays into the controller:

This step determines which on-board or remote relays are active, as well as their mode of operation.

- Press the '8' hotkey for 'relay'. 'Relay Database' will be displayed, press 'enter/accept'.
- Press '8' key for 'r=style'.
- You are prompted for a 'relay' number, enter your first relay number and press 'enter/accept'.

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.

		UNLESS OTHERWISE SPECIFIED:		QUATROSENSE ENVIRONMENTAL LTD	
		DIMENSIONS ARE IN INCHES	DRAWN	XY	DATE
		FRACTIONAL ±	CHECKED	ROB	2008/12
		ANGULAR: MACH ±	ENG APPR.		
		TWO PLACE DECIMAL ±	MFG APPR.		
		THREE PLACE DECIMAL ±			
		INTERPRET GEOMETRIC TOLERANCING PER:	Q.A.		
		MATERIAL	COMMENTS:		
		FINISH			
NEXT ASSY	USED ON				
APPLICATION		SIZE		DWG. NO.	
		B		84350-005-000	
				REV	
				C	
SCALE: 1:4				SHEET 13 OF 13	

88

7

6

5

4

3

2

1